

Your Global Automation Partner

**TURCK**

TN-UHF-...-CDS

UHF Read/Write Head

Instructions for Use



# Contents

<b>1</b>	<b>About these Instructions</b> .....	<b>7</b>
1.1	Target groups.....	7
1.2	Explanation of symbols used .....	7
1.3	Other documents .....	7
1.4	Naming convention .....	7
1.5	Feedback about these instructions.....	7
<b>2</b>	<b>Notes on the Product</b> .....	<b>8</b>
2.1	Product identification.....	8
2.2	Scope of delivery .....	8
2.3	Legal requirements .....	8
2.4	Manufacturer and service .....	9
<b>3</b>	<b>For Your Safety</b> .....	<b>10</b>
3.1	Intended use.....	10
3.2	General safety notes .....	11
<b>4</b>	<b>Product Description</b> .....	<b>12</b>
4.1	Device overview .....	12
4.1.1	Indication elements .....	12
4.2	Properties and features.....	13
4.3	Operating principle.....	13
4.4	Functions and operating modes .....	14
4.4.1	Operating frequency .....	14
4.4.2	Combination of UHF read/write heads and tags.....	15
4.4.3	Multiprotocol function.....	15
4.4.4	Data transfer to the PLC.....	15
4.4.5	RFID channels – operating modes.....	15
4.4.6	RFID commands .....	16
4.4.7	Loop counter function .....	16
4.4.8	CODESYS OPC UA server .....	16
4.4.9	Compatible CODESYS versions .....	16
4.5	Technical accessories.....	17
<b>5</b>	<b>Installing</b> .....	<b>18</b>
<b>6</b>	<b>Connecting</b> .....	<b>19</b>
6.1	Connecting devices to Ethernet .....	19
6.2	Connecting the power supply .....	20
6.3	Connecting digital sensors and actuators .....	21
6.4	Connecting external antennas .....	22
<b>7</b>	<b>Commissioning</b> .....	<b>23</b>
7.1	Parameterizing read/write heads with the DTM .....	23
7.1.1	Connecting the device with the PC.....	24
7.1.2	Starting the extended read/write head parameter setting .....	27
7.1.3	DTM main menu – overview .....	28
7.1.4	Choosing the access level .....	29
7.1.5	Setting multiplex operation .....	30
7.1.6	Setting antenna power .....	33
7.1.7	Setting antenna polarization .....	40

7.1.8	Switching on presence sensing mode .....	43
7.1.9	Transferring the RSSI value – communication .....	44
7.1.10	Setting the air interface parameters – EPC Class 1 Gen 2.....	45
7.1.11	Setting the RSSI filter – Post read filter.....	46
7.1.12	Setting LED indication – Signaling .....	47
<b>7.2</b>	<b>Parameterizing read/write heads with the web server.....</b>	<b>48</b>
7.2.1	Opening a web server .....	48
7.2.2	Editing settings in the web server .....	49
<b>7.3</b>	<b>Testing read/write heads with the DTM .....</b>	<b>54</b>
7.3.1	Starting the RFID Test.....	55
7.3.2	Start window – overview.....	56
7.3.3	RFID Test – main menu .....	57
7.3.4	RFID Test – Basic test window .....	58
7.3.5	RFID Test – Tag actions window .....	59
7.3.6	RFID Test – Logger window .....	63
7.3.7	HF diagnosis window .....	63
<b>7.4</b>	<b>Testing read/write heads with the web server .....</b>	<b>64</b>
<b>7.5</b>	<b>Querying device information with the DTM .....</b>	<b>67</b>
<b>7.6</b>	<b>Setting the IP address.....</b>	<b>69</b>
7.6.1	Setting the IP address via the Turck Service Tool.....	69
7.6.2	Setting the IP address via the web server .....	71
<b>7.7</b>	<b>Connecting the device to a Modbus master .....</b>	<b>72</b>
7.7.1	Connecting the device with the controller .....	73
7.7.2	Renaming a Modbus slave.....	77
7.7.3	Setting up network interfaces.....	78
7.7.4	Setting Modbus channels (registers) .....	82
7.7.5	Setting the I/O mapping .....	84
7.7.6	Writing the application to the device.....	91
7.7.7	Connecting the device online with the controller.....	98
7.7.8	Reading out process data .....	98
<b>7.8</b>	<b>Connecting a device to an EtherNet/IP controller .....</b>	<b>99</b>
<b>7.9</b>	<b>Connecting a device to a Siemens controller .....</b>	<b>99</b>
7.9.1	Configuring the device in CODESYS as a PROFINET device .....	100
7.9.2	Setting up the network interface .....	106
7.9.3	Connecting a device to a Siemens controller in the TIA Portal.....	110
7.9.4	Reading out process data .....	115
<b>7.10</b>	<b>Starting the device as the Modbus master.....</b>	<b>116</b>
7.10.1	Setting up the network interface .....	121
7.10.2	Setting Modbus channels (registers) .....	125
7.10.3	Connecting Modbus master and Modbus slave online .....	127
7.10.4	Reading out process data .....	127
<b>7.11</b>	<b>Linking the device to the Turck Cloud .....</b>	<b>128</b>
7.11.1	Register or login user and project in the cloud.....	130
7.11.2	Creating a Cloud project .....	131
7.11.3	Activate a device as Cloud gateway in Turck Cloud Portal.....	134
7.11.4	Configuring the Cloud access in the web server.....	137
7.11.5	Transfer process data from CODESYS to the cloud .....	139
7.11.6	Manage data node points from CODESYS symbol table.....	140
<b>7.12</b>	<b>Setting up a CODESYS OPC UA server.....</b>	<b>142</b>

<b>8</b>	<b>Setting</b>	<b>147</b>
8.1	<b>RFID channels – parameter data</b>	<b>147</b>
8.1.1	Meaning of the parameter bits	148
8.1.2	Setting Continuous presence sensing mode	148
8.1.3	Transferring the read/write head settings	149
8.2	<b>RFID channels – process input data</b>	<b>150</b>
8.2.1	Meaning of the status bits	152
8.2.2	Tag in detection range (TP) – using bit or pre-loading the command	153
8.3	<b>RFID channels – process output data</b>	<b>154</b>
8.3.1	Meaning of the command bits	156
8.4	<b>Digital channels – process input data</b>	<b>157</b>
8.4.1	Meaning of the status bits	157
8.5	<b>RFID channels – overview of the commands</b>	<b>158</b>
8.5.1	Command: Idle	160
8.5.2	Command: Inventory	161
8.5.3	Command: Read	164
8.5.4	Command: Write	165
8.5.5	Command: Write and verify	167
8.5.6	Command: Continuous mode	169
8.5.7	Command: Get data from buffer (Continuous mode)	171
8.5.8	Command: UHF continuous presence sensing mode	173
8.5.9	Command: End Continuous (presence sensing) mode	174
8.5.10	Command: Read/write head identification	175
8.5.11	Direct read/write head command	176
8.5.12	Command: Set tag password	178
8.5.13	Command: Set read/write head password	179
8.5.14	Command: Reset read/write head password	180
8.5.15	Command: Set tag protection	181
8.5.16	Command: Tag info	183
8.5.17	Command: Permanently deactivate UHF tags (Kill)	185
8.5.18	Command: Restore UHF read/write head settings	186
8.5.19	Command: Backup settings of the UHF read/write head	187
8.5.20	Command: Query error/status of UHF read/write head	188
8.5.21	Command: Reset	192
8.6	<b>Setting devices via the web server</b>	<b>193</b>
<b>9</b>	<b>Operation</b>	<b>197</b>
9.1	<b>Executing a command and calling data</b>	<b>197</b>
9.2	<b>Using fragmentation</b>	<b>197</b>
9.3	<b>Using commands with a loop counter function</b>	<b>197</b>
9.4	<b>Using Inventory command and Continuous (presence sensing) mode</b>	<b>198</b>
9.5	<b>LEDs</b>	<b>199</b>
9.6	<b>Software diagnostic messages</b>	<b>201</b>
9.6.1	Diagnostic messages – gateway functions	201
9.6.2	Diagnostic messages – RFID channels	201
9.6.3	Diagnostic messages – digital channels	202
9.6.4	Diagnostic messages – device status	202
9.7	<b>Reading error codes</b>	<b>203</b>
<b>10</b>	<b>Troubleshooting</b>	<b>206</b>
10.1	<b>Rectifying errors</b>	<b>207</b>
<b>11</b>	<b>Maintenance</b>	<b>211</b>
11.1	<b>Executing the firmware update via FDT/DTM</b>	<b>211</b>

12	Repair .....	216
12.1	Returning devices.....	216
13	Disposal .....	216
14	Technical Data.....	217
15	Appendix: Flow Charts Showing the Operation of the Device .....	219
15.1	Flow chart: Command processing.....	219
15.2	Flow chart: Rapid command processing with loop counter .....	220
15.3	Flow chart: Command processing with fragmentation .....	221
15.4	Flow chart: Continuous mode with interruption before reading data .....	222
15.5	Flow chart: Continuous mode without interruption before reading data.....	223
16	EU Declaration of Conformity .....	224

# 1 About these Instructions

These operating instructions describe the structure, functions and the use of the product and will help you to operate the product as intended. Read these instructions carefully before using the product. This is to avoid possible damage to persons, property or the device. Retain the instructions for future use during the service life of the product. If the product is passed on, pass on these instructions as well.

## 1.1 Target groups

These instructions are aimed at qualified personal and must be carefully read by anyone mounting, commissioning, operating, maintaining, dismantling or disposing of the device.

## 1.2 Explanation of symbols used

The following symbols are used in these instructions:



**DANGER**

DANGER indicates a dangerous situation with high risk of death or severe injury if not avoided.



**WARNING**

WARNING indicates a dangerous situation with medium risk of death or severe injury if not avoided.



**CAUTION**

CAUTION indicates a dangerous situation of medium risk which may result in minor or moderate injury if not avoided.



**NOTICE**

NOTICE indicates a situation which may lead to property damage if not avoided.



**NOTE**

NOTE indicates tips, recommendations and useful information on specific actions and facts. The notes simplify your work and help you to avoid additional work.



**CALL TO ACTION**

This symbol denotes actions that the user must carry out.



**RESULTS OF ACTION**

This symbol denotes relevant results of actions.

## 1.3 Other documents

Besides this document the following material can be found on the Internet at [www.turck.com](http://www.turck.com):

- Data sheet
- Approvals
- Configuration manual

## 1.4 Naming convention

Common synonyms for "data carriers" include "tag", "transponder", and "mobile storage device". Read/write heads are also described as "transceivers" or "readers".


## 1.5 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to [techdoc@turck.com](mailto:techdoc@turck.com).

## 2 Notes on the Product

### 2.1 Product identification

These instructions apply to the following UHF read/write heads:



### 2.2 Scope of delivery

The scope of delivery includes:

- Read/write head
- Wall bracket (metal rail)
- Quick Start Guide

### 2.3 Legal requirements

The devices are subject to the following EU directives:

- 2014/30/EU (electromagnetic compatibility)
- 2011/65/EU (RoHS Directive)
- 2014/53/EU (RED Directive)



## 2.4 Manufacturer and service

Hans Turck GmbH & Co. KG  
Witzlebenstraße 7  
45472 Mülheim an der Ruhr  
Germany

Turck supports you with your projects, from initial analysis to the commissioning of your application. The Turck product database contains software tools for programming, configuration or commissioning, data sheets and CAD files in numerous export formats. You can access the product database at the following address: [www.turck.de/products](http://www.turck.de/products)

For further inquiries in Germany contact the Sales and Service Team on:

- Sales: +49 208 4952-380
- Technology: +49 208 4952-390

Outside Germany, please contact your local Turck representative.

## 3 For Your Safety

The product is designed according to state-of-the-art technology. However, residual risks still exist. Observe the following warnings and safety notices to prevent damage to persons and property. Turck accepts no liability for damage caused by failure to observe these warning and safety notices.

### 3.1 Intended use

These devices are designed solely for use in industrial areas.

The read/write heads with an integrated RFID interface are used for contactless data exchange with the BL ident tags in the Turck UHF RFID system. The following table shows the operating frequency of the devices:

Type code	Operating frequency	Region
TN-UHF-...-EU-CDS	865...868 MHz	Europe
TN-UHF-...-NA-CDS	902...928 MHz	North America (USA, Canada, Mexico)
TN-UHF-...-CHN-CDS	920.5...924.5 MHz	China
TN-UHF-...-KOR-CDS	917...920.8 MHz	Korea
TN-UHF-...-BRA-CDS	915...928 MHz	Brazil
TN-UHF-...-RUS-CDS	866...868 MHz	Russia
TN-UHF-...-AUS-CDS	920...926 MHz	Australia

These devices may only be started up under the following conditions:

- The particular frequency range is permissible for the use of UHF-RFID.
- The operating frequency range of the devices is compliant with the permissible UHF RFID range of the region.
- A valid certification and/or approval is available for the region of use.

The integrated RFID interface enables the read/write heads to communicate directly with the PLC or other higher-level systems. Read data is sent to the controller via the device. The device can perform autonomous controller and diagnostics functions in order to reduce the workload of the controller. The functions of devices can be programmed using the IEC 61131-3 compliant CODESYS V3 programming software.

Four configurable digital channels are also provided for connecting digital sensors and actuators. The multiprotocol interfaces can be used as an EtherNet/IP device, Modbus TCP Turck slave, or PROFINET RT device. In Modbus TCP systems the devices can also be used as masters.

The devices may only be used as described in these instructions. Any other use is not in accordance with the intended use. Turck accepts no liability for any resulting damage.

### 3.2 General safety notes

- The device only meets the EMC requirements for industrial areas and is not suitable for use in residential areas.
- The device may only be assembled, installed, operated, parameterized and maintained by professionally-trained personnel.
- The device may only be used in accordance with applicable national and international regulations, standards and laws.
- Any extended stay within the area of radiation of the UHF read/write heads may be harmful to health. Observe minimum distances from the actively radiating surface of the UHF read/write head:

<b>Region</b>	<b>Max. permissible total radiant output power</b>	<b>Safety distance</b>
Europe, Russia, China	2 W ERP (according to ETSI)	> 0.24 m
USA, Canada, Brazil, Korea, Australia, New Zealand	4 W EIRP	> 0.30 m
Singapore	0.5 W ERP	> 0.24 m

- The radiation of the UHF read/write heads may have an adverse effect on the operation of electrically controlled medical equipment. Keep an additional distance from active radiation sources up to the maximum transmission distance.

## 4 Product Description

The devices are designed with an aluminum housing and degree of protection IP67. The active face is made out of plastic. Devices are available with an integrated antenna (Q300) or for connecting external antennas (Q180). Both device variants are suitable for connecting up to four external passive UHF RFID antennas.

The terminals for the Ethernet and for digital I/Os are M12 sockets. The device has an M12 plug connector for connecting the power supply. Terminals are provided for up to four external antennas.

### 4.1 Device overview




Fig. 1: Dimensions – TN-UHF-Q180L300...




Fig. 2: Dimensions – TN-UHF-Q300...

#### 4.1.1 Indication elements

The device has the following LED indicators:

- Power supply
- Group and bus errors
- Status
- Diagnostics

An audible alarm can also be set using software tools.

## 4.2 Properties and features

- Rectangular, height 180 or 300 mm
- Active front face, UV-resistant
- Four terminals for passive UHF RFID antennas
- Four configurable digital channels, which can be configured as PNP inputs and/or 0.5 A outputs
- 2 W (ERP) maximum output power
- Programmable according to IEC 61131-3 with CODESYS V3
- CODESYS V3 PLC Runtime
- CODESYS OPC UA server
- PROFINET device, EtherNet/IP device or Modbus TCP master/slave
- Data interface "U" for convenient use of the RFID functionality
- Close to control integration in PLC systems without the use of a special function block
- Integrated web server
- LED indications and diagnostics

## 4.3 Operating principle

The read/write heads are used for contactless data exchange with tags. For this the controller sends commands and data via the interface to the read/write head and receives the corresponding response data from the read/write head. The reading of the IDs of all RFID tags in the read area or the writing of an RFID tag with a specific production date are examples of typical commands. To communicate with the tag, the data of the read/write head is coded and transferred via an electromagnetic field, which at the same time supplies the tags with power.

A read/write head contains a transmitter and a receiver, an interface to the interface and a coupling element (coil and dipole antenna) for communicating with the tag. Electromagnetic wave propagation is used for the transmission between read/write head and tag on devices for the UHF range.




Fig. 3: Operating principle of UHF-RFID

The antenna of the read/write head generates electromagnetic waves. This produces a transmission window as a so-called air interface in which the data exchange with the tag takes place. The size of the transmission window depends on the combination of read/write heads and tags, as well as on the relevant environmental conditions.

Each read/write head can communicate with a number of tags. This requires the read/write head and the tag to operate in the same frequency range. Depending on the power and frequency used, the device ranges vary from a few millimeters up to several meters. The specified maximum read/write distances only represent typical values under laboratory conditions without allowing for the effect of materials. The achievable distances may vary due to component tolerances, the mounting situation in the application, ambient conditions and the effect of materials (particularly metal and liquids).

## 4.4 Functions and operating modes

The devices operate with an integrated or external antenna (TN-UHF-Q300...) or only with an external antenna (TN-UHF-Q180L300...). The devices enable passive UHF tags to be read or written in single and multitag operation. For this the devices form a transmission zone that varies in size and range according to the tags used and the operating conditions of the application. Refer to the data sheets for the applicable maximum read/write distances. The devices can be fully tested, configured and parameterized from a PC using the specified software tools.

The integrated RFID interfaces transfer data between the RFID level and the controller level. The devices can be used as an EtherNet/IP device, Modbus TCP Turck slave, or PROFINET RT device. The devices can also be used as masters in the Modbus TCP fieldbus system.

The device enables the execution of different commands such as Inventory (single-tag and multitag applications), read, write and password protection. Additional functions are provided for optimizing the speed, the self triggering of the system, as well as for backup and restore operations. In every write or read cycle, up to 128 bytes can be transferred on each channel to the controller. The data must be fragmented in order to transfer more than 128 bytes.

Sensors and actuators can be connected to the configurable digital channels. Up to four 3-wire PNP sensors or two PNP DC actuators with a maximum output current of 0.5 A per output can be connected. The total output current of all devices connected to the DXP channels must not exceed max. 1 A.

The device can perform autonomous controller and diagnostics functions in order to reduce the workload of the controller. The devices can be programmed using the IEC 61131-3 compliant CODESYS 3 programming software.

### 4.4.1 Operating frequency

The Turck UHF system uses nationally specified transmission frequencies for the communication between the tags and read/write heads. These national operating frequencies for UHF are the frequency ranges that are individually specified by the national regulation bodies.

The operating frequency of the devices in the UHF band is for example 865...868 MHz for Europe and 902...928 MHz for the USA. The BL ident read/write heads in the UHF band can therefore only be used in the countries they are intended for and must not be put into operation outside of these regions. As the BL ident UHF tags do not radiate their own radio waves, these are suitable for use worldwide.

Turck offers different tag variants that are specially designed and optimized for national frequency bands in order to achieve as large a communication range as possible. Wide-band multi-range tags for international use are also available as an alternative.

The various Turck read/write heads support the following operating frequencies:

- 865...868 MHz (e.g. for Europe, Turkey and India)
- 866...868 MHz (e.g. for Russia)
- 902...928 MHz (e.g. for USA and Canada)
- 920...925 MHz (e.g. for China and Singapore)
- 902...907.5 MHz and 915...928 MHz (e.g. for Brazil)
- 917...920.8 MHz (e.g. for Korea)

The relevant national specifications for UHF such as frequency range, output and the status of any national regulations can be obtained from the Internet at:  
[http://www.gs1.org/docs/epcglobal/UHF\\_Regulations.pdf](http://www.gs1.org/docs/epcglobal/UHF_Regulations.pdf)

For more detailed information please contact the regulation authorities of the country where you wish to use the UHF RFID system.

HF RFID systems can be run parallel to UHF RFID systems in an installation.

4.4.2 Combination of UHF read/write heads and tags

The UHF read/write heads form a transmission zone for which the size depends on the combination of read/write head and tag. The listed maximum read/write distances only represent typical values under laboratory conditions without the effect of materials. The achievable distances may be different due to component tolerances, mounting location in the application, ambient conditions and the effect of materials (particularly metal).

For this reason, the application must be tested in all cases under real conditions (particularly with read and write operations in motion).

4.4.3 Multiprotocol function

The devices can be used in the following three Ethernet protocols:

- Modbus TCP
- EtherNet/IP
- PROFINET

The Ethernet protocol used must be selected in the CODESYS project.

Manual protocol selection

The protocol must be defined manually in the CODESYS program. After that only read access to the device is allowed with the other protocols. Manual protocol selection thus also provides an additional permanent locking feature.

4.4.4 Data transfer to the PLC

In every write or read cycle, up to 128 bytes can be transferred on each channel. The data must be fragmented in order to transfer more than 128 bytes. The amount of data transferred per read or write cycle can be set as follows for different Ethernet protocols:

<b>PROFINET</b>	<b>EtherNet/IP</b>	<b>Modbus TCP</b>
<ul style="list-style-type: none"> <li>■ 8 bytes</li> <li>■ 16 bytes</li> <li>■ 32 bytes</li> <li>■ 64 bytes</li> <li>■ 128 bytes (default setting)</li> </ul>	<ul style="list-style-type: none"> <li>■ 16 bytes</li> <li>■ 64 bytes</li> <li>■ 128 bytes (default setting)</li> </ul>	<ul style="list-style-type: none"> <li>■ 128 bytes (permanently set)</li> </ul> Adjustable fragment size: <ul style="list-style-type: none"> <li>■ 8 bytes</li> <li>■ 16 bytes</li> <li>■ 32 bytes</li> <li>■ 64 bytes</li> <li>■ 128 bytes (default setting)</li> </ul>

4.4.5 RFID channels – operating modes

Two different data interfaces can be selected for the RFID channels:

- UHF compact: Transfer of up to 128 bytes possible, recommended for single tag applications
- UHF extended: Transfer of more than 128 bytes possible, recommended for multi-tag applications

#### 4.4.6 RFID commands

The device can perform the following commands and functions. A complete description of the commands is provided in the section "Setting".

- Idle
- Inventory
- Read
- Write
- Write and verify
- Continuous mode
- Get data from buffer (Continuous mode)
- UHF continuous presence sensing mode
- End Continuous (presence sensing) mode
- Read/write head identification
- Direct read/write head command
- Set tag password
- Set read/write head password
- Reset read/write head password
- Set tag protection
- Tag info
- Permanently deactivate UHF tags (Kill)
- Restore UHF read/write head settings
- Backup settings of the UHF read/write head
- Query error/status of UHF read/write head
- Reset

#### 4.4.7 Loop counter function

The loop counter function is provided for rapid command processing. The loop counter function only requires two PLC cycles to execute a command repeatedly (flow chart see [► 220]). This increments the loop counter to execute a command repeatedly. At least four PLC cycles are required in conventional command processing. In order to execute a command repeatedly with conventional command processing, a command has to be reset and then set again. The loop counter function is provided for special commands. If the command was successfully executed, the command code is output in the response data.

#### 4.4.8 CODESYS OPC UA server

The device can exchange data with any OPC UA clients via the integrated CODESYS OPC UA server.

The device can be connected via OPC UA to higher-level systems such as MES, ERP or Cloud systems. The data transfer is defined according to the Micro Embedded Device Server protocol of the OPC Foundation for supporting OPC UA in field devices. For this data transfer, the integrated OPC UA server of the interface communicates with the OPC UA client of the higher-level system.

#### 4.4.9 Compatible CODESYS versions

The device is compatible with the following CODESYS versions:

<b>CODESYS programming environment</b>	<b>CODESYS runtime</b>	<b>Firmware version</b>	<b>CODESYS package</b>
3.5.12.10	3.5.11.20	1.0.1.0	1.0.1.0



## 4.5 Technical accessories

Accessories for mounting, connecting and parameterizing can be found in product database or the Accessories List for TBEN (D301367) under [www.turck.com](http://www.turck.com). The accessories are not part of the scope of delivery.

## 5 Installing

The device is provided with a bracket in accordance with VESA 100 × 100 for mounting. The device is provided with four M4 threaded holes spaced 100 mm apart (horizontally and vertically). The maximum length of the screws is 8 mm plus the thickness of the VESA bracket. The devices can be mounted in any position.

- Fasten the device with four M4 screws to a bracket in accordance with VESA 100 × 100.




Fig. 4: Rear view – TN-UHF-Q180...




Fig. 5: Rear view – TN-UHF-Q300...

## 6 Connecting

### 6.1 Connecting devices to Ethernet

The device is provided with a 4-pin M12 female connector for connecting the device to an Ethernet system.




Fig. 6: M12 Ethernet connector

- ▶ Connect the device to Ethernet as per the following pin assignment (max. tightening torque 0.8 Nm).




Fig. 7: Pin assignment of the Ethernet connections



**NOTE**

With PoE transfer the power supply via PoE Mode A with 4-wire cables.

## 6.2 Connecting the power supply

The device is provided with a 5-pin M12 plug connectors for connecting the power supply.




Fig. 8: M12 plug connector for connecting the power supply

- ▶ Connect the device to the power supply as per the following pin assignment (max. tightening torque 0.8 Nm).




Fig. 9: Pin assignment of the power supply terminals

### 6.3 Connecting digital sensors and actuators

The device has two 5-pin M12 plug connectors for connecting digital sensors and actuators.




Fig. 10: M12 plug connectors for connecting digital sensors and actuators



**NOTE**

When operating via PoE (Power over Ethernet) the digital channels cannot be used as outputs.

- ▶ Connect sensors and actuators to the device as per the following pin assignment (max. tightening torque 0.8 Nm).





Fig. 11: Connections for digital sensors and actuators – pin assignment

Fig. 12: Connections for digital sensors and actuators – wiring diagram

## 6.4 Connecting external antennas

The device is provided with four RP-TNC sockets for connecting up to four external antennas. The input impedance is 50  $\Omega$ .




Fig. 13: RP-TNC sockets for connecting external antennas

- ▶ Connect external antennas with an RP-TNC antenna cable to the device (max. tightening torque 0.8 Nm).

## 7 Commissioning

### 7.1 Parameterizing read/write heads with the DTM

The UHF settings of the device can be assigned additional parameters via a DTM.

All the required Turck software components can be downloaded via the Turck Software Manager. The Turck Software Manager is available free of charge from [www.turck.com](http://www.turck.com).



**NOTE**


The parameterization function up to firmware version V2.0.39.3937 is only available in English. All parameters are written in the DTM.

The individual read/write heads are available in different variants. When a connection is made to a connected read/write head, the DTM automatically detects the relevant device and deactivates menu items that are not supported. The connection cannot be established if a different variant than set in the project tree is connected.



**NOTE**

Adjustable parameters are indicated in the DTM with a green arrow. Fixed parameters are indicated by gray arrows.

 Enable antenna

 Radiated power unit

Fig. 14: DTM – example of adjustable and fixed parameters

#### Requirements for extended parameter setting

- PACTware must be installed.
- The DTM for UHF read/write heads must be installed.
- The DTM for the BL20, BL67, BLcompact, FEN20, FXEN, FGEN and TBEN fieldbus I/O system must be installed.

### 7.1.1 Connecting the device with the PC

- ▶ Open PACTware.
- ▶ Right-click **Host PC** in the project tree.
- ▶ Click **Add device**.
- ▶ Add **BL Service Ethernet**.
- ▶ Confirm selection with **OK**.




Fig. 15: Selecting an Ethernet adapter



- ▶ Right-click the Ethernet adapter.
- ▶ Start the **Topology scan**.




Fig. 16: Starting the Topology scan

The connected devices are automatically detected and added to the project tree.




Fig. 17: Project tree

7.1.2 Starting the extended read/write head parameter setting

- ▶ Right-click the device.
- ▶ Start the parameter setting: Choose **Parameterization** or **Online parameterization**. The device must be connected to the PC for the **Online parameterization**.




Fig. 18: Starting the parameterization

### 7.1.3 DTM main menu – overview



Fig. 19: DTM – main menu

The main menu provides the following functions:

Icon	Function	Description
	Show and hide information bar	Shows the information bar for the connected device and DTM version at the top of the screen.
	DTM help	Starts the DTM help.
	Device help	Opens the data sheet of the connected read/write head.
	Expert mode ON/OFF	Opens the drop-down menu to select the access level. The following access levels are available: <ul style="list-style-type: none"> <li>■ Basic (default setting)</li> <li>■ Advanced</li> <li>■ Administrator (password-protected)</li> </ul>
	Display channel wise	Toggles the view between standard display and channel-wise display.
	Load data from database	Loads previously stored parameters from the database (e.g. an existing project).
	Store data in database	Transfers the current read/write head parameters to the database of the current project.
	Read data from device	Reads the set parameters from the device.
	Transmit data to device	Transfers the set parameters to the device.
	Compare displayed values with database	Compares the values displayed in the DTM with the values saved in the database.
	CSV export current values	Exports the current values from the DTM to a CSV file.

The following setup windows can be opened in tabs via the main menu:

- Basic setup
- Antenna
- Antenna configuration
- Communication
- EPC Class1 Gen2
- Post read filter
- Signaling

### 7.1.4 Choosing the access level

Three access levels are available for setting the device parameters. Different parameters can be set depending on the access level.



**NOTE**

Modifications made in the **Administrator** access level can result in serious changes to operation. The **Administrator** access level is therefore only available for Turck service technicians. All relevant settings for the successful parameter setting of an application are available in the **Advanced** access level.

Access level	Description	Initial password
Basic	Basic access for configuration and commissioning	Not required
Advanced	Extended access, e.g. for applications	Not required
Administrator	Administrator access for critical security or wireless settings	Required

The current access level is displayed in the top right screen area of the DTM.



Fig. 20: Display of the access level

### 7.1.5 Setting multiplex operation

In multiplex operation, several antennas can be controlled or switched on in sequence. The example below shows the activation of the antennas in sequence. The multiplex operation can consist of up to 16 sequences and can be used, for example, for gate applications.




Fig. 21: Gate application – schematic representation

#### Configuring multiplex operation – example

- ▶ Choose the **Antenna** tab in the main menu.
- ▶ At **Antenna** → **Antenna multiplexing** → **Number of entries** enter the number of antennas.




Fig. 22: Entering the number of antennas

► Assign antennas with functions (e.g. internal antenna: RHCP, LHCP, external antenna)

The screenshot shows a software interface for antenna configuration. At the top, there is a navigation bar with tabs: 'Basic setup', 'Antenna', 'Antenna configuration', 'Communication', 'EPC Class1 Gen2', 'Post read filter', and 'Signaling'. Below the tabs is a table with columns 'Name' and 'Wert'. The 'Antenna' tab is active, and the 'Antenna multiplexing' section is expanded. Under 'Antenna multiplexing', there are four entries: 'Number of entries' (4), '1st entry' (Antenna RHCP), '2nd entry' (Antenna LHCP), and '3rd entry' (Antenna H). The '3rd entry' is highlighted in yellow, and a dropdown menu is open, showing options: 'Antenna RHCP', 'Antenna LHCP', 'Antenna H', 'Antenna V', 'External Antenna 1', 'External Antenna 2', 'External Antenna 3', and 'External Antenna 4'. The 'External Antenna 1' option is currently selected in the dropdown.

Fig. 23: Example: setting multiplex operation

- ▶ Click **Accept** to save the settings.
- ▶ For all antennas used set at **Antenna configuration** → **Maximal transmit time** the time in which the particular antenna is to remain active and stay switched on.




Fig. 24: Setting the maximum transmit time



### 7.1.6 Setting antenna power

The antenna power of the read/write head can be set for the specific application. The radiated power for the integrated antenna can be entered directly in the DTM. The power must be calculated for external antennas.

The following parameters must be used to calculate the radiated power ( $P_{ERP}$ ):

- $P_{cond}$  Power to be output at the TNC socket of the read/write head
- dB Cable attenuation
- $G_{HW}$  Antenna gain of the external antenna



**NOTE**

Refer to the data sheets of the components used for the cable attenuation and antenna gain.




Fig. 25: Power calculation – relevant variables (schematic representation)

The power can be calculated with the following formula:

$$P_{ERP} = G_{HW} - dB + P_{cond}$$

#### Setting antenna power – Restrictions of radio regulations

Some national regulations restrict the degree of freedom available for creating an RFID system. You as the operator are responsible for ensuring that regulations are observed.

- ETSI
  - Radiated power  $P_{ERP}$ : Max. 33 dBm ERP
- FCC
  - Radiated power  $P_{ERP}$ : Max. 36 dBm EIRP
  - $P_{cond}$ : Max. 30 dBm with antenna gain  $G_{HW} \leq 6$  dbi



**NOTE**

The DTM indicates impermissible configurations with an exclamation mark. A transmission to the device is prevented.

## Calculating radiated power

The effective radiated power (ERP) is the power that is radiated from an antenna into free space. To make it possible to compare the technical properties of different antenna, the power specifications given are always in relation to a reference antenna.

- EIRP = equivalent isotropic radiated power (reference: isotropic antenna)
- ERP = effective radiated power (reference: with the length of  $\lambda/2$ )

The radiated power can be stated in watts or in dBm. The following table shows approximate values as a guide for converting between dBm and mW:

dBm	mW	dBm	mW	dBm	mW	dBm	mW
1	1.25	9	8	17	50	25	316
2	1.6	10	10	18	63	26	400
3	2	11	13	19	80	27	500
4	2.5	12	16	20	100	28	630
5	3	13	20	21	125	29	800
6	4	14	25	22	160	30	1000
7	5	15	32	23	200	...	...
8	6	16	40	24	250	33	2000

The formula for calculating the exact values is:  $\text{dBm} = 10 \times \lg (P/1 \text{ mW})$

## Converting antenna gain

The antenna gain can be specified in the following units:

- dBd     Antenna gain in relation to a dipole
- dBi     Antenna gain in relation to an isotropic radiator (linear)
- dBic    Antenna gain in relation to an isotropic radiator (circular)

The different units can be converted as follows:

- $G_{\text{HW}} = \text{dBd}$
- $G_{\text{HW}} = \text{dBi} - 2.15$
- $G_{\text{HW}} = \text{dBic} - 5.15$

### Setting the power for external antennas via the DTM

When supplied via Power over Ethernet (PoE), the radiated power for the internal antenna is limited to 1 W. With external antennas 1 W of output power is provided at the TNC socket. The power supply type is set automatically via **Antenna configuration** → **Power supply** to the **external power supply** value.

- ▶ Set the radiated power via **Antenna Configuration** → **Radiated power** (here: 33 dBm e.r.p.).




Fig. 26: Setting the radiated power

- ▶ Refer to the data sheet of the cable used for the cable attenuation.
- ▶ Enter the cable attenuation at **Antenna cable attenuation**.




Fig. 27: DTM – entering the cable attenuation

- ▶ Refer to the data sheet of the external antenna for the antenna gain.
- ▶ Set the unit for the antenna gain at **Antenna gain unit** (here: dBd).

The screenshot shows a configuration interface with a top navigation bar containing icons and tabs: 'Basic setup', 'Antenna', 'Antenna configuration', 'Communication', 'EPC Class1 Gen2', 'Post read filter', and 'Signaling'. Below the tabs is a table with columns 'Name' and 'Wert'. The 'Antenna configuration' section is expanded, showing various settings. The 'Antenna gain unit' setting is highlighted in yellow, and its dropdown menu is open, showing options: 'dBd (dipole)', 'dBi (isotropic)', and 'dBic (isotropic circular)'. The 'dBd (dipole)' option is selected.

Name	Wert
Antenna configuration	
General	
Power supply	external power supply
Antenna RHCP (right-handed circular polarization)	
Antenna LHCP (left-handed circular polarization)	
Antenna H (horizontal polarization)	
Antenna V (vertical polarization)	
External Antenna 1	
Enable antenna	<input checked="" type="checkbox"/>
Radiated power unit	dBm e.r.p.
Radiated power	33 dBm e.r.p.
Antenna cable attenuation	4 dB
Antenna gain unit	dBd (dipole)
Antenna gain	dBd (dipole)
Conducted power	dBi (isotropic)
Maximal number of inventory rounds	dBic (isotropic circular)
Prefered channel (fixed frequency and LBT mode)	0
Switch to next antenna if no transponder was read	disabled
Maximal transmit time	65535 ms
Use channel from this configuration	disabled
External Antenna 2	
External Antenna 3	
External Antenna 4	

Fig. 28: Setting the unit for the antenna gain

► Set antenna gain at **Antenna gain** (here: 9.00).

The screenshot shows a software interface for configuring an antenna. The 'Antenna configuration' tab is active, and the 'Antenna gain' parameter is highlighted in yellow. The value is set to 9.00. Other parameters include Power supply (external power supply), Radiated power (33 dBm e.r.p.), and Conducted power (24.00 dBm).

Name	Wert
Antenna configuration	
General	
Power supply	external power supply
Antenna RHCP (right-handed circular polarization)	
Antenna LHCP (left-handed circular polarization)	
Antenna H (horizontal polarization)	
Antenna V (vertical polarization)	
External Antenna 1	
Enable antenna	<input checked="" type="checkbox"/>
Radiated power unit	dBm e.r.p.
Radiated power	33 dBm e.r.p. [v]
Antenna cable attenuation	4 dB [v]
Antenna gain unit	dBd (dipole)
<b>Antenna gain</b>	<b>9.00</b> [v]
Conducted power	24.00 dBm
Maximal number of inventory rounds	65535 [v]
Preferred channel (fixed frequency and LBT mode)	0 [v]
Switch to next antenna if no transponder was read	disabled
Maximal transmit time	65535 ms [v]
Use channel from this configuration	disabled
External Antenna 2	
External Antenna 3	
External Antenna 4	

Fig. 29: Setting antenna gain

The power at the TNC socket ( $P_{cond}$ ) is calculated automatically by the DTM and displayed at **Conducted power**.




Fig. 30: Display of the power at the TNC socket

- ▶ Click **Accept** to save the settings.
- ▶ Set the power for each additional antenna separately.

### 7.1.7 Setting antenna polarization

The antenna polarization can be switched via the DTM. Switching the polarization makes it possible to change null spots caused by interference. The detection rate can be increased by switching the polarization. Polarization switching is suitable for example in single tag applications in particularly metallic environments.

The following graphics schematically illustrate the possibilities of antenna polarization.




Fig. 31: Antenna polarization circular (RHCP)




Fig. 32: Antenna polarization circular (LHCP)




Fig. 33: Antenna polarization linear (vertical)




Fig. 34: Antenna polarization linear (horizontal)



### Switching antenna polarization

Polarization switching is activated in the DTM via the multiplex settings.

- ▶ Set at **Antenna** → **Number of entries** the value 2.
- ▶ Set at **Antenna** → **1st entry** the value **Antenna LHCP**.
- ▶ Set at **Antenna** → **2nd entry** the value **Antenna RHCP**.




Fig. 35: Switching antenna polarization

- ▶ At **Antenna configuration** → **Maximal transmit time** set the time up to the polarization switch or activate the **Switch to next antenna if no transponder was read** option.
- ⇒ If the **Switch to next antenna if no transponder was read** option is enabled, the read/write head automatically switches after an Inventory operation without reading to the next multiplex sequence (**Entry**).




Fig. 36: Switching polarization automatically

### 7.1.8 Switching on presence sensing mode

In order to use the Continuous presence sensing mode command, the Presence sensing mode must be activated in the read/write head. In Presence sensing mode, the read/write heads are automatically switched on as soon as a tag is located in the detection range.

- ▶ Choose **Basic setup** → **General** → **Device mode** and set the **presence sensing mode** option.




Fig. 37: Switching on presence sensing mode

The Advanced access level allows the **Tag data delay time** and **Carrier delay time** parameters to be set individually.

- **Tag data delay time:** Time in which the read/write head searches for a tag. If a tag is found, the field is switched on. In the Basic access level, the parameter is set by default to 100 ms.
- **Carrier delay time:** Time until the read/write head switches off the field after the last read operation. In the Basic access level, the parameter is set by default to 65535 ms.



**NOTE**

Report mode is recommended for the RFID test since the read tag information items appear in the RFID test window and do not have to be polled individually.

### 7.1.9 Transferring the RSSI value – communication

The **Communication** tab is used to set the parameters for the configuration of the deBus messages. All parameters and the settable values are written in the DTM.

Example: switch on RSSI transmission

- ▶ Switch on RSSI transmission: choose **Communication** → **Message data content** → **Transponder RSSI** and select the **enabled** option.
- ⇒ The RSSI value is displayed with the inventory in the read data.




Fig. 38: Switching on RSSI transmission

7.1.10 Setting the air interface parameters – EPC Class 1 Gen 2

The EPC Class1 Gen2 tab is used to set the **EPC Class1 Gen2** parameters for the air interface. The parameters set are used if the read/write head performs an Inventory command. All parameters and the settable values are written in the DTM.

Example: set the tag reset

The tag reset function makes it possible to set how often a tag returns a signal to the read/write head with an Inventory operation. The tag reset function is only useful in single-tag applications.

- ▶ **EPC Class 1 Gen 2** → **Inventory** → **Inventory profile 1: Transponder reset** → enter value (here: 150 ms).




Fig. 39: Setting the tag reset

### 7.1.11 Setting the RSSI filter – Post read filter

The **Post read filter** tab enables parameters to be set in order to filter event messages.

The set filters do not reduce the data traffic on the air interface and are not suitable for multi-tag applications with many tags or high passing speeds. All parameters and the settable values are written in the DTM.

Example: set the RSSI filter

An RSSI filter makes it possible to prevent unwanted read operations. All read operations with an RSSI outside of the set limit values are filtered out and not displayed.

- ▶ At **Post read filter** → **RSSI filter** switch on the RSSI filter.




Fig. 40: Switching on the RSSI filter

- ▶ Set the limit values at **Post read filter** → **RSSI filter** → **Lower threshold**.
- ⇒ Example: all read operations below an RSSI value of -45 dBm are filtered out.




Fig. 41: Example – setting the limit value for RSSI

### 7.1.12 Setting LED indication – Signaling

The **Signaling** tab enables the default settings for the USER LEDs to be edited. All parameters and the settable values are written in the DTM.

## 7.2 Parameterizing read/write heads with the web server



### NOTE

The web server always shows all setting options. Parameterization via the web server is possible for the TN-UHF-Q300-EU-CDS from firmware version >1.0.2.0.

---

The devices can be set and commands sent to the devices via the integrated web server. To open the web server with a PC, the device and the PC must be located in the same IP network.

### 7.2.1 Opening a web server

The web server can be opened via a web browser or via the Turck Service Tool. The procedure for accessing the web server via the Turck Service Tool is described in the section "Setting the IP address".

In the delivery state the device has the IP address 192.168.1.254. To open the web server via a web browser, enter <http://192.168.1.254> in the address bar of the web browser.



7.2.2 Editing settings in the web server

A login is required in order to edit settings via the web server. The default password is "password".



**NOTE**

To ensure greater security, Turck recommends changing the password after the first login.

- ▶ Enter the password in the Login field on the start page of the web server.
- ▶ Click **Login**.




Fig. 42: Web server – login

- Change the password after the first login.




Fig. 43: Web server – changing the password

The start page is displayed with the device information after the login.




Fig. 44: Web server – start page

► Click UHF RFID CONFIG & DEMO to display and set the device parameters.




Fig. 45: Web server – UHF RFID CONFIG & DEMO

- ▶ Click **GO ONLINE** in the login window.




Fig. 46: Web server – GO ONLINE

- ▶ Click **Parameter** in the navigation bar on the left of the screen.




Fig. 47: Web server – Parameter dialog

⇒ All parameters of the device are displayed.



**NOTE**

The parameters are arranged in the web server in the same way as in the UHF DTM. Information on the parameters is provided at [▶ 28]. The access level displayed in the web server corresponds to the Advanced level in the DTM.




Fig. 48: Web server – Parameter arrangement

The following setup windows can be called:

- Basic setup
- Antenna
- Antenna configuration
- Communication
- EPC Class1 Gen2
- Post read filter
- Signaling

▶ Set the parameters: click **Write**.



**NOTE**

While a parameter is set, the ERR LED of the device is lit red and changes automatically to green.

## 7.3 Testing read/write heads with the DTM

The following functions can be executed via the RFID Test in the DTM:

- Displaying read data
- Displaying the protocol of the communication between host or PC and read/write head
- Logging of the interface communication between host or PC and read/write head
- Sending of user-specific deBus commands
- Writing of tags with a user-defined number
- Sending tag-specific commands

Requirements for the RFID test

- PACTware must be installed.
- The DTM for UHF read/write heads must be installed.
- The DTM for the BL20, BL67, BLcompact, FEN20, FXEN, FGEN and TBEN fieldbus I/O system must be installed.
- The connection between the read/write head and the PC must be established.
- A project must have been created in PACTware.

### 7.3.1 Starting the RFID Test

- ▶ Right-click the device in the project tree.
- ▶ In the context menu choose **Additional functions** → **RFID Test**.




Fig. 49: Starting the RFID Test

### 7.3.2 Start window – overview

The **RFID Test** window consists of the following elements:

- Main menu
- Basic test
- Tag actions
- Reader Status
- Logger




Fig. 50: RFID Test – overview of the start window



7.3.3 RFID Test – main menu



Fig. 51: RFID Test – main menu

The main menu provides the following functions:

Icon	Function	Description
	DTM help	Starts the DTM help.
	Trigger start/ON or Trigger stop/OFF	Starts the trigger for command execution (standard view). Ends the trigger for command execution (displayed after clicking the start button).
	Configure message content	Displays the content to be transferred with a read operation. The following can be selected: <ul style="list-style-type: none"> <li>■ Phase</li> <li>■ RSSI</li> <li>■ Socket</li> <li>■ Time</li> </ul>
	Switch mode (report/polling)	Switches between Report mode (automatic read/write) and polling mode (read/write started through an explicit polling command).
	Get read/write head status	Calls the status of the read/write head and provides the information in the <b>Logger</b> window.
	Get read/write head version	Calls the following information from the read/write head and provides the information in the <b>Logger</b> window: <ul style="list-style-type: none"> <li>■ Hardware revision</li> <li>■ Firmware status</li> <li>■ Serial number</li> </ul>
	Reset the read/write head	Offers three ways of resetting the read/write head: <ul style="list-style-type: none"> <li>■ Voltage reset</li> <li>■ Factory reset: Reset to factory settings</li> <li>■ Reset read/write head status</li> </ul> <p>When resetting to factory settings, any modified transfer rate or RS485 address is not changed because the read/write head could not otherwise be addressed any longer.</p>
	Set current window layout as default	Saves the individually set window layout.
	Reset window layout	Resets the window layout.
	HF diagnosis	Opens the window for HF diagnostics.
	Firmware update	Opens the window for the firmware update.

### 7.3.4 RFID Test – Basic test window










Fig. 52: RFID Test – Basic test window

The following functions are available in the **Basic test** window:

Icon	Function	Description
	Polling	Shows the first tag in the polling memory of the device in the tag list. The function is only available in polling mode.
	Poll all	Shows all tags in the polling memory of the device in the tag list. The function is only available in polling mode.
	Clear polled tags from read/write head	Clears the polling memory of the read/write head.
	Group tag list	Combines readings of tags with the same EPC.
	CSV export current values	Saves the tag list in CSV format.
	Clear tag list	Deletes the list of displayed tags.

The queried data is displayed in the tag list. The content of the message can be set via the **Configure message content** function.



**NOTE**

If the polling memory of the read/write head is full, the ERR LED is lit red and indicates an internal error.

### 7.3.5 RFID Test – Tag actions window

The functions in the **Tag actions** window are available if a tag is selected in the tag list of the **Basic test** window.









Fig. 53: RFID Test – Tag actions window

The following functions are available in the **Tag actions** window:

Icon	Function	Description
	Read RFID tag memory	Starts the read operation. The chip type is automatically displayed. One word is always read with the first read operation. The following parameters can be set for other read operations: <ul style="list-style-type: none"> <li>■ Memory bank (TID, EPC/UID, PC, access password or kill password)</li> <li>■ Start word</li> <li>■ Number of words</li> </ul> The read data is displayed in the <b>Data</b> area.
	Write RFID tag memory	Starts the write operation. The chip type is automatically displayed. The following parameters can be set for the write operations: <ul style="list-style-type: none"> <li>■ Memory bank (TID, EPC/UID, PC, access password or kill password)</li> <li>■ Start word</li> <li>■ Number of words</li> </ul> Data to be written is displayed in the <b>Data</b> area.
	Auto-increment	The EPC is incremented automatically by 1.
	Auto-decrement	The EPC is decremented automatically by 1.
	Switch on/off access password	Switches the password for write or read access on or off.


Example: execute tag actions

- ▶ Position tag in detection range of the read/write head.
- ▶ Activate the trigger for the read/write head in the main menu.



Fig. 54: Main menu – activating trigger

- ▶ **Basic test** window: execute polling command in order to display tag in the tag list.
- ▶ **Basic test** window: select tag from the tag list.








The screenshot shows a window titled 'Basic test' with a yellow header bar. Below the header is a toolbar with icons for home, list, refresh, and delete. The main area contains a table with the following data:

IDX	EPC/UID	Time	RSSI	RSSI Min	RSSI Max	Phase	Slot	Reads
1	4242 FB63 AC1F 3841 EC88 0467	08:50:34.695	-40.2	-40.2	-40.2	53	5	1

Fig. 55: Basic test – tag selection

- ▶ **Tag actions** window: To read, select **Memory location**, **Start word** or **Word length** and click the appropriate icon.
- ▶ To write enter values under **Data** and confirm with **OK**

**Tag actions**
⌵ ×






Manufacturer/Model	Impinj Monza R6
Memory location	EPC / UID
Start word	2
Word length	6
<b>Data</b>	

**Status: Tag detected**

Fig. 56: Execute tag action (example: read)

⇒ Successful access is displayed via the status message at the bottom of the window.

**Tag actions** ⌵ ✕

Manufacturer/Model	Impinj Monza R6
Memory location	TID memory
Start word	0
Word length	6
Data	E2801160200065EE1F0A092A

Status: Read successfull

Fig. 57: Example: read successful

### 7.3.6 RFID Test – Logger window

The **Logger** window displays read/write information and error messages. The list can be cleared via the **Delete** button.




Fig. 58: Messages in the Logger window

### 7.3.7 HF diagnosis window

Interference frequencies affecting the respective channels are displayed in the **HF diagnosis** window.




Fig. 59: HF diagnosis window

The following functions can be executed in the **HF diagnosis** window:

Icon	Function	Description
	Start/stop HF diagnosis	Starts or closes the HF diagnosis.
	Clear values	Deletes the displayed values.

## 7.4 Testing read/write heads with the web server

The **Application** function enables the devices to be tested with the web server.

- ▶ Click **UHF RFID CONFIG & DEMO** → **Application**




Fig. 60: Web server – RFID Application

The **RFID Test**, the **UHF Diagnostics** and the **Command builder** are provided in the application area:

- **RFID Test:** If the trigger is set to ON, the RF field is activated and tags can be read.
- **UHF Diagnostics:** The graphs show interference frequencies of all channels used.
- **Command builder:** Use of the Command builder is reserved for Turck Support and is not designed for setting device parameters or device operation.



RFID Test enables EPC information on tags to be displayed and read out in single tag and multitag mode. The received RSSI values are displayed as a curve in relation to time.




Fig. 61: Example of RFID Test: Detection of a tag with received RSSI values over time and the number of read operations

The currently received power level for each channel of the read/write head is displayed in the **UHF Diagnostics** window.




Fig. 62: Example of UHF Diagnostics: Received power level per channel

## 7.5 Querying device information with the DTM

The DTM provides access to hardware and software information as well as regulations on the connected device.

- ▶ Right-click the device in the project tree.
- ▶ Choose **Additional functions** → **Identify**.




Fig. 63: Calling up Identification

⇒ The DTM shows the available information on the device according to the selected access level.

⊖	📄	Device information	
⊖	☰	Hardware	
	🔍	Device type	Q175L200
	🔍	Internal antenna	available
	🔍	RS485 termination on/off switch	available
	🔍	Serial number	212101439
	🔍	Transceiver ASIC	R2000
	🔍	Prefix customer ID	1000001 (hex)
⊖	☰	Software	
	🔍	Firmware version	01.56
⊖	☰	Regulations	
	🔍	Adaptive frequency agility	available
	🔍	Fixed frequency	available
	🔍	Frequency hopping	available
	🔍	Listen before talk	not available
	🔍	Number of available channels	15
⊖	☰	Regulations: Channel mask	
	🔍	Channel mask: Channel 1	-
	🔍	Channel mask: Channel 2	-
	🔍	Channel mask: Channel 3	-
	🔍	Channel mask: Channel 4	enabled
	🔍	Channel mask: Channel 5	-

Fig. 64: Device information for TN865-Q175L200-H1147 in the Advanced access level

## 7.6 Setting the IP address

The IP address can be set via the Turck Service tool or via the web server.

### 7.6.1 Setting the IP address via the Turck Service Tool

The device is factory set to IP address 192.168.1.254 The IP address can be set via the Turck Service Tool. The Turck Service Tool is available free of charge from [www.turck.com](http://www.turck.com).

- ▶ Connect the device to a PC via the Ethernet interface.
- ▶ Launch the Turck Service Tool.
- ▶ Click **Search** or press F5.




Fig. 65: Turck Service Tool – start screen

The Turck Service Tool displays the connected devices.




Fig. 66: Turck Service Tool – found devices

- ▶ Click the required device.
- ▶ Click **Change** or press [F2].




Fig. 67: Turck Service Tool – selecting the device to be addressed



**NOTE**

Clicking the IP address of the device opens the web server.

- ▶ Change the IP address and if necessary the network mask and gateway.
- ▶ Accept the changes by clicking **Set in device**.




Fig. 68: Turck Service Tool – changing the device configuration

7.6.2 Setting the IP address via the web server

- ▶ Open the web server.
- ▶ Log into the device as administrator.
- ▶ Click **Network configuration**.
- ▶ Change the IP address and if necessary also the subnet mask and default gateway.
- ▶ Write the new IP address, subnet mask and default gateway via **Submit** to the device.




Fig. 69: Web server – changing the IP address

## 7.7 Connecting the device to a Modbus master

In this example, the **Continuous mode active** bit has to be set. This requires the network interface to be set up, the hardware configured and the I/O mapping defined.

### Hardware used

This example uses the following hardware components:

- Turck HMI TX707-P3CV01 (Modbus master)
- TN-UHF-Q300-EU-CDS UHF read/write head (IP address: 192.168.1.20)

### Software used

This example uses the following software:

- CODESYS 3.5.12.1 (download free of charge from [www.turck.com](http://www.turck.com))

### Prerequisites

- The programming software has been started.
- A new project has been created.
- The PLC has been added to the project.



### 7.7.1 Connecting the device with the controller

To connect the device to the controller, the following components must be added in CODESYS first of all:

- Ethernet adapter
- Modbus TCP master
- Modbus TCP slave

#### Adding an Ethernet adapter

- ▶ Right-click **Device (TX707-P3CV01)** in the project tree.




Fig. 70: Project tree

- ▶ Select **Append device**.
- ▶ Select an Ethernet adapter.
- ▶ Click **Append device**.
- ⇒ The Ethernet adapter appears as **Ethernet (Ethernet)** in the project tree.




Fig. 71: Adding an Ethernet adapter

### Adding a Modbus master

- ▶ Right-click **Ethernet (Ethernet)** in the project tree.
- ▶ Select **Append device**.
- ▶ Double-click **Modbus TCP Master**.
- ⇒ The Modbus master appears as **Modbus\_TCP\_Master** in the project tree.




Fig. 72: Adding a Modbus master

### Adding a Modbus slave

- ▶ In the project tree right-click **Modbus\_TCP\_Master (Modbus TCP Master)**.
- ▶ Select **Append device**.
- ▶ Double-click **Modbus TCP Slave**.
- ⇒ The Modbus slave appears as **Modbus\_TCP\_Slave** in the project tree.




Fig. 73: Adding a Modbus slave

## 7.7.2 Renaming a Modbus slave

- ▶ Click Modbus slave in the project tree.
- ▶ Press [F2].
- ▶ Adapt the name of the slave in the project tree of the application (here: TN\_UHF\_Q300\_EU\_CDS).




Fig. 74: Renaming a Modbus slave

### 7.7.3 Setting up network interfaces

- ▶ Click **Device** → **Scan network**.
- ▶ Select Modbus master (here: TX707-P3CV01) and confirm with **OK**.




Fig. 75: Setting up a network interface to the Modbus master

- ▶ Select the PLC Settings tab.
- ▶ In the **Always update variables** drop-down menu, select the **Enabled 2 (always in bus cycle task)** option.




Fig. 76: Selecting the option: Always update variables

- ▶ Double-click **Ethernet**.
- ▶ Enter the IP address of the Modbus master (here: 192.168.1.70).




Fig. 77: Modbus master – enter the IP address



- ▶ Double-click the Modbus TCP slave.
- ▶ In the **General** tab enter the IP address of the slave (here: 192.268.1.20).




Fig. 78: Modbus slave – entering the IP address

### 7.7.4 Setting Modbus channels (registers)

Set channel 0 (input data)

- ▶ Double-click the Modbus TCP slave.
- ▶ Select in the **Modbus Slave Channel** tab → **Add channel**.
- ▶ Enter the following values:
  - Name of channel
  - Access type: Read holding registers
  - Offset: 0x0000
  - Length: 64 registers (128 bytes)
- ▶ Confirm with **OK**.




Fig. 79: Setting the READ register

Set channel 1 (output data)

- ▶ Double-click the Modbus TCP slave.
- ▶ Select in the **Modbus Slave Channel** tab → **Add channel**.
- ▶ Enter the following values:
  - Name of channel
  - Access type: Write holding registers
  - Offset: 0x0000
  - Length: 64 registers (128 bytes)
- ▶ Confirm with **OK**.




Fig. 80: Setting the WRITE registers

### 7.7.5 Setting the I/O mapping

To create I/O mapping the local I/Os must be added to the project and connected with the Modbus master.

- ▶ Right-click the name of the project in the project tree.
- ▶ Select **Add device**.
- ▶ Double-click **Q300**.
- ⇒ The local I/Os appear in the project tree.




Fig. 81: Adding local I/Os to the project

### Attaching the Ethernet adapter to the local I/Os

- ▶ Right-click Q300 (Q300) in the project tree.
- ▶ Select **Add device**.
- ▶ Double-click **Ethernet**.




Fig. 82: Attaching the Ethernet adapter to the local I/Os

### Attaching the Modbus TCP slave to the local I/Os

- ▶ Right-click **Ethernet (Ethernet)** in the project tree.
- ▶ Select **Add device**.
- ▶ Double-click **Modbus TCP Slave Device**.




Fig. 83: Attaching the Modbus TCP slave to the local I/Os

- ▶ Define the size of the input and output data for the Modbus slave (here: 64 registers each)




Fig. 84: Defining the size for input and output data

### Local I/Os – setting the Ethernet interface

- ▶ Double-click **Q300 (Q300)** in the project tree.
- ▶ In the **Communication Settings** tab click the **Scan network...** button.
- ▶ Select TN-UHF-Q300-CDS and confirm with **OK**.




Fig. 85: Setting up an Ethernet interface to the read/write head



- ▶ Select the PLC Settings tab.
- ▶ In the **Always update variables** drop-down menu, select the **Enabled 2 (always in bus cycle task)** option.




Fig. 86: Setting the option – Always update variables option

- ▶ Double-click **Q300 [connected] (Q300)**.
- ▶ Enter the IP address of the Modbus slave (here: 192.168.1.100).




Fig. 87: Modbus master – entering the IP address

### 7.7.6 Writing the application to the device

An executable application must be present in the device in order to establish communication between Modbus master and TN-UHF-Q300-CDS.

- ▶ Right-click **Application** in the project tree.
- ▶ Choose **Add Object** → **Task Configuration** in the context menu.




Fig. 88: Adding a task for the application

### Adding a program organization unit (POU)

This example shows a simple program for mapping the **Continuous mode active** bit to the inputs of the Modbus master.

- ▶ Right-click **Application** in the project tree.
- ▶ Choose **Add Object** → **POU** in the context menu.




Fig. 89: Adding a POU

► Add the POU as a program to the application: Click **Add**.




Fig. 90: Adding the POU to the application

- Confirm the adding of the POU in the entry dialog with **OK**.




Fig. 91: Confirming the adding of the POU in the entry dialog

Mapping local I/Os to I/Os of the Modbus master

- ▶ Obtain the address of the **Continuous mode active** input bit from the mapping for the selected operating mode (here: UHF compact).




Fig. 92: Address of the input bit in the local I/Os of the RFID interface – Continuous mode active

- ▶ Obtain the address for the **Continuous mode active output bit** from the mapping for the slave device.




Fig. 93: Address for the output bit



► Transfer the mapping to the POU




Fig. 94: Transferring the mapping to the POU

### 7.7.7 Connecting the device online with the controller

- ▶ Select device.
- ▶ Click **Online** → **Login**.

### 7.7.8 Reading out process data

The process data can be interpreted if the device is connected online with the controller.

- ▶ Double-click the Modbus TCP slave.
- ▶ Click the **Modbus TCP Slave I/O Mapping** tab.
- ⇒ The process data is displayed. In this example the **Continuous mode active** bit is set if the read/write head is in Continuous mode.




Fig. 95: Example: process data

## 7.8 Connecting a device to an EtherNet/IP controller

The device can be linked to an EtherNet/IP controller via an L5K file. Further information on commissioning in EtherNet/IP can be provided by Turck on request.

## 7.9 Connecting a device to a Siemens controller

In this example the **Tag present** bit is queried. This requires the network interface to be set up, the hardware configured and the I/O mapping defined.

### Hardware used

This example uses the following hardware components:

- Siemens S7-1500 controller with CPU 1513-1 PN
- TN-UHF-Q300-CDS-EU UHF read/write head (IP address: 192.168.1.254)

### Software used

This example uses the following software:

- CODESYS 3.5.12.1 (download free of charge from [www.turck.com](http://www.turck.com))
- SIMATIC STEP7 Professional V15 (TIA Portal)
- Generic GSDML file for Turck UHF read/write heads (available as download free of charge from [www.turck.com](http://www.turck.com))

### Requirements

- The package file for TBEN-L...-4RFID-8DXP-CDS must be installed.
- A new standard project must have been created in CODESYS.
- The TN-UHF-Q300-CDS-EU UHF read/write head must have been added to the CODESYS project.
- A new project must have been created in the TIA portal.

7.9.1 Configuring the device in CODESYS as a PROFINET device  
The device must have been created in the project tree.




Fig. 96: TN-UHF-Q300-CDS-EU in the project tree

### Adding an Ethernet adapter

- ▶ Right-click **Device (Q300)** in the project tree.
- ▶ Select **Append device**.
- ▶ Select an Ethernet adapter.
- ▶ Click **Add Device**.




Fig. 97: Adding an Ethernet adapter

### Attaching a PROFINET device

- ▶ Right-click **Ethernet (Ethernet)** in the project tree.
- ▶ Select **Append device**.
- ▶ Select **Profinet Device**.
- ▶ Click **Add Device**.




Fig. 98: Attaching the PROFINET device

### Assigning inputs and outputs

- ▶ Right-click **Profinet\_Device (Profinet Device)** in the project tree.
- ▶ Select **Append device**.
- ▶ Example: double-click **IN 1 BYTE**.
- ▶ Example: double-click **OUT 1 BYTE**.
- ▶ Click **Add Device**.



### NOTE

The slots defined as inputs in CODESYS correspond to the outputs in the TIA Portal and vice versa.




Fig. 99: Assigning inputs and outputs

Inputs and outputs – creating the mapping

Example: The **Continuous mode active** bit is sent to the controller via an output byte.

- ▶ Double-click the required operating mode in the project tree (here: HF compact).
- ▶ Select the **UHF compact I/O Mapping** tab.
- ▶ Find the internal device address of the **Continuous mode active** bit from the I/O image for the selected operating mode (here: UHF compact).




Fig. 100: Bit: Tag present – internal address



- ▶ Example: double-click **OUT\_1\_BYTE** in the project tree.
- ▶ Assign the internal address for the **Continuous mode active** bit to the output byte.




Fig. 101: Mapping the I/O address

### 7.9.2 Setting up the network interface

- ▶ Click **Device (Q300)** → **Scan network**.
- ▶ Select **TN-UHF-Q300-EU-CDS** and confirm with **OK**.




Fig. 102: Setting up the network interface

- ▶ Select the **PLC Settings** tab.
- ▶ In the **Always update variables** drop-down menu, select the **Enabled 2 (always in bus cycle task)** option.




Fig. 103: Setting the option – Always update variables option

- ▶ Double-click **Ethernet (Ethernet)**.
- ▶ Select the network interface.
- ▶ Enter the IP address of the PROFINET master (here: 192.168.0.254).




Fig. 104: PROFINET master – entering the IP address

Connecting the device online

- ▶ Click **Online** → **Login**.
- ▶ Click the **Start** button.
- ⇒ The connection is now displayed in the project tree.




Fig. 105: Display of the connection in CODESYS

### 7.9.3 Connecting a device to a Siemens controller in the TIA Portal

- ▶ Add a controller to the project (here: CPU 1513-1 PN).




Fig. 106: Adding a controller

- ▶ Include the Turck Codesys device in the project. To do this, select the generic GSDML file CDS3 PN Device from the Turck folder.




Fig. 107: Adding the Turck Codesys device

TN-UHF-Q...-CDS... – assigning IP address and PROFINET device name

- ▶ Assign IP address and PROFINET device name for the UHF read/write head if necessary via the Turck Service Tool.
- ▶ Enter IP address and PROFINET device name in the TIA Portal (**Device configuration** → **Properties** → **General** → **Ethernet addresses**).




Fig. 108: Setting the IP address and PROFINET device name in the TIA Portal



Assigning inputs and outputs



**NOTE**

The slots defined as inputs in CODESYS correspond to the outputs in the TIA Portal and vice versa.

- ▶ Example: assign IN 1 Byte and OUT 1 Byte from the Hardware catalog to the device.




Fig. 109: Assigning the inputs and outputs in the TIA Portal

### Creating the monitoring table

The process data (here: the set **Continuous mode active** bit) can be visualized via monitoring tables.

- ▶ Creating a new monitoring table.

### Loading the configuration in the controller

- ▶ Load the configuration in the controller.




Fig. 110: Loading the configuration in the controller

### 7.9.4 Reading out process data

In online mode, the **CONTINUOUS\_MODE\_ACTIVE** bit is displayed in the monitoring table.

	Name	Address	Display format	Monitor value	Modify value	Comment	Tag comm...
1	*CONTINUOUS_MODE_ACTIVE*	%I1.1	Bool	<input type="checkbox"/>	<input type="checkbox"/>		
2	<Add new>						

Fig. 111: Bit in the monitoring table – CONTINUOUS\_MODE\_ACTIVE

The successful connection is now displayed in the project tree in CODESYS.

Variable	Mapping	Channel	Address	Type	Current Value
Out8		Out8	%QB566	USINT	1
Bit0		Bit0	%QX566.0	BOOL	TRUE
Bit1		Bit1	%QX566.1	BOOL	FALSE
Bit2		Bit2	%QX566.2	BOOL	FALSE
Bit3		Bit3	%QX566.3	BOOL	FALSE
Bit4		Bit4	%QX566.4	BOOL	FALSE
Bit5		Bit5	%QX566.5	BOOL	FALSE
Bit6		Bit6	%QX566.6	BOOL	FALSE
Bit7		Bit7	%QX566.7	BOOL	FALSE

Fig. 112: Successfully established connection – display in CODESYS

## 7.10 Starting the device as the Modbus master

In this example the **Tag present** bit is queried. This requires the network interface to be set up, the hardware configured and the I/O mapping defined.

### Hardware used

This example uses the following hardware components:

- TN-UHF-Q300-CDS-EU UHF read/write head (IP address 192.168.1.20)
- TBEN-S2-2RFID-4DXP block module (IP address 192.168.1.100)
- TN-Q80-H1147 HF read/write head

### Software used

This example uses the following software:

- CODESYS 3.5.12.10 (download free of charge from [www.turck.com](http://www.turck.com))

### Requirements

- The package file for TN-UHF-Q300-CDS is installed.
- A new standard project has been created.

### Defining the device as master in CODESYS

- ▶ Select TN-UHF-Q300-CDS-EU UHF read/write head (**Q300**) as master device.




Fig. 113: Selecting the master device

This displays the device in the project tree.




Fig. 114: TN-UHF-Q300-CDS-EU in the project tree

### Adding an Ethernet adapter

- ▶ Right-click **Device (Q300)** in the project tree.
- ▶ Select **Append device**.
- ▶ Select an Ethernet adapter.
- ▶ Click **Add Device**.




Fig. 115: Adding an Ethernet adapter

### Adding a Modbus master

- ▶ Right-click **Ethernet (Ethernet)** in the project tree.
- ▶ Select **Append device**.
- ▶ Double-click **Modbus TCP Master**.
- ⇒ The device appears as **Modbus\_TCP\_Master** in the project tree.
- ⇒ Modbus slaves can be connected to the Modbus master.




Fig. 116: Adding a Modbus master

### Adding a Modbus slave

- ▶ Right-click **Modbus\_TCP\_Master** in the project tree.
- ▶ Select **Append device**.
- ▶ Double-click **Modbus TCP Slave**.
- ⇒ The device appears as **Modbus\_TCP\_Slave** in the project tree.




Fig. 117: Adding a Modbus slave



### 7.10.1 Setting up the network interface

- ▶ Double-click **Device (Q300)** in the project tree.
- ▶ Choose the **Communication Settings** tab.
- ▶ Click **Scan network**.
- ▶ Select **TN-UHF-Q300-CDS-EU** and confirm with **OK** or a double-click.




Fig. 118: Adding the network interface

- ▶ Select the **PLC Settings** tab.
- ▶ In the **Always update variables** drop-down menu, select the **Enabled 2 (always in bus cycle task)** option.




Fig. 119: Selecting an option – Always update variables option

- ▶ Double-click **Ethernet (Ethernet)** in the project tree.
- ▶ Enter the IP address of the Modbus master (here: 192.168.1.20).




Fig. 120: Modbus master – enter the IP address

- ▶ Double-click **Modbus\_TCP\_Slave** in the project tree.
- ▶ Enter the IP address of the Modbus slave (here: 192.168.1.100).




Fig. 121: Modbus slave – entering the IP address

## 7.10.2 Setting Modbus channels (registers)

Set channel 0 (input data)

- ▶ Double-click **Modbus TCP Slave**.
- ▶ Select in the **Modbus slave channel** tab → **Add channel**.
- ▶ Enter the following values:
  - Name of channel
  - Access type: Read input registers
  - Offset: 0x0000
  - Length: 64 registers (128 bytes)
- ▶ Confirm with **OK**.




Fig. 122: Setting the READ register

Set channel 1 (output data)

- ▶ Double-click **Modbus TCP Slave**.
- ▶ Select in the **Modbus slave channel** tab → **Add channel**.
- ▶ Enter the following values:
  - Name of channel
  - Access type: Write multiple registers
  - Offset: 0x0000
  - Length: 64 registers (128 bytes)
- ▶ Confirm with **OK**.




Fig. 123: Setting the WRITE registers

7.10.3 Connecting Modbus master and Modbus slave online

- ▶ Select the slave device.
- ▶ Click **Online** → **Login**.

7.10.4 Reading out process data

The I/O image of the slave can be viewed in Online mode.

- ▶ Double-click the Modbus TCP slave.
- ▶ Click the **Modbus TCP Slave I/O Mapping** tab.
- ⇒ The process data is displayed. In this example, the “Tag present” bit is set if a tag is present in the detection range of the read/write head connected to channel 1.




Fig. 124: Example: process data

Refer to the operating instructions of the connected slave for the mapping the channels (see figure below).

Description	Register		Bit offset	Bit length
	Channel 1	Channel 2		
Response code	0x0000	0x004C	0	14
Error	0x0000	0x004C	14	1
Busy	0x0000	0x004C	15	1
Tag within the detection range	0x0002	0x004E	0	1
Loop counter	0x0001	0x004D	0	8
Read/write head detuned	0x0002	0x004E	4	1
Parameter not supported by read/write	0x0003	0x004F	0	1

Fig. 125: Example: extract from the Modbus TCP mapping for the connected TBEN-S2-2RFID-4DXP slave device

## 7.11 Linking the device to the Turck Cloud

To transfer data to the Turck Cloud, the device must be integrated in an Ethernet network with internet access. The cloud can be accessed via any internet router. Port 443 (SSL) must be enabled for connection with the Turck cloud in the internet router.



### NOTE

The integration of the TN-UHF-Q300-EU-CDS requires CODESYS version V3.5 SP14.

### Application example

- TN-UHF-Q300-EU-CDS (firmware version  $\geq$  V1.0.2.0)
- IP address: As the device only has one Ethernet port, programming in CODESYS and the display of the device in the cloud are not possible at the same time. Turck recommends connecting all devices to the same DHCP server, e.g. to a router or in the same network.

The screenshot shows the web server interface for the TN-UHF-Q300-EU-CDS device. The interface is divided into a left sidebar and a main content area. The sidebar contains navigation options: Info, Parameter, Diagnosis, Status, Event log, Ex- / Import, Change Password, LOCAL I/O, Parameter, Diagnosis, Input, and Output. The main content area is titled 'TN-UHF-Q300-EU-CDS - Gateway - Parameter' and features a 'Write' button and a 'Channel view' toggle. The configuration is organized into several sections:

- Date and time Settings:**
  - Current time (UTC): 07.04.2020 08:18:34
  - Set time from host: SET TIME FROM HOST (with a help icon)
  - Timezone: UTC (with a help icon)
- Timer server:**
  - SNTP enable: yes (with a help icon)
  - NTP server address: pool.ntp.org (with a help icon)
- Network:**
  - Global:**
    - SNMP Public Community: public
    - SNMP Private Community: private
    - MAC address: 00:07:46:85:45:e9
  - PROFINET configuration:**
    - Device name: uhfq300 (with a help icon)
- Ethernet port 1:**
  - Addressing mode: PGM-DHCP (with a help icon)
  - Connection mode: Autonegotiation (with a help icon)
  - IP address: 192.168.178.50
  - Netmask: 255.255.255.0
  - Default gateway: 192.168.178.1
  - Set network configuration: SET NETWORK CONFIGURATION (with a help icon)

Fig. 126: Web server – ethernet port settings



## DNS server

A DNS must be accessible for internet access. The DNS server can be configured automatically via DHCP or manually.

MAIN    UHF RFID CONFIG & DEMO    DOCUMENTATION    CLOUD

---

**TN-UHF-Q300-EU-CDS**

- Info
- Parameter
- Diagnosis
- Status
- Event log
- Ex- / Import
- Change Password

---

**LOCAL I/O**

- Parameter
- Diagnosis
- Input
- Output

**TN-UHF-Q300-EU-CDS - Gateway - Parameter**

Write
Channel view

---

	<b>Global</b>		
Device	SNMP Public Community	<input type="text" value="public"/>	
	SNMP Private Community	<input type="text" value="private"/>	
Date and time	MAC address	<input type="text" value="c8.df.84.aa.e2.cd"/>	
<b>Network</b>	DNS-Mode	<input type="text" value="Automatic"/> ?	
	DNS Domain	<input type="text"/>	
	DNS Name Server 1	<input type="text" value="0.0.0.0"/>	
	DNS Name Server 2	<input type="text" value="0.0.0.0"/>	
	DNS Name Server 3	<input type="text" value="0.0.0.0"/>	
	<b>PROFINET configuration</b>		
	Device name	<input type="text"/>	?
	<b>Ethernet port 1</b>		
	Addressing mode	<input type="text" value="PGM-DHCP"/>	?
	Connection mode	<input type="text" value="Autonegotiation"/>	?
	IP address	<input type="text" value="192.168.145.35"/>	
	Netmask	<input type="text" value="255.255.255.0"/>	
	Default gateway	<input type="text" value="192.168.145.1"/>	
	Set network configuration	<input type="button" value="SET NETWORK CONFIGURATION"/>	?

Fig. 127: Web server – setting up a DNS server

### 7.11.1 Register or login user and project in the cloud

To use the device (TN-UHF-...-CDS) in the Turck Cloud as a cloud gateway, a cloud user account must exist with a cloud project. The device (device type) can be (TN-UHF-...-CDS) as a cloud gateway.

- ▶ No customer account present:  
Create a new customer account via **Register** in the Turck Cloud [www.turck.cloud](http://www.turck.cloud).
- ▶ Customer account present:  
Request user data from the cloud administrator. Newly created users receive a confirmation email.
- ▶ Follow the link to the new user account in the email and assign a user password.

7.11.2 Creating a Cloud project

- ▶ Create a project via **ADMINISTRATE** → **PROJECTS** → **Create a project**.
- ▶ Assign a project via **Project** and select a service user.
- ▶ Complete the entry via **CHECK INPUT**.




Fig. 128: Creating a cloud project

The costs of the creation of a new project are shown in the next step of the **Create a project** operation.

- ▶ Click **ORDER AND ACTIVATE WITH COSTS** and create the project.




Fig. 129: Turck Cloud – paying to order and activating the project

The screenshot shows the Turck Cloud web interface. At the top right is the TURCK logo. Below it is a navigation bar with the following items: MANAGE (with a hamburger menu icon), GATEWAYS, SURFACE, PROJECTS, BILLING, USER, and EXPORT. To the right of the navigation bar are icons for home, globe, monitor, and user profile. The main content area has a yellow background. On the left is a sidebar with a 'HIDE SIDEBAR' button, a search bar labeled 'SEARCH...', a 'Create a project' button with a plus icon, and a list of projects including 'Project1' with a right arrow icon. The main content area displays a 'Project1' details card with the following information:

Project1	
Name	Project1
Project address	<a href="https://project1.turck.cloud">https://project1.turck.cloud</a>
Service user	Author (Documentation, Author)
Maximum limit for history storage	365 Days

At the bottom of the page, the footer contains the text: © 2019 | Hans Turck GmbH & Co. KG and Legal notice | Terms of Use | Privacy statement.

Fig. 130: Turck Cloud – project created, link to project URL

- ⇒ The entered service user receives an email as a purchase and vendor order confirmation. The email also contains a link to the project URL.

### 7.11.3 Activate a device as Cloud gateway in Turck Cloud Portal

Gateways can only be added to projects for which the user has appropriate rights. The manual for the Turck Cloud contains further information on user rights.

- ▶ Open the project URL and login to the project.
- ▶ Add the gateway to a project via **ADMINISTRATION** → **GATEWAYS** → **Activate Gateway**.




Fig. 131: Turck Cloud – activate gateway

- ▶ **Activate gateway:** Select the device (TN-UHF-...-CDS) as gateway and enter the MAC address of the device.
- ▶ Assign a **scope** (gateway name in the cloud user interface), a gateway user name under **User** and a password under **Password**.
- ▶ Complete the entry via **CHECK INPUT**.



**NOTE**

The gateway user name should be unique and only used once in the project. It is not associated with the user name.

Fig. 132: Turck Cloud Portal – activating TN-UHF-...-CDS as a cloud gateway (step 1)

The costs arising when a new gateway is activated are displayed in the next step of the **Activate gateway** operation.

- ▶ Click **ORDER AND ACTIVATE WITH COSTS** and create a gateway.




Fig. 133: Turck Cloud Portal – ordering and paying to activate the gateway

- ⇒ The person responsible for the project receives an email as a purchase and vendor order confirmation. The email also contains a link to the project URL.



7.11.4 Configuring the Cloud access in the web server

Enter Cloud access data (credentials)

In the web server, the access data for the Turck Cloud are entered under **CLOUD** → **Credentials**.

- ▶ Activate the portal access via **Turck Cloud Portal** → **Enable**
- ▶ Enter the Turck Cloud access data. The access data are displayed in the cloud under **Manage** → **Gateways** at the (TN-UHF-...-CDS) entry.
- ▶ If necessary, configure a proxy server.
- ▶ Write the changes into the device (TN-UHF-...-CDS) via **WRITE**.




Fig. 134: Web server – entering access data from Turck Cloud in the web server

- ▶ Restart the device.
- ⇒ The cloud connection status (Status) shows that the device is connected to the cloud.




Fig. 135: Webserver – cloud connection established (Status)

### 7.11.5 Transfer process data from CODESYS to the cloud

The process data of the device (TN-UHF-...-CDS) from a CODESYS project is transferred via a symbol configuration in the CODESYS project to the Turck Cloud.

- ▶ Add the symbol configuration in the CODESYS project via **Application** → **Append object** → **Symbol configuration** to the project. The symbol configuration contains all the variables used in the project.
- ▶ Select the variables to be displayed in the web server and in the cloud, and define in the **Access rights** column whether the variables in the cloud are to be only read, written or read and written. Only read access is possible in the web server in the area **CLOUD** → **Portal** → **Nodes** (see Cleaning nodes [▶ 140]).




Fig. 136: Symbol configuration



**NOTE**

If access rights were assigned in CODESYS, the appropriate access data must be entered in the web server (see [▶ 140]).

### 7.11.6 Manage data node points from CODESYS symbol table

#### Options for CODESYS Symbols in the Web Server (Node Options)

##### CODESYS symbols

In CODESYS it is possible to restrict user rights for projects and to link them to individual users.

- ▶ Enter access data for the CODESYS project, from which symbols are to be displayed in the web server, under **CODESYS Symbols**. If no access rights have been assigned in the CODESYS project, no data must be entered here.

##### Settings - Automatic Node delete

Activated

Deactivating CODESYS symbols in the symbol configuration automatically deletes the corresponding data nodes in the Turck Cloud Portal and on the web server interface. Historical data can no longer be displayed.

Deactivated

Data nodes in the Turck Cloud Portal and on the web server interface are not automatically deleted. Historical data is still displayed. You can only delete data manually in the web server (see **Clean Data Nodes (Nodes)**).




Fig. 137: Webservice – Cloud – Node Options

### Clean Data Nodes (Nodes)

This dialog shows the data nodes of the device imported from the CODESYS symbol configuration [▶ 139].

The data node points can be deleted manually here if **Node Options** → **Settings – Automatic Node delete** is deactivated.




Fig. 138: Webserver – Cloud – Clean data nodes (Nodes)

- ▶ Select data nodes to be deleted.
- ▶ Delete marked data nodes via the **Delete** button
- ⇒ The data nodes including the historical data are also deleted in the Turck Cloud Portal.

## 7.12 Setting up a CODESYS OPC UA server

The following example shows the transfer of the **Tag present**, **Read UID** functions and a counter program to an OPC UA client. For this the symbol configuration must be set up in CODESYS.

### Hardware used

- TN-UHF-...-CDS read/write head

### Software used

This example uses the following software:

- CODESYS 3.5.12 (available as a free download at [www.turck.com](http://www.turck.com))
- UA Expert

### Prerequisites

- The programming software has been started.
- A new project has been created.
- The PLC has been added to the project.

Example: setting up a CODESYS OPC UA server

- ▶ Add the symbol configuration in CODESYS.
- ▶ Activate OPC UA features.




Fig. 139: CODESYS – adding OPC UA features

- ▶ Optional: Activate OPC UA features in the settings at a later time.




Fig. 140: CODESYS – activating OPC UA features at a later time

- ▶ Select the functions in the symbol configuration that are to be transferred to the OPC UA client (in this case: **test\_counter**, **TagPresent** and **UID**).




Fig. 141: CODESYS – symbol configuration



- ▶ Write data to the device.
- ▶ Open the OPC UA client (example: UA Expert).
- ▶ Establish the connection between the OPC UA server and OPC UA client.




Fig. 142: UA Expert: establishing a connection

The data is displayed in the OPC UA client.

The screenshot displays the UA Expert software interface. On the left, the 'Project' tree shows a server named 'OPCUAServer@192.168.1.10\_TBEN\_CDS'. The 'Address Space' tree on the left shows a hierarchical structure: Root > Objects > DeviceSet > TBEN-L5-4RFID-8DXP-CDS > Resources > Application > GlobalVars > RFID\_data > TagPresent > UID > test\_counter. The 'Data Access View' table on the right shows the following data:

#	Server	Node Id	Display Name	Value	Datatype	Source Timestamp	Server Timestamp	Statuscode
1	OPCUAServer@192.168.1.10_TBEN_CDS	NS4\$String[vari...	TagPresent	false	Boolean	21:46:09.514	21:46:09.514	Good
2	OPCUAServer@192.168.1.10_TBEN_CDS	NS4\$String[vari...	UID	(224,8,1,72,96,49,75,198)	Byte	21:46:15.016	21:46:15.016	Good
3	OPCUAServer@192.168.1.10_TBEN_CDS	NS4\$String[vari...	test_counter	96	Byte	21:47:01.962	21:47:01.962	Good

Fig. 143: UA Expert – data in the OPC UA client

## 8 Setting

### 8.1 RFID channels – parameter data

Byte no.	Bit							
	7	6	5	4	3	2	1	0
0	Operating mode (Mode)							
1	Reserved							
2	Reserved							
3								
4								
5	DDI							
6	Reserved							
7	Reserved							
8	Command repetitions (CRET)							
9	Reserved							
10	Reserved							
11								
12	Reserved							
13								
14								
15								
16	Reserved							
17	...							
18								
19								
20								
21								
22								
23								
24								
25								
26								
27	Reserved							
28	Reserved							
29	Reserved							
30	Reserved							
31	Reserved							
32	Length of write data (WDS)							
33								
34	Length of read data (RDS)							
35								

### 8.1.1 Meaning of the parameter bits

The default values of the firmware, the DTM and the EDS file are shown in **bold type**. The default values for PROFINET may differ.

Designation	Meaning
Operating mode (OMRFID)	0: Deactivated <b>1: UHF compact</b> 2: UHF extended
Diagnostic input filter (DID)	<b>0: All diagnostic messages on</b> 1: Diagnostic messages off
Command repetitions in the event of an error (CRET)	Number of command repetitions after an error message, default setting: 2
Length of write data (WDS)	Size of the write data, default setting depends on the selected interface and fieldbus
Length of read data (RDS)	Size of the read data, default setting depends on the selected interface and fieldbus

### 8.1.2 Setting Continuous presence sensing mode

- ▶ Set adaptations to the Presence sensing behavior in the DTM.
- ▶ Optional: Set the grouping of the EPCs via the **Start address** parameter:  
0: Grouping inactive  
1: Grouping active (same EPC is not recorded again, only the counter incremented in the header)
- ▶ Execute the **Continuous presence sensing mode** command.
- ⇒ The read/write head is switched to Presence sensing mode and sends all received data to the interface as soon as at least one tag is located in the detection range.
- ⇒ The data received from the read/write head is stored in the FIFO memory of the interface.
- ▶ Send the **Idle** command (0x0000) in order to then read data from the buffer of the interface.



#### NOTE

The **Continuous presence sensing mode** command also stays active after the **Idle** command is sent.

- ▶ To pass on data from the FIFO memory of the interface to the controller, execute the **Get data from buffer** (0x0011) command. The length of the data must be less than or equal to the value of the available data bytes (BYFI). Depending on the length of the data, it is no longer used for grouping.



#### NOTE

If Grouping is active: Only read data from the buffer if the number of available bytes is stable. If stable data was fetched, the command can be terminated by means of a reset since the grouping is no longer based on the fetched data and therefore old EPCs can be detected again.

- ▶ Do not carry out the reset until the data has been successfully read from the buffer.
- ▶ To end Continuous presence sensing mode and clear the FIFO memory of the interface send the **Reset** command (0x0800).

### 8.1.3 Transferring the read/write head settings

The Backup function enables the settings of a UHF read/write head to be transferred, e.g. when swapping a device.

- ▶ Execute the **Backup settings of the UHF read/write head** command.
- ⇒ The settings for the read/write head are saved in the interface.
- ▶ Replace the read/write head.
- ▶ Execute the **Restore UHF read/write head settings** command.
- ⇒ The data stored in the interface is transferred to the read/write head.

## 8.2 RFID channels – process input data

## Process input data – UHF compact mode

Byte no.		Bit							
PROFINET	Modbus EtherNet/ IP	7	6	5	4	3	2	1	0
0	0	Response code (RESCUHF)							
1	1								
2	2	Loop counter for rapid processing (RCNT)							
3	3	Reserved							
4	4		TRE1	PNS1					TP1
5	5							CMON	
6	6	Length (LEN)							
7	7								
8	8	Error code (ERRC)							
9	9								
10	10	Tag counter (TCNT)							
11	11								
12	16	Reserved							
13	17	Reserved							
14	18	Reserved							
15	19	Reserved							
16	20	Reserved							
17	21	Reserved							
18	22	Reserved							
19	23	Reserved							
20	24	Read data Byte 0							
...	...	...							
147	151	Read data Byte 127							

Process input data – UHF extended mode

Byte no.		Bit							
PROFINET	Modbus EtherNet/ IP	7	6	5	4	3	2	1	0
0	0	Response code (RESCUHF)							
1	1								
2	2	Loop counter for rapid processing (RCNT)							
3	3	Reserved							
4	4		TRE1	PNS1					TP1
5	5							CMON	
6	6	Length (LEN)							
7	7								
8	8	Error code (ERRC)							
9	9								
10	10	Tag counter (TCNT)							
11	11								
12	12	Data (bytes) available (BYFI)							
13	13								
14	14	Read fragment no.							
15	15	Write fragment no.							
16	16	Reserved							
17	17	Reserved							
18	18	Reserved							
19	19	Reserved							
20	20	Reserved							
21	21	Reserved							
22	22	Reserved							
23	23	Reserved							
24	24	Read data Byte 0							
25	25	Read data Byte 1							
26	26	Read data Byte 2							
27	27	Read data Byte 3							
28	28	Read data Byte 4							
29	29	Read data Byte 5							
30	30	Read data Byte 6							
31	31	Read data Byte 7							
...	...	...							
151	151	Read data Byte 127							

## 8.2.1 Meaning of the status bits

Default values are shown in **bold type**.

Designation	Meaning
Response code (RESC)	Display of the last command executed
Loop counter for rapid processing (RCNT)	Output of the command code requested by the loop counter
Read/write head reports error (TRE1)	<b>0: No error</b> 1: Error message of the read/write head
Parameter not supported by read/write head (PNS1)	<b>0: No error</b> 1: Parameter not supported by read/write head
Tag within the detection range (TP1)	<b>0: No tag in detection range of read/write head</b> 1: Tag in detection range of read/write head
Continuous presence sensing mode active (CMON)	<b>0: Continuous presence sensing mode not active</b> 1: Continuous presence sensing mode active
Length (LEN)	Display of the length of the read data
Error code (ERRC)	Display of the specific error code if the error bit (ERROR) is set.
Tag counter (TCNT)	Display of the detected tags read with an Inventory command. The tag counter is reset by the following commands: <ul style="list-style-type: none"> <li>■ Inventory</li> <li>■ Continuous presence sensing mode</li> <li>■ Reset</li> </ul>
Data (bytes) available (BYFI) (only available with UHF extended)	Shows the number of bytes in the FIFO memory of the interface. Ascending: New data from a tag read or received by the device Descending: Execution of a command completed Error message 0xFFFF: Memory overfilled, data loss of new data likely
Read fragment no. (RFN) (only available with UHF extended)	If the data to be read exceeds the size of the read data memory, the data is divided in max. 256 fragments. The fragments are numbered consecutively from 1...255. From fragment number 256 numbering starts again at 1. The sending of a fragment is confirmed by the device if the read fragment number appears in the process input data. After the confirmation the next fragment is read. 0: No fragmentation In Idle mode the size of fragments is stated. With a read command the number of fragments containing data is stated.
Write fragment no. (WFN) (only available with UHF extended)	If the data to be written exceeds the size of the write data memory, the data is divided in max. 256 fragments. The fragments are numbered consecutively from 1...255. From fragment number 256 numbering starts again at 1. The sending of a fragment is confirmed by the device if the write fragment number appears in the process input data. After the confirmation the next fragment is written. 0: No fragmentation In Idle mode the size of fragments is stated. With a write command the number of fragments containing data is stated.
Read data	User-defined read data



## 8.2.2 Tag in detection range (TP) – using bit or pre-loading the command

The **Tag in detection range** bit is set automatically if a read/write head detects a tag.

To set the bit in Idle mode, the read/write head must be set to Presence sensing mode via the DTM.

All commands can be sent irrespective of whether the **Tag in detection range** bit (TP) is set. If no tag is present in the detection range when the command is sent, the command is executed by a rising edge at TP. A command is executed immediately if there is a tag in the detection range at the time of sending.



### NOTE

If the read/write head detects a new tag in the detection range, the **Tag in detection range** bit and the UID are indicated at the same time in Idle mode. If two tags are detected in quick succession, the TP bit may remain set. The UID of the second tag is displayed.

---

## 8.3 RFID channels – process output data

## Process output data – UHF compact mode

Byte no.		Bit							
PROFINET	Modbus EtherNet/ IP	7	6	5	4	3	2	1	0
0	0	Command code (CMD C)							
1	1								
2	2	Loop counter for rapid processing (RCNT)							
3	3	Memory area (DOM)							
4	4	Start address (ADDR)							
5	5								
6	6								
7	7								
8	8	Length (LEN)							
9	9								
10	10	Length of EPC (SOUID)							
11	11	Reserved							
12	24	Write data Byte 0							
13	25	Write data Byte 1							
14	26	Write data Byte 2							
15	27	Write data Byte 3							
16	28	Write data Byte 4							
17	29	Write data Byte 5							
18	30	Write data Byte 6							
19	31	Write data Byte 7							
...	...	...							
131	151	Write data Byte 127							

Process output data – UHF extended mode

Byte no.		Bit							
PROFINET	Modbus EtherNet/ IP	7	6	5	4	3	2	1	0
0	0	Command code (CMDCUHF)							
1	1								
2	2	Loop counter for rapid processing (RCNT)							
3	3	Memory area (DOM)							
4	4	Start address (ADDR)							
5	5								
6	6								
7	7								
8	8	Length (LEN)							
9	9								
10	10	Length of EPC (SOUID)							
11	11	reserved							
12	12	Timeout (TOUT)							
13	13								
14	14	Read fragment number (RFN)							
15	15	Write fragment number (WFN)							
16	16	Reserved							
17	17	Reserved							
18	18	Reserved							
19	19	Reserved							
20	24	Write data Byte 0							
21	25	Write data Byte 1							
22	26	Write data Byte 2							
23	27	Write data Byte 3							
24	28	Write data Byte 4							
25	29	Write data Byte 5							
26	30	Write data Byte 6							
27	31	Write data Byte 7							
...	...	...							
139	151	Write data Byte 127							

## 8.3.1 Meaning of the command bits

Description	Meaning
Command code (CMDCUHF)	Enter the command code
Loop counter for rapid processing (LCNT)	Loop counter for repeated processing of a command 0: Loop counter off
Memory area (DOM)	0: Kill password 1: EPC 2: TID 3: USER area 4: Access password 5: PC (size of EPC)
Start address (ADDR) in bytes	Enter the address where a command is to be sent (e.g. memory area of a tag)
Length (LEN) in bytes	Enter the length of the data to be read or written
Length of EPC (SQUID) in bytes	<b>Inventory command:</b> 0: Transfer the actual length (bytes) of the transferred EPC during an inventory operation. > 0: EPC completely output <b>Other commands:</b> Enter EPC size in bytes, if a particular tag is read, written or protected. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be read, written or protected if an EPC is present in the write data.
Timeout (TOUT)	Time in ms in which one command is to be executed. If a command is not executed within the entered time, the device outputs an error message. 0: No timeout, command stays active until the first tag was read. 1: Command is executed once (if there is already a tag in the detection range) > 1...65535: Time in ms Inventory: Command active for the entire specified time
Read fragment no. (RFN)	If the data to be read exceeds the size of the read data memory, the data is divided in max. 256 fragments. The fragments are numbered consecutively from 1...255. From fragment number 256 numbering starts again at 1. The sending of a fragment is confirmed by the device if the read fragment number appears in the process input data. After the confirmation the next fragment is read. 0: No fragmentation In Idle mode the size of fragments is stated. With a read command the number of the fragments containing data is stated.
Write fragment no. (WFN)	If the data to be written exceeds the size of the write data memory, the data is divided in max. 256 fragments. The fragments are numbered consecutively from 1...255. From fragment number 256 numbering starts again at 1. The sending of a fragment is confirmed by the device if the write fragment number appears in the process input data. After the confirmation the next fragment is written. 0: No fragmentation In Idle mode the size of fragments is stated. With a write command the number of the fragments is stated that contain data.
Write data	User-defined write data or entry of an EPC to select a specific tag for the command execution (if the <b>Length of EPC (SQUID)</b> command parameter is greater than 0).

## 8.4 Digital channels – process input data

Byte no.	Bit							
	<b>7</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>	<b>0</b>
0	DXP7	DXP6	DXP5	DXP4				
1								

### 8.4.1 Meaning of the status bits

Default values are shown in **bold** type.

Designation	Meaning
DXP4	<b>0: Digital channel 1 not active</b> 1: Digital channel 1 active
DXP5	<b>0: Digital channel 2 not active</b> 1: Digital channel 2 active
DXP6	<b>0: Digital channel 3 not active</b> 1: Digital channel 3 active
DXP7	<b>0: Digital channel 4 not active</b> 1: Digital channel 4 active

## 8.5 RFID channels – overview of the commands

RFID commands are initiated via the command code in the process output data of an RFID channel. The commands can be executed with or without a loop counter function. The loop counter must be set individually for each new command.



### NOTE

After commands are executed without the loop counter function, the device must be reset to the Idle state before a new command is sent.

- ▶ After a command is executed, send an Idle command to the device.

Command	Command code		Possible for	
	hex.	dec.	UHF compact	UHF extended
Idle	0x0000	0	x	x
Inventory	0x0001	1	x	x
Fast inventory	0x2001	8193	x	x
Read	0x0002	2	x	x
Fast read	0x2002	8194	x	x
Write	0x0004	4	x	x
Fast write	0x2004	8196	x	x
Write and verify	0x0008	8	x	x
Continuous mode	0x0010	16	–	x
Get data from buffer (Continuous mode)	0x0011	17	Max. 128 bytes	x
Get data from buffer with fast command processing (Continuous mode)	0x2011	8209	Max. 128 bytes	x
Continuous presence sensing mode	0x0020	32	–	x
End Continuous (presence sensing) mode	0x0012	18	–	x
Read/write head identification	0x0041	65	x	x
Direct read/write head command	0x0060	96	x	x
Direct read/write head command with fast command processing	0x2060	8288	x	x
Set tag password	0x0102	258	x	x
Set tag password with fast command processing	0x2102	8450	x	x
Set read/write head password	0x0100	256	x	x
Reset read/write head password	0x0101	257	x	x
Set tag protection	0x0103	259	x	x
Set tag protection with fast command processing	0x2103	8451	x	x
Set permanent lock (Lock)	0x0105	261	x	x
Set permanent lock with fast command processing	0x2105	8453	x	x
Tag info	0x0050	80	x	x

Command	Command code		Possible for	
	hex.	dec.	UHF compact	UHF extended
Tag info with fast command processing	0x2050	8272	x	x
Kill UHF tag	0x0200	512	x	x
Kill UHF tag with fast command processing	0x2200	8704	x	x
Restore UHF read/write head settings	0x1000	4096	x	x
Backup settings of the UHF read/write head	0x1001	4097	x	x
Query error/status of UHF read/write head	0x0042	66	x	x
Reset	0x8000	32768	x	x

## 8.5.1 Command: Idle

The **Idle** command switches the interface to Idle mode. The command execution is aborted. In UHF applications the EPC is indicated if the read/write head is assigned parameters directly in Presence sensing mode via the DTM.

<b>Request</b>	
Loop counter	Not required
Command code	0x0000 (hex.), 0 (dec.)
Read/write head address	Not required
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	Not required
Write fragment no.	Not required
Read fragment no.	Not required
Write data	Not required
<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0000 (hex.), 0 (dec.)
Length	Length of the EPC of the tag in the detection range
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	Size of the fragments
Read fragment no.	Size of the fragments
Read data, Bytes 0...n	EPC of the tag in the detection range



8.5.2 Command: Inventory

The **Inventory** command causes the read/write head to search for tags in the detection range and read the EPC or RSSI of the tag if activated in the UHF read/write head. The inventory command can be executed in single-tag mode and in Multi-tag mode.



**NOTE**

The command code for fast processing with the loop counter is 0x2001 (hex.) or 8193 (dec.).

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0001 (hex.), 1 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	1: Grouping of the EPCs active 0: Grouping of the EPCs inactive
Length	0: Transfer the actual length (bytes) of the transferred EPC during an inventory operation. > 0 : EPC completely output.
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0001 (hex.), 1 (dec.)
Length	Length of the read data
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	Ascending
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data, Bytes 0...n	See example: UHF read data

Data format in UHF applications

The UHF read data is formatted by means of a header. The header has the following structure:

Type	Name	Meaning
uint8_t	Size	Data size
uint8_t	Block type	1: EPC etc. Other values: Reserved
uint8_t	Data [size]	EPC and read data

The size of EPC/RSSI etc. depends on the settings of the read/write head.

## Reading out the RSSI value

The RSSI value is output in binary code in 2 bytes and corresponds to the two's complement of the output binary code. Mapped to a signed integer, the 2 bytes output correspond to ten times the actual RSSI value. Refer to the following table for an example of the RSSI value:

MSB...LSB (decimal)	MSB...LSB (binary)	Two's complement	RSSI (dBm)
252 253	11111100 11111101	-771	-77.1

Example: UHF read data (header and EPC, grouping deactivated)

Type	Name	Meaning
uint8_t	Size	14
uint8_t	Block type	1
uint8_t	Data [14]	uint8_t EPC [12] uint16_t Number of the antenna (LSB → MSB) [2]

Example: UHF read data (header and EPC, grouping activated)

Type	Name	Meaning
uint8_t	Size	16
uint8_t	Block type	1
uint8_t	Data [16]	uint8_t EPC [12] uint16_t Number of the antenna (LSB → MSB) [2] uint16_t Number of the read operations (LSB → MSB) [2]

Example: UHF read data (header and EPC, grouping with RSSI activated)

Type	Name	Meaning
uint8_t	Size	16
uint8_t	Block type	1
uint8_t	Data [20]	uint8_t EPC [12] uint16_t RSSI [2] uint16_t Number of the antenna (LSB → MSB) [2] uint16_t Number of the read operations (LSB → MSB) [2]

Byte	Content	Meaning
0	Data size (EPC + number of read operations)	2 byte header
1	UHF memory range	
3...13	EPC	12 bytes EPC
14	LSB	2 bytes RSSI
15	MSB	
16	LSB	2 bytes Number of the antenna:
17	MSB	<ul style="list-style-type: none"> <li>■ 0: RHCP</li> <li>■ 1: LHCP</li> <li>■ 2: Horizontal</li> <li>■ 3: Vertical</li> <li>■ 4: External 1</li> <li>■ 5: External 2</li> <li>■ 6: External 3</li> <li>■ 7: External 4</li> </ul>
18	LSB	2 bytes Number of read operations
19	MSB	

Example: UHF read data (header, EPC, grouping with RSSI, slot, time, phase activated)

Type	Name	Meaning
uint8_t	Size	24
uint8_t	Block type	1
uint8_t	Data [24]	uint8_t EPC [12] uint16_t RSSI (LSB → MSB) uint16_t Slot (LSB → MSB) uint32_t Time (LSB → MSB) uint16_t Phase (LSB → MSB) uint16_t Number of the antenna (LSB → MSB) [2] uint16_t Number of read operations (LSB → MSB)

## 8.5.3 Command: Read

The **Read** command causes the read/write head to read the data of tags in the detection range. 128 bytes are transferred in a read operation by default. Larger data volumes can be transferred in fragments. If a particular EPC is entered, the read/write head only reads the appropriate tags. All other tags in the detection range are ignored in this case.

**NOTE**

The command code for fast processing with the loop counter is 0x2002 (hex.) or 8194 (dec.).

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0002 (hex.), 2 (dec.)
Memory area	See description of the output data, [▶ 156]
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Enter EPC size in bytes, if a particular tag is to be read. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be read if an EPC is present in the write data.
Start address	Start address of the memory area on the tag to be read (entry in bytes)
Length	Length of the data to be read in bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data, Byte 0...(size of the EPC – 1)	EPC of the tag to be protected
Write data, Byte (size of the EPC)...127	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0002 (hex.), 2 (dec.)
Length	Length of the read data
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Increases during command execution
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data, Bytes 0...n	Read data

8.5.4 Command: Write

The **Write** command causes the read/write head to write data to tags in the detection range. 128 bytes are transferred in a write operation by default. Larger data volumes can be transferred in fragments. If a particular EPC is entered, the read/write head only writes the appropriate tags. All other tags in the detection range are ignored in this case.



**NOTE**

► With multi-tag applications enter the EPC of the tag to be written.



**NOTE**

The command code for fast processing with the loop counter is 0x2004 (hex.) or 8196 (dec.).

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0004 (hex.), 4 (dec.)
Memory area	See description of the output data, [▶ 156]
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Enter the EPC size in bytes if a particular tag is to be written. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be written if an EPC is present in the write data.
Start address	Start address of the memory area on the tag to be written (entry in bytes)
Length	Length of the data to be written in bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	1: Use fragmentation 0: Do not use fragmentation
Read fragment no.	0
Write data, Byte 0...(size of the EPC - 1)	EPC of the tag to be written
Write data, Byte (size of the EPC)...127	Write data

<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0004 (hex.), 4 (dec.)
Length	Length of the read data
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Increases during command execution
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	See description of the input data, [▶ 152]
Read fragment no.	0
Read data, Byte 0...127	Not required

8.5.5 Command: Write and verify

The **Write and verify** command writes a number of bytes defined by the user. The written data is also sent back to the interface and verified. 128 bytes are transferred by default in a write operation. Larger data volumes can be transferred in fragments. The written data is only verified in the interface and is not sent back to the controller. If the verification fails, an error message is output. If the command is processed without an error message, the data was verified successfully.



**NOTE**

▶ With multi-tag applications enter the EPC of the tag to be written.



**NOTE**

The command code for fast processing with the loop counter is 0x2008 (hex.) or 8200 (dec.).

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0008 (hex.), 8 (dec.)
Memory area	See description of the output data, [▶ 156]
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Enter the EPC size in bytes if a particular tag is to be written. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be written if an EPC is present in the write data.
Start address	Start address of the memory area on the tag to be written (entry in bytes)
Length	Length of the data to be written in bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	1: Use fragmentation 0: Do not use fragmentation
Read fragment no.	0
Write data, Byte 0...(size of the UID/EPC – 1)	Optional: UID or EPC of the tag to be written
Write data, Byte (size of the EPC)...127	Write data

Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0008 (hex.), 8 (dec.)
Length	Length of the read data
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Increases during command execution
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	See description of the input data, [▶ 152]
Read fragment no.	0
Read data, Byte 0...MIN(127, set length-1)	Not required



8.5.6 Command: Continuous mode

In Continuous mode, a user-defined command is sent to the read/write head and saved in the read/write head. The commands write, read and inventory can be executed in Continuous mode. The parameters for Continuous mode must be set directly in the read/write head.

The command is continuously executed until the user terminates Continuous mode. Continuous mode can be terminated with a reset command.



**NOTE**

The reset command resets all read data.

Read/write heads in Continuous mode send all command related data to the interface. The data is stored in the FIFO memory of the interface and can be queried by the controller via the **Get Data from FIFO** command.

Commands in Continuous mode are triggered if the read/write head detects a tag. If there is a tag in the detection range of the read/write head, the command sent in Continuous mode is executed with the next tag.



**NOTE**

In Continuous mode the **Tag in detection range** signal is not updated. Start address and length cannot be changed during the execution of Continuous mode. After Continuous mode is restarted, all data of the already running Continuous mode is deleted.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0010 (hex.), 16 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	1: Grouping of the EPCs active (only UHF inventory) 0: Grouping of the EPCs inactive (only UHF inventory) >1: Not defined
Length	Not required
Command timeout	Not required
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required

<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0010 (hex.), 16 (dec.)
Length	0
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Increases during command execution
Tag counter	Increases with each read or written EPC
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	See description of the input data, [▶ 152]

8.5.7 Command: Get data from buffer (Continuous mode)



**NOTE**

The command code for fast processing with the loop counter is 0x2011 (hex.) or 8209 (dec.).

The Get data from buffer command (Continuous mode) passes on data stored in the interface to the controller. The command is required to transfer read data to the controller in Continuous mode or in Continuous presence sensing mode. The data is transferred to the controller in fragments of up to 128 bytes. The size of the fragments can be set by the user. An EPC is not divided by fragment limits. If an EPC does not fit completely in a fragment, it is automatically moved to the next fragment.



**NOTE**

The **Get data from buffer** command does not end Continuous mode.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0011 (hex.), 17 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Not required
Length	Max. length of the data to be read by the device (≤ size of the data that the device has actually stored), entered in bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0011 (hex.), 17 (dec.)
Length	Length of the read data. The data is stated in complete blocks.
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Is automatically decreased after the execution of the command
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Read data

## Data format in UHF applications

The UHF read data is formatted by means of a header. The header has the following structure:

Type	Name	Meaning
uint8_t	Size	Data size
uint8_t	Block type	1: EPC etc. Other values: Reserved
uint8_t	Data [size]	EPC and read data

The size of EPC/RSSI etc. depends on the settings of the read/write head.

Example: UHF read data (header and EPC, grouping deactivated)

Type	Name	Meaning
uint8_t	Size	14
uint8_t	Block type	1
uint8_t	Data [14]	uint8_t EPC [12] uint16_t Number of the antenna (LSB → MSB) [2]

Example: UHF read data (header and EPC, grouping activated)

Type	Name	Meaning
uint8_t	Size	16
uint8_t	Block type	1
uint8_t	Data [16]	uint8_t EPC [12] uint16_t Number of the antenna (LSB → MSB) [2] uint16_t Number of the read operations (LSB → MSB) [2]

Example: UHF read data (header, EPC, grouping with RSSI, slot, time, phase activated)

Type	Name	Meaning
uint8_t	Size	24
uint8_t	Block type	1
uint8_t	Data [24]	uint8_t EPC [12] uint16_t RSSI (LSB → MSB) uint16_t Slot (LSB → MSB) uint32_t Time (LSB → MSB) uint16_t Phase (LSB → MSB) uint16_t Number of the antenna (LSB → MSB) [2] uint16_t Number of read operations (LSB → MSB)

8.5.8 Command: UHF continuous presence sensing mode

In Continuous presence sensing mode, a user-defined command (write, read, inventory) is sent to the UHF read/write head and saved in the read/write head. The read/write heads are automatically switched on in Continuous presence sensing mode as soon as a tag is located in the detection range. The duration of the scan interval and the on time can be adjusted in the settings of the UHF read/write head. The command is continuously executed until the user terminates Continuous presence sensing mode by executing a reset command.



**NOTE**

The reset command resets all read data.

Read/write heads in Continuous presence sensing mode send all command related data to the interface. The data is stored in the buffer of the interface and can be queried by the controller via the **Get data from buffer** command. In Continuous presence sensing mode the **Tag in detection range** signal is not permanently updated.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0020 (hex.), 32 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	0: Grouping inactive 1: Grouping active >1: Not defined
Length	Not required
Command timeout	Not required
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0020 (hex.), 32 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	Increases during command execution
Tag counter	Increases with each read or written EPC
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	See description of the input data, [▶ 152]

## 8.5.9 Command: End Continuous (presence sensing) mode

Continuous and presence sensing mode can be stopped via the **Shut down Continuous (presence sensing) mode** command. The data in the buffer of the interface is not deleted after the command is executed and can still be called up by the controller via the **Get data from buffer** command.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0012 (hex.), 18 (dec.)
Read/write head address	Not required
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0012 (hex.), 18 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

8.5.10 Command: Read/write head identification

The **Read/write head identification** command scans the following parameters of the connected read/write head:

- Ident No.
- Serial number
- Hardware version
- Firmware status

The parameters are contained in the read/write head in the identification record.

<b>Request</b>	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0041 (hex.), 65 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Start address in the identification record, stated in bytes
Length	Length of the data to be scanned 0: Read complete parameter set
Command timeout	Not required
Write fragment no.	Not required
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required

<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0041 (hex.), 65 (dec.)
Length	See description of the input data, [▶ 152]
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	Increases with each read or written EPC
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data, Byte 0...19	Ident No.: ARRAY [0...19] of BYTE
Read data, Byte 20...35	Serial number: ARRAY [0...15] of BYTE
Read data, Byte 36...37	Hardware version: INT16 (Little Endian)
Read data, Byte 38...41	Firmware status: ARRAY [0...] of BYTE: V (0x56), x, y, z (Vx.y.z)
Read data, Bytes 42...119	Not required

## 8.5.11 Direct read/write head command



### NOTE

The command code for fast processing with the loop counter is 0x2060 (hex.) or 8288 (dec.).

A direct command enables commands from the read/write head protocol to be sent directly to the read/write head. The commands are defined and interpreted by the entries in the write and data.



### NOTE

The read/write head protocol is not part of this documentation and must be requested from Turck and specially released. Send any inquiries about the read/write head protocol to Turck.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0060 (hex.), 96 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	0
Start address	Not required
Length	Length of the description of the direct command in the write data, entry in bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Description of the direct command
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0060 (hex.), 96 (dec.)
Length	Length of the description of the direct command in the write data
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Response to the direct command



Example: Direct command in UHF applications (scan read/write head version)

<b>Request</b>	
Loop counter	0
Command code	0x0060
Read/write head address	0
Length of EPC	0
Start address	0
Length	2
Command timeout	200
Write fragment no.	0
Read fragment no.	0
Write data	0x02 (CMD), 0x00 (application) – see debug protocol

<b>Response</b>	
Loop counter	0
Response code	0x0060
Length	12
Error code	0
Tag within the detection range	0
Data (bytes) available	0
Tag counter	0
Write fragment no.	0
Read fragment no.	0
Read data	0x02, 0x00, 0x01, 0x02, 0x03, 0x04, 0x8B, 0x20, 0x00, 0x01, 0x00, 0x01

The debug protocol enables the read data to be interpreted as follows:

MSG	ERR	SNR0	SNR1	SNR2	SNR3	GTYP	VERS	HW
0x02	0x00	0x01	0x02	0x03	0x04	0x8B 0x20	0x00 0x01	0x00 0x01

- Serial number: 0x01020304
- Device type: 0x208B
- Software version: v1.00
- Hardware version: v1.00

## 8.5.12 Command: Set tag password



### NOTE

The command code for fast processing with the loop counter is 0x2102 (hex.) or 8450 (dec.).

The **Set tag password** command sets a password in the tag. When sending the command only one tag can be located in the detection range of the read/write head. After the password is sent, other commands (e.g. **Set tag protection**) can be sent to the tag. The **Set tag password** command prevents a Kill password from being set in the tag.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0102 (hex.), 258 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length UID/EPC	Enter the EPC size in bytes if a particular tag is to be protected. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be protected if an EPC is present in the write data.
Start address	Not required
Length	4 bytes
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data, Byte 0...3	Password: ARRAY [0...3] OF BYTE
Write data, Byte 4...127	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0102 (hex.), 258 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

8.5.13 Command: Set read/write head password

The **Set read/write head password** command directly sets a password for write access, read access or a kill command in the tag. The password is stored temporarily in the memory of the read/write head. After the voltage of the read/write head is reset, the password must be set again in the read/write head. With UHF applications, the password is stored in the memory of the interface.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0100 (hex.), 256 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data, Byte 0...3	Password: ARRAY [0...3] OF BYTE
Write data, Byte 4...127	Not required

Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0100 (hex.), 256 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

## 8.5.14 Command: Reset read/write head password

The **Reset read/write head** password command directly resets a password for write access, read access or a kill command in the read/write head. The password function is switched off, there is no password exchange between the read/write head and the tag.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0101 (hex.), 257 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0101 (hex.), 257 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

8.5.15 Command: Set tag protection



**NOTE**

The command code for fast processing with the loop counter is 0x2103 (hex.) or 8451 (dec.).

The **Set tag protection** command defines password protection for the tag with a direct command. For this it has to be specified whether a write protection or a read protection should be set and the area of the tag to which the password applies. Protection for all areas is defined with one command. When sending the command only one tag can be located in the detection range of the read/write head.

Write protection is always also contained in a read protection.



**NOTE**

A write protection for UHF tags cannot be undone.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0103 (hex.), 259 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Enter the EPC size in bytes if a particular tag is to be protected. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: The command is executed for the tag which is located in the detection range of the read/write head. > 0: EPC length of the tag to be protected if an EPC is present in the write data.
Start address	Not required
Memory area	Possible values: <ul style="list-style-type: none"> <li>■ PC and EPC (memory area 1)</li> <li>■ USER memory (memory area 3)</li> </ul> The entire memory area selected is protected with a password.
Length	0 byte
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data, Byte 0	Not required
Write data, Byte 1	0
Write data, Byte 2	0
Write data, Byte 3	0
Write data, Byte 4	Not required
Write data, Byte 5	0
Write data, Byte 6	0
Write data, Byte 7	0
Write data, Byte 8...127	Not required

<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0103 (hex.), 259 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

8.5.16 Command: Tag info



**NOTE**

The command code for fast processing with the loop counter is 0x2050 (hex.) or 8272 (dec.).

The **Tag info** command enables the following chip information of a tag to be scanned:

- Allocation class identifier
- Tag mask designer identifier
- Tag model number

The data is queried from the GSI record of the tag.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0050 (hex.), 80 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Start address in the GSI record
Length	Length of the system data read (bytes) 0: All system data is read
Command timeout	Not required
Write fragment no.	Not required
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required

Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0050 (hex.), 80 (dec.)
Length	See description of the input data, [▶ 152]
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data, Byte 0...3	First 32 bytes of the TID (tag class, manufacturer and chip type)
Read data, Bytes 4...n	EPC (length variable)

## Chip information on the UHF tags

Name	TID memory		Tag model number	Size (Bits)		
	Allocation class identifier	Tag mask designer		EPC	TID	USER
Alien Higgs-3	0xE2	0x003	0x412	96...480	96	512
Alien Higgs-4	0xE2	0x003	0x414	16...128	96	128
NXP U-Code G2XM	0xE2	0x006	0x003	240	64	512
NXP U-Code G2XL	0xE2	0x006	0x004	240	64	–
NXP U-Code G2iM	0xE2	0x006	0x80A	256	96	512
NXP U-Code G2iM+	0xE2	0x006	0x80B	128...448	96	640...320
NXP U-Code G2iL	0xE2	0x006	0x806, 0x906, 0xB06	128	64	–
NXP U-Code G2iL+	0xE2	0x006	0x807, 0x907, 0xB07	128	64	–
NXP U-Code 7	0xE2	0x806	0x890	128	96	–
NXP U-Code 7xm (2k)	0xE2	0x806	0xF12	448	96	2048
Impinj Monza 4E	0xE2	0x001	0x10C	496	96	128
Impinj Monza 4D	0xE2	0x001	0x100	128	96	32
Impinj Monza 4QT	0xE2	0x001	0x105	128	96	512
Impinj Monza 5	0xE2	0x001	0x130	128	96	–
Impinj Monza R6	0xE2	0x001	0x160	96	96	–
Impinj Monza R6-P	0xE2	0x001	0x170	128	96	64



8.5.17 Command: Permanently deactivate UHF tags (Kill)



**NOTE**

The command code for fast processing with the loop counter is 0x2200 (hex.) or 8704 (dec.).

The **Kill UHF tag** command makes the tag memory unusable. After a kill command, the tag can neither be read nor written. A kill command cannot be undone.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0200 (hex.), 512 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Enter the EPC size in bytes if a particular tag is to be deleted. The EPC must be defined in the write data (start byte: 0). The function of the length of the EPC depends on the command used. 0: No entry of an EPC for executing the command. Only one tag can be located in the detection range of the read/write head. > 0: EPC length of the tag to be deleted if an EPC is present in the write data.
Start address	Not required
Length	1 byte
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data, Byte 0...3	Password: ARRAY [0...3] OF BYTE
Write data, Byte 4...127	Not required

Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x0200 (hex.), 512 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

## 8.5.18 Command: Restore UHF read/write head settings

The **Restore UHF read/write head settings** command restores the parameters of the UHF read/write head from a backup. To execute the command, a backup must be created beforehand via the **Backup settings of the UHF read/write head** command.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x1000 (hex.), 4096 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x1000 (hex.), 4096 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

8.5.19 Command: Backup settings of the UHF read/write head

The **Backup settings of the UHF read/write head** command saves the current settings of the connected read/write head in the memory of the interface. The backup is retained also after a voltage reset. The backup data can be restored via the **Restore UHF read/write head settings** command.

<b>Request</b>	
Loop counter	See description of the output data, [▶ 156]
Command code	0x1001 (hex.), 4097 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length of EPC	Not required
Start address	Not required
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x1001 (hex.), 4097 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required

## 8.5.20 Command: Query error/status of UHF read/write head

The **Read error/status of UHF read/write head** command enables error/status messages of the UHF read/write head to be read.

Request	
Loop counter	See description of the output data, [▶ 156]
Command code	0x0042 (hex.), 66 (dec.)
Read/write head address	Not required
Length of EPC	Not required
Start address	Address in the <b>Get Status response</b> record
Length	Length of the data to be read from the <b>Get Status response</b> record 0: Read entire <b>Get Status response</b> record
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required

Response	
Loop counter	See description of the input data, [▶ 152]
Response code	0x042 (hex.), 66 (dec.)
Length	See description of the input data, [▶ 152]
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data, Byte 0...(Length-1)	<ul style="list-style-type: none"> <li>■ Status general: 1 byte general status</li> <li>■ RF status: 1 byte status of the RF module</li> <li>■ Device status: 1 byte device-specific status information</li> <li>■ RF mode: 1 byte, defines the reason for starting the read operation</li> <li>■ Trigger status: 1 byte, trigger number of the RF mode</li> <li>■ I/O status: 1 byte, status of the inputs and outputs (0 = low, 1 = high)</li> <li>■ Ambient temperature: 1 byte, ambient temperature in °C (data format: 8 bit, two's complement)</li> <li>■ PA temperature: 1 byte, PA temperature in °C (data format: 8 bit, two's complement)</li> <li>■ RF antenna temperature: 1 byte, antenna temperature in °C (data format: 8 bit, two's complement)</li> <li>■ Transmit power: 2 bytes, output power of the read/write head in 1/10 dBm steps, LSB...MSB (data format: 16 bit, two's complement)</li> <li>■ Reverse power: 2 bytes, returned reverse power in 1/10 dBm steps, LSB...MSB (data format: 16 bit, two's complement)</li> <li>■ Antenna DC resistance: 4 bytes, resistance at the antenna port in Ω, LSB...MSB</li> <li>■ Jammer power: 2 bytes, input power at the RX port in 1/10 dBm steps, LSB...MSB (data format: 16 bit, two's complement)</li> <li>■ Channel: Number of the currently used channel (offset from the next available channel)</li> </ul>
Read data, byte (Length)...127	Not required

## Evaluating read data – general status

Bit	Meaning
7	Read/write head was reset (after reset)
6	Read/write head configuration damaged, default settings are used
5	Test mode active
1	Tag present

## Evaluating read data – RF status

Bit	Meaning
4	Limit value for radiated power exceeded
3	No free channel present
2	Antenna resistance too high or too low
1	Reverse power too high
0	PLL not locked

## Evaluating read data – device status

Bit	Meaning
4	Error in message generation (in Polling mode outside of memory area)
3	Temperature warning
2	Temperature too high
1	Communication error
0	Configuration invalid. Command execution not possible.

## Evaluating read data – RF mode

Value	Meaning
0x00	None (tag off)
0x01	Mode 1: Trigger is digital signal (edge), Timeout
0x02	Mode 2: Trigger is digital signal (edge), Timeout
0x03	Mode 3: Trigger is digital signal (level), Timeout
0x04	Trigger is a command
0x08	Reserved
0x10	DCU controlled read operation
0x20	Continuous mode
0x80	Automatic trigger (presence sensing mode)

## Evaluating read data – I/O status

<b>Value</b>	<b>Meaning</b>
7	Output 4
6	Output 3
5	Output 2
4	Output 1
3	Input 4
2	Input 3
1	Input 2
0	Input 1

## 8.5.21 Command: Reset

The **Reset** command resets the read/write head and interface.

<b>Request</b>	
Loop counter	See description of the output data, [▶ 156]
Command code	0x8000 (hex.), 32768 (dec.)
Read/write head address	See description of the output data, [▶ 156]
Length UID/EPC	Not required
Start address	0: Software reset 1: Voltage reset
Length	Not required
Command timeout	See description of the output data, [▶ 156]
Write fragment no.	0
Read fragment no.	See description of the output data, [▶ 156]
Write data	Not required
<b>Response</b>	
Loop counter	See description of the input data, [▶ 152]
Response code	0x8000 (hex.), 32768 (dec.)
Length	Not required
Error code	See description of the input data, [▶ 152]
Tag within the detection range	See description of the input data, [▶ 152]
Data (bytes) available	See description of the input data, [▶ 152]
Tag counter	See description of the input data, [▶ 152]
Write fragment no.	0
Read fragment no.	See description of the input data, [▶ 152]
Read data	Not required



## 8.6 Setting devices via the web server

The devices can be set and commands sent to the devices via the integrated web server.

- ▶ Open the web server and log in as user (see [▶ 48])
- ⇒ Write access to input data, output data and parameter data is possible after the login.

Example: operating mode setting

In the following example the operating mode is set to **UHF Compact**.

- ▶ Click **Local I/O** → **Parameter** in the navigation bar on the left of the screen.
- ▶ Select **RFID control/status ch0**.




Fig. 144: Web server – parameters

- ▶ Select the operating mode via the **Operation mode** drop-down menu.




Fig. 145: Web server – setting the operating mode

Example: executing the Inventory command

In the following example an Inventory command is carried out via the web server.

- ▶ Click **Local I/O** → **Output** in the navigation bar on the left of the screen.
- ▶ Select the Inventory command via the **Command code** drop-down menu: **0x0001 Inventory**
- ▶ Activate Optional grouping: Set **Start address** parameter to **1**.
- ⇒ The receipt of the command is confirmed automatically in the input data at **Response code**.

The screenshot shows the web server interface for the device TN-UHF-Q300-EU-CDS. The page title is "TN-UHF-Q300-EU-CDS - Local I/O - Output". The interface is divided into two main sections: "Input values" and "Output values".

**Input values:**

- Response code: 0x8001 Busy - Inventory
- Tag present at read/write head: no
- Continuous (Presence sensing) mode active: no
- Loop counter for fast processing: 0
- Length: 0
- Error code: -
- Tag counter: 0
- Data (Bytes) available: 0
- Read fragment No.: 0
- Write fragment No.: 0

**Output values:**

- Command code: 0x0001 Inventory
- Loop counter for fast processing: 0
- UHF: Memory area: Kill password
- Start address: 1
- Length: 0
- Length of UID/EPC: 0
- Command timeout (\*1ms): 0

The interface also includes a navigation menu on the left with options like Info, Parameter, Diagnosis, Status, Event log, Ex- / Import, and Change Password. The "LOCAL I/O" section is active, showing options for Parameter, Diagnosis, Input, and Output.

Fig. 146: Web server – executing the Inventory command

The Inventory command is executed as soon as there is a tag in the detection range of the read/write head.

**TN-UHF-Q300-EU-CDS**

**TN-UHF-Q300-EU-CDS - Local I/O - Output**

Write Channel view

**RFID control/status ch0**

**Input values**

Response code	0x0001 Inventory	
Tag present at read/write head	<input type="checkbox"/> no	?
Continuous (Presence sensing) mode active	<input type="checkbox"/> no	?
Loop counter for fast processing	0	?
Length	20	?
Error code	-	?
Tag counter	1	?
Data (Bytes) available	0	?
Read fragment No.	0	?
Write fragment No.	0	?

**Output values**

Command code	0x0001 Inventory	
Loop counter for fast processing	0	?
UHF: Memory area	Kill password	
Start address	1	?
Length	0	?
Length of UID/EPC	0	?
Command timeout (*1ms)	0	?

Fig. 147: Web server – input data with successful Inventory command

The read data can be called at **RFID read data ch0**.

The screenshot shows the web server interface for 'TN-UHF-Q300-EU-CDS'. The main content area is titled 'TN-UHF-Q300-EU-CDS - Local I/O - Output'. On the left, there is a navigation menu with options: Info, Parameter, Diagnosis, Status, Event log, Ex- / Import, Change Password, LOCAL I/O, Parameter, Diagnosis, Input, and Output. The 'Output' option is highlighted. The main content area shows a 'Write' button and a 'Channel view' tab. Below this, there is a list of input buffers and their corresponding data values:

Channel	Input buffer	Data
RFID control/status ch0	Input buffer 0-7	12 01 21 21 00 00 00 00
	Input buffer 8-15	00 00 00 00 00 00 70 fd
<b>RFID read data ch0</b>	Input buffer 16-23	00 00 01 00 00 00 00 00
	Input buffer 24-31	00 00 00 00 00 00 00 00
RFID write data ch0	Input buffer 32-39	00 00 00 00 00 00 00 00
	Input buffer 40-47	00 00 00 00 00 00 00 00
DXP	Input buffer 48-55	00 00 00 00 00 00 00 00
	Input buffer 56-63	00 00 00 00 00 00 00 00
VAUX control	Input buffer 64-71	00 00 00 00 00 00 00 00
	Input buffer 72-79	00 00 00 00 00 00 00 00
	Input buffer 80-87	00 00 00 00 00 00 00 00
	Input buffer 88-95	00 00 00 00 00 00 00 00
	Input buffer 96-103	00 00 00 00 00 00 00 00
	Input buffer 104-111	00 00 00 00 00 00 00 00
	Input buffer 112-119	00 00 00 00 00 00 00 00
	Input buffer 120-127	00 00 00 00 00 00 00 00

Fig. 148: Web server – read data

## 9 Operation

### 9.1 Executing a command and calling data



#### NOTE

A command is successful when the response code is the same as the command code.

---

- ▶ Set the parameters for the command.
- ▶ Set command code.
- ⇒ Set the command code. The command is successful when the response code is the same as the command code and no error message is present.

### 9.2 Using fragmentation

If more data is read than the set size of the data interface, the fragment counter is automatically incremented in the input data.

- ▶ To read more data, increase the fragment counter in the output data.
- ▶ Repeat process until the read or write fragment no. in the input data equals 0.

If less data is read than the set size of the data interface, the fragment counter stays at 0.

### 9.3 Using commands with a loop counter function



#### NOTE

The loop counter is only supported for fast execution commands.

---

- ▶ Setting the command: Enter the command code.
- ▶ Set the loop counter to 1.
- ⇒ The command was successfully executed if the same command code appears in the process input data as in the process output data. The RFID data is stored in the buffer of the interface.
- ▶ Repeating the command: Increase the loop counter in the output data by 1.
- ⇒ The command was successfully executed if the same loop counter value appears in the process input data as in the process output data. The RFID data is stored in the buffer of the interface.
- ▶ Setting a new command: Set the new command code and set the loop counter to 0.

## 9.4 Using Inventory command and Continuous (presence sensing) mode

The Inventory command and Continuous (presence sensing) mode transfer data to the PLC in different ways. Continuous mode is suitable for high-speed applications, in which a command (e.g. read or write) is to be performed repetitively. Repeated execution of the same command by the controller is unnecessary.

The following lists the most important differences between an Inventory command and Continuous mode:

Inventory	Continuous mode	Continuous presence sensing mode
Triggered reading of EPCs	<ul style="list-style-type: none"> <li>■ Repeated reading of EPCs</li> <li>■ Automatic repetition of the same command (e.g. Inventory, read, write)</li> </ul>	<ul style="list-style-type: none"> <li>■ UHF read/write head switches on as soon as a tag is detected</li> <li>■ Repeated reading of EPCs</li> <li>■ Automatic repetition of the same command (e.g. Inventory, read, write)</li> </ul>
Data is displayed in the read data after the command has ended.	Data must be read from the memory of the interface with a separate command.	Data must be read from the memory of the interface with a separate command.
Grouping of EPCs possible	Grouping of EPCs possible	Grouping of EPCs possible
No buffering on the read/write head	No buffering on the read/write head	No buffering on the read/write head
Terminate command: <ol style="list-style-type: none"> <li>1. Timeout</li> <li>2. Automatically after command execution</li> </ol>	Terminate command: <ol style="list-style-type: none"> <li>1. Timeout</li> <li>2. Separate command</li> </ol>	Terminate command: <ol style="list-style-type: none"> <li>1. Timeout</li> <li>2. Separate command</li> </ol>

## 9.5 LEDs

The device has the following LED indicators:

- Power supply
- Group and bus errors
- Status
- Diagnostics

The APPL LED can be programmed in CODESYS according to the application.

<b>PWR LED</b>	<b>Meaning</b>
Off	No power supply
Green	Power supply error-free
Yellow	Undervoltage within tolerance range
Red	Undervoltage outside of tolerance range

<b>RFON LED</b>	<b>Meaning</b>
Off	RF field switched off
Green	RF field switched on

<b>DATA LED</b>	<b>Meaning</b>
Off	No tag in the field, no data transfer
Yellow flashing	Tag in the field, data transfer via the air interface

<b>DIAG LED</b>	<b>Meaning</b>
Off	No error
Red	Error

The USER LED can be adjusted according to the application.

<b>BUS LED</b>	<b>Meaning</b>
Off	No voltage present
Green	Connection to a master active
Flashing green (1 Hz)	Device is operational
Red	IP address conflict or Restore mode active
Flashing red	Wink command active
Flashing red/green (1 Hz)	Autonegotiation and/or wait for IP address allocation in DHCP or BootIP mode

<b>ERR LED</b>	<b>Meaning</b>
Off	No voltage present
Green	No diagnostics
Red	Diagnostics present

<b>RUN LED</b>	<b>Meaning</b>
Green	Program active
Red	Program stopped
Flashing red	No program present
Flashing red (double, 1 Hz)	F_Reset active
Flashing red/green (1 Hz)	OS starts

<b>APP LED(programmable)</b>	
Flashing white	Wink command active

<b>LAN LED</b>	<b>Meaning</b>
Off	No Ethernet connection
Lit green	Ethernet connection established, 100 Mbit/s
Green flashing	Data transfer, 100 Mbit/s
Lit yellow	Ethernet connection established, 10 Mbit/s
Yellow flashing	Data transfer, 10 Mbit/s



## 9.6 Software diagnostic messages

### 9.6.1 Diagnostic messages – gateway functions

Meaning of the diagnostic bits

Designation	Meaning
FCE	Force mode in the DTM active
COM	Internal error
V1oPoE	Undervoltage detected at power supply terminal V1 or power sourcing equipment (PSE) type 1
DIAG	Module diagnostics present

Byte no.	Bit							
	7	6	5	4	3	2	1	0
0		FCE				COM	V1oPoE	
1								DIAG

### 9.6.2 Diagnostic messages – RFID channels

Byte no.	Bit							
	7	6	5	4	3	2	1	0
0	VAUX	PRMER	DTM	FIFO				
1	Reserved							
2	Reserved							
3	Reserved							
4		TRE1	PNS1					
5	Reserved							
...	...							
35	Reserved							

Meaning of the diagnostic bits

Designation	Meaning
VAUX	Overvoltage at power supply terminal VAUX
PRMER	Parameter error
DTM	Configuration via the DTM active
FIFO	Buffer full
TRE1	Read/write head reports error
PNS1	Parameter not supported by read/write head

### 9.6.3 Diagnostic messages – digital channels

Byte no.	Bit							
	7	6	5	4	3	2	1	0
0							VErrV1C1	VErrV1C0
3					ERR3	ERR2	ERR1	ERR0

Meaning of the diagnostic bits

Designation	Meaning
VErrV1C0Ch0Ch1	Overcurrent at power supply terminal VAUX1 at socket C0 (channels 0 and 1)
VErrV1C1Ch2Ch3	Overcurrent at power supply terminal VAUX1 at socket C1 (channels 2 and 3)
ERRx	Error message on channel x

### 9.6.4 Diagnostic messages – device status

Byte no.	Bit							
	7	6	5	4	3	2	1	0
0								DIAG
1		FCE				COM	V1oPoE	

Meaning of the diagnostic bits

Designation	Meaning
DIAG	Module diagnostics present
FCE	Force mode in the DTM active
COM	Internal error
V1oPoE	Undervoltage detected at power supply terminal V1 or power sourcing equipment (PSE) type 1

## 9.7 Reading error codes

The error codes are part of the process input data.

Error code (hex.)	Error code (dec.)	Meaning
0x8000	32768	Channel not active
0x8001	32769	Read/write head not connected
0x8002	32770	Memory full
0x8003	32771	Block size of the tag not supported
0x8004	32772	Length larger than the size of the read fragment
0x8005	32773	Length larger than the size of the write fragment
0x8100	33024	Parameter undefined
0x8105	33029	Size of the write fragment outside of the permissible range
0x8106	33030	Size of the read fragment outside of the permissible range
0x81FF	33023	No read/write head selected
0x8200	33280	Command code unknown
0x8201	33281	Command not supported
0x8203	33283	Command not supported in UHF applications
0x8209	33289	Length parameter outside of the permissible range
0x820A	33290	Address outside of the permissible range
0x820B	33291	Length and address outside of the permissible range
0x820C	33292	No tag found
0x820D	33293	Timeout
0x8210	33296	Length outside of the tag specification
0x8211	33297	Address outside of the tag specification
0x8212	33298	Length and address outside of the tag specification
0x8213	33299	Memory area of the tag outside of the permissible range
0x8214	33300	Read/write head address outside of the permissible range
0x8215	33301	Value for timeout outside of the permissible range
0x8300	33536	<b>Continuous mode</b> command not activated
0x8302	33538	Grouping not supported with read commands
0x8304	33540	Grouping not supported with write commands
0x0801	2049	Write or read error
0x2000	8192	Kill command not successful
0x2500	9472	Password function not supported by tag
0x2501	9473	Password function not supported by read/write head
0x2900	10496	Address outside of the block limits
0x2901	10497	Length outside of the block limits

Error code (hex.)	Error code (dec.)	Meaning
0xC000	49152	Internal error (response of the read/write head too short)
0xC001	49153	Command not supported by read/write head version
0xB0...	45...	Read/write head reports error
0xB062	45154	Read/write head error when executing an Inventory command
0xB067	45159	Read/write head error when executing a lock block command
0xB068	45160	Read/write head error when executing a read multiple block command
0xB069	45161	Read/write head error when executing a write multiple block command
0xB06A	45162	Error when reading the system information
0xB06B	45163	Error when reading the protection status of the tags
0xB0BD	45245	Error when setting the transfer rate
0xB0DA	45274	Error with the <b>Tag in detection range</b> function
0xB0E1	45281	Error when reading the extended read/write head version
0xB0F8	45304	Error when resetting a command in Continuous mode
0xB0FA	45306	Error when outputting the response code
0xB0FF	45311	Error when resetting the read/write head
0xB0B3	45235	Error when setting the tag password
0xB0B6	45238	Error when setting the write or read protection
0xB0B8	45240	Error when reading the protection status of the memory area on the tag
0xB0C3	45251	Error when setting the password in the read/write head
0xD0...	53...	Read/write head reports error
0xD001	53249	Error when resetting the read/write head
0xD002	53250	Error when reading the read/write head version
0xD003	53251	Error when reading the read/write head version when a tag is in the detection range
0xD004	53252	Error when setting the read/write head address
0xD009	53257	Error with the parameter setting of the read/write head
0xD00A	53258	Error when setting the transfer speed and the operating mode of the read/write head
0xD00B	53259	Error when polling
0xD00D	53261	Error when reading the device status
0xD00E	53262	Error when resetting the internal status bit
0xD00F	53263	Error when setting the read/write head outputs and/or LEDs
0xD011	53265	Error when reading the internal malfunctions
0xD014	53268	Diagnostics error
0xD016	53270	Error with the heartbeat message
0xD017	53271	Error when outputting the user settings
0xD01B	53275	Error when emptying the message memory in Polling mode
0xD081	53377	Error when switching the UHF tag on or off
0xD083	53379	Error when reading from a tag
0xD084	53380	Error when writing to a tag

Error code (hex.)	Error code (dec.)	Meaning
0xD085	53381	Software trigger error
0xD088	53384	Error when outputting a command according to EPC Class1 Gen2
0xD100	53504	Error with the Backup function
0xD101	53505	Error with the Backup function (required memory not available)
0xD102	53506	Error when restoring a backup
0xD103	53507	Error when restoring a backup (no backup present)
0xD104	53508	Error when restoring a backup (backup data damaged)
0xD105	53509	Error when restoring the default settings
0xD106	53510	Error with the tag function
0xF8...	63...	Read/write head error
0xF820	63520	Read/write head: Command not supported
0xF821	63521	Read/write head: Unspecified error
0xF822	63522	Read/write head: A valid password is expected before the command is accepted.
0xF824	63524	Read/write head: Read operation not possible (e.g. invalid tag)
0xF825	63525	Read/write head: Write operation not possible (e.g. tag can only be read)
0xF826	63526	Read/write head: Write or read error
0xF827	63527	Read/write head: Access to unknown address (e.g. memory area outside of range)
0xF828	63528	Read/write head: The data to be sent is not valid
0xF82A	63530	Read/write head: The command requires a long time for execution.
0xF82C	63532	Read/write head: The requested object is not in the persistent memory.
0xF82D	63533	Read/write head: The requested object is not in the volatile memory.
0xF835	63541	Read/write head: The command is temporarily not permissible.
0xF836	63542	Read/write head: The opcode is not valid for this type of configuration memory.
0xF880	63616	Read/write head: No tag in the field
0xF881	63617	Read/write head: The EPC of the command does not match the EPC in the detection range
0xF882	63618	Read/write head: Incorrect tag type specified
0xF883	63619	Write command to a block failed
0xFFFFE	65534	Timeout on the RS485 interface
0xFFFF	65535	Command aborted

## 10 Troubleshooting

If the device does not work as expected, proceed as follows:

- ▶ Exclude environmental disturbances.
- ▶ Check the connections of the device for errors.
- ▶ Check device for parameterization errors.

If the malfunction persists, the device is faulty. In this case, decommission the device and replace it with a new device of the same type.

## 10.1 Rectifying errors

Errors are displayed by an ERR LED lit red on the device.

Calling error messages in the DTM and rectifying them



### NOTE

Contact Turck if the error persists after the read/write head is reset.

- ▶ Right-click the device in the project tree.
- ▶ Select **Diagnosis** in the context menu.



PACTware




Fig. 149: Project tree – starting diagnosis

⇒ The diagnosis window opens in the DTM.




Fig. 150: DTM – diagnosis

Rectifying error messages:

- ▶ Click the **Reset read/write head** button in the RFID Test main menu.
- ▶ Select **Reset the read/write head** in the drop-down menu.
- ⇒ The read/write head is reset.




Fig. 151: DTM – Reset the read/write head



Calling error messages in the web server and rectifying them



**NOTE**

Contact Turck if the error persists after the read/write head is reset.

- ▶ Log in to the web server (see [▶ 49]).
- ▶ Click **Diagnostics** in the navigation bar on the left of the screen.
- ⇒ The error messages are displayed in the device status.

MAIN    UHF RFID CONFIG & DEMO    DOCUMENTATION    CLOUD

---

**INTERN Q300 GENERIC**    **TN-UHF-Q300-EU-CDS**

**UHF IDENT 0 - UHF DEVICE**

- Info
- Parameter
- Diagnostics**
- Input
- Import-/Export
- Application

Write    Channel view

**Device status**

Device status	Value	?
Configuration invalid; operation impossible	-	?
Message generation error - out of memory in polling mode	-	?
RF Transceiver communication error	-	?
Temperature too high	-	?
Temperature warning	-	?
<b>General status</b>		
Device configuration invalid, using defaults	-	?
Device had a reset	active	?
Test mode	-	?
Transponder present	-	?
<b>RF status</b>		
Antenna resistance too high or too low	-	?
PLL is not locked	-	?
Regulation execution failed; no free RF channel	-	?
Reverse power too high	-	?
Transmit power exceeded limit	-	?

Fig. 152: Web server – Diagnostics

Rectifying error messages:

- ▶ Click **Local I/O** → **Output** in the navigation bar on the left of the screen.
- ▶ Select **RFID control/status ch0**.
- ▶ Select the Reset command via the **Command code** drop-down menu: **0x8000 Reset**
- ⇒ The read/write head is reset.




Fig. 153: Web server – resetting the read/write head

## 11 Maintenance

### 11.1 Executing the firmware update via FDT/DTM

The firmware of the device can be updated via FDT/DTM. The PACTware FDT frame application, the DTM for the device and the latest firmware can be downloaded free of charge from [www.turck.com](http://www.turck.com).



**NOTICE**

Interruption of the power supply during the firmware update

**Risk of device damage due to faulty firmware update**

- ▶ Do not interrupt the power supply during the firmware update.
- ▶ During the firmware update do not reset the power supply.

Example: Updating the firmware with the PACTware FDT frame application

- ▶ Launch PACTware.
- ▶ Right-click **HOST PC** → **Add device**.




Fig. 154: Adding a device in PACTware

- ▶ Select **BL Service Ethernet** and confirm with **OK**.




Fig. 155: Selecting the Ethernet interface

- ▶ Double-click the connected device.
- ⇒ PACTware opens the bus address management.




Fig. 156: Opening Bus Address Management

- ▶ Search for connected Ethernet devices: Click the **Search** icon.
- ▶ Select the required device.




Fig. 157: Selecting the device

- ▶ Click **Firmware Download** to start the firmware update.




Fig. 158: Starting the firmware update

- ▶ Select BL Service Ethernet and confirm with **OK**.
- ⇒ PACTware shows the progress of the firmware update with a green bar at the bottom of the screen.




Fig. 159: Firmware update in progress

## 12 Repair

The device must not be repaired by the user. The device must be decommissioned if it is faulty. Observe our return acceptance conditions when returning the device to Turck.

### 12.1 Returning devices

Returns to Turck can only be accepted if the device has been equipped with a Decontamination declaration enclosed. The decontamination declaration can be downloaded from <https://www.turck.de/en/retoure-service-6079.php> and must be completely filled in, and affixed securely and weather-proof to the outside of the packaging.

## 13 Disposal



The devices must be disposed of correctly and must not be included in general household garbage.



## 14 Technical Data

<b>Technical Data</b>	
<b>Electrical data</b>	
Operating voltage	18...30 VDC
DC rated operational current	≤ 1000 mA
Data transmission	Electromagnetic AC field
Wireless communication and protocol standards	ISO 18000-6C EN 302208 EPCglobal Gen 2
Antenna polarization	Circular/linear, adjustable
Antenna half power beam width	65°
Output function	Read/write
<b>Mechanical data</b>	
Mounting condition	Non-flush
Ambient temperature	-20...+50 °C
Dimensions	300 × 300 × 61.7 mm
Housing material	Aluminum, AL, silver
Material of active face	Fiber glass reinforced polyamide, PA6-GF30, black
Vibration resistance	55 Hz (1 mm)
Shock resistance	30 g (11 ms)
Type of protection	IP67
No. of channels	4
Electrical connection	RP-TNC
Input impedance	50 Ω
<b>System description</b>	
Processor	ARM Cortex A8, 32-bit, 800 MHz
ROM memory	256 MB Flash
RAM memory	512 MB DDR3
Programming	CODESYS V3
Released for CODESYS version	V3.5.11.20
Programming languages	IEC 61131-3 (IL, LD, FBD, SFC, ST)
Application tasks	10
Number of POUs	1024
Programming interface	Ethernet
Cycle time	< 1 ms for 1000 IL commands (without I/O cycles)
Input data	8
Output data	8
RFID data interface	UHF

<b>Technical Data</b>	
<b>System data</b>	
Ethernet transfer rate	10 Mbit/s / 100 Mbit/s
Ethernet connection technology	1 × M12, 4-pin, D-coded
Web server	Default: 192.168.1.254
<b>Modbus TCP</b>	
Addressing	Static IP, BOOTP, DHCP
Supported function codes	FC1, FC2, FC3, FC4, FC5, FC6, FC15, FC16, FC23
Number of TCP connections	8
Number of output data (PAA)	Max. 1024
Number of input data (PAE)	Max. 1024
<b>EtherNet/IP</b>	
Addressing	As per EtherNet/IP specification
Device level ring (DLR)	Supported
Input assembly instance	103
Number of input data (PAE)	248
Output assembly instance	104
Number of output data (PAA)	248
Class1 connections	10
Class3 connections	3
Configuration assembly instance	106
<b>PROFINET</b>	
Addressing	DCP
MinCycleTime	4ms
Diagnostics	According to PROFINET Alarm Handling
Automatic addressing	Supported
Media redundancy protocol (MRP)	Supported
Number of input data (PAE)	Max. 512
Number of output data (PAA)	Max. 512
<b>Digital inputs</b>	
No. of channels	2
Connection technology of inputs	M12, 5-pin
Input type	PNP
Switch threshold	EN 61131-2 Type 3, PNP
Signal voltage Low signal	< 5 V
Signal voltage High signal	> 11 V
Signal current Low signal	<1.5 mA
Signal current High signal	> 2 mA
Type of input diagnostics	Channel diagnostics
<b>Digital outputs</b>	
No. of channels	2
Connection technology of outputs	M12, 5-pin
Output type	PNP
Type of output diagnostics	Channel diagnostics

# 15 Appendix: Flow Charts Showing the Operation of the Device

The flow charts explain the operation of the device as well as the processing of commands.

## 15.1 Flow chart: Command processing




Fig. 160: Flow chart for command processing

## 15.2 Flow chart: Rapid command processing with loop counter




Fig. 161: Flow chart for fast command processing with loop counter

### 15.3 Flow chart: Command processing with fragmentation




Fig. 162: Flow chart for command processing with fragmentation

15.4 Flow chart: Continuous mode with interruption before reading data





Fig. 163: Flow chart for Continuous mode with interruption before reading data

15.5 Flow chart: Continuous mode without interruption before reading data



\*) After increasing the Read Fragment No., the new data will be shown in the read data input.

Fig. 164: Flow chart for Continuous mode without interruption before reading data

## 16 EU Declaration of Conformity

Hans Turck GmbH & Co. KG hereby declares that wireless system read/write heads of type TN-UHF-Q...L...-EU... comply with directive 2014/53/EU. The complete text of the EU declaration of conformity can be obtained from the following Internet address: [www.turck.com](http://www.turck.com)



# TURCK

Over 30 subsidiaries and over  
60 representations worldwide!

100003065 | 2020/12



[www.turck.com](http://www.turck.com)