

# VE Series Smart Camera

## Instruction Manual

Original Instructions  
191666 Rev. B  
31 October 2016  
© Banner Engineering Corp. All rights reserved



191666

# Contents

1	Product Description	6
1.1	Models	6
2	Overview	7
2.1	Features	7
2.1.1	Display	7
2.1.2	Indicators	7
2.1.3	Buttons	7
2.2	Vision Manager Software	8
3	Specifications and Requirements	9
3.1	Specifications	9
3.2	PC Requirements	9
3.3	Dimensions	10
3.4	Banner Engineering Corp. Software Copyright Notice	11
4	Installation Instructions	12
4.1	Install the Accessories	12
4.2	Mount the Sensor	12
4.3	Connect the Cables	12
4.3.1	Wiring Diagrams	13
4.4	Install the Software	15
5	Getting Started	16
5.1	Connect to the Sensor	16
5.2	Acquire a Good Image	16
5.3	Set Up an Inspection	17
5.3.1	Add a Tool	17
5.3.2	Rename a Tool	18
5.3.3	Name an Inspection	19
5.3.4	Save an Inspection to a Computer, Network Drive, or Storage Device	19
5.3.5	Modify a Currently Running Inspection	19
5.3.6	Copy a Tool	20
5.3.7	Delete a Tool	20
5.3.8	Delete a Tool and All Tools After It	20
5.3.9	Delete an Inspection	20
5.4	Configure the Discrete I/O	21
6	Vision Manager Workspace	22
6.1	Home Screen	22
6.1.1	Sensor Neighborhood	22
6.1.2	Sensor Maintenance	24
6.1.3	Emulators	25
6.1.4	About	26
6.2	Sensor Screen	26
6.2.1	Image Pane Parameters	26
6.2.2	Summary Pane	27
6.2.3	Tools & Results	28
6.2.4	Tools Only	28
6.2.5	All Results	29
6.3	Inspection Logs Screen	30
6.3.1	Log Sources	30
6.3.2	Loaded Logs	31
6.4	Inspection Management Screen	31
6.4.1	Manage	32
6.4.2	Transfer	33
6.5	System Settings Screen	34
6.5.1	Sensor Info	34
6.5.2	Discrete I/O	34
6.5.3	Communications	36
6.5.4	Logs	39
6.5.5	Units	41
6.5.6	System Reset	44
7	Using the Camera Tool	45
7.1	Imager	45
7.2	Trigger	46
7.3	Focus Information	47
7.4	External Strobe	47

7.5 Camera Tool: Results .....	48
<b>8 Using the Inspection Tools: Vision Tools .....</b>	<b>49</b>
8.1 Average Gray Tool .....	49
8.1.1 Average Gray Tool: Input Parameters .....	49
8.1.2 Average Gray Tool: Test Parameters .....	51
8.1.3 Average Gray Tool: Results .....	52
8.1.4 Using the Average Gray Tool .....	52
8.2 Bead Tool .....	53
8.2.1 Bead Tool: Input Parameters .....	53
8.2.2 Bead Tool: Test Parameters .....	58
8.2.3 Bead Tool: Results .....	58
8.2.4 Bead Tool: Adjust the ROI .....	59
8.2.5 Using the Bead Tool .....	61
8.3 Blemish Tool .....	63
8.3.1 Blemish Tool: Input Parameters .....	64
8.3.2 Blemish Tool: Test Parameters .....	66
8.3.3 Blemish Tool: Results .....	67
8.3.4 Using the Blemish Tool .....	67
8.4 Blob Tool .....	68
8.4.1 Blob Tool: Input Parameters .....	68
8.4.2 Blob Tool: Test Parameters .....	72
8.4.3 Blob Tool: Results .....	73
8.4.4 Using the Blob Tool .....	76
8.5 Edge Tool .....	79
8.5.1 Edge Tool: Input Parameters .....	79
8.5.2 Edge Tool: Test Parameters .....	85
8.5.3 Edge Tool: Results .....	85
8.5.4 Using the Edge and Measure Tools .....	86
8.6 Locate Tool .....	87
8.6.1 Locate Tool: Input Parameters .....	88
8.6.2 Locate Tool: Test Parameters .....	94
8.6.3 Locate Tool: Results .....	94
8.6.4 Using the Locate Tool .....	95
8.7 Match Tool .....	98
8.7.1 Match Tool: Input Parameters .....	98
8.7.2 Match Tool: Test Parameters .....	102
8.7.3 Match Tool: Results .....	103
8.7.4 Using the Match Tool .....	104
8.7.5 Using Remote TEACH with the Match Tool .....	106
8.8 Object Tool .....	106
8.8.1 Object Tool: Input Parameters .....	106
8.8.2 Object Tool: Test Parameters .....	112
8.8.3 Object Tool: Results .....	112
8.8.4 Using the Object Tool .....	113
<b>9 Using the Inspection Tools: Analysis Tools .....</b>	<b>115</b>
9.1 Math Tool .....	115
9.1.1 Math Tool: Input Parameters .....	115
9.1.2 Math Tool: Test Parameters .....	117
9.1.3 Math Tool: Results .....	117
9.1.4 Using the Math Tool .....	118
9.2 Measure Tool .....	119
9.2.1 Measure Tool: Operations .....	119
9.2.2 Measure Tool: Input Parameters .....	120
9.2.3 Measure Tool: Test Parameters .....	122
9.2.4 Measure Tool: Results .....	122
9.2.5 Using the Edge and Measure Tools .....	123
9.3 Logic Tool .....	125
9.3.1 Logic Tool: Input Parameters .....	125
9.3.2 Logic Tool: Test Parameters .....	127
9.3.3 Logic Tool: Results .....	127
9.3.4 Using the Logic Tool .....	127
<b>10 Emulators .....</b>	<b>130</b>
10.1 Backup or Restore the Emulator .....	130
<b>11 Sensor Display .....</b>	<b>131</b>
11.1 Sensor Display Interface .....	131
11.2 Locking and Unlocking the Sensor .....	131
11.3 Sensor Menu .....	132
11.4 Ethernet Menu (ETHER) .....	133
11.5 Product Change Menu (PCHANGE) .....	133
11.6 Input/Output Menu (IO) .....	133

11.7	Image Menu (IMAGE)	133
11.8	Information Menu (INFO)	133
11.9	System Error Menu (SYSERR)	134
11.10	Display Menu (DISPLAY)	134
11.11	Reboot Menu (REBOOT)	134
12	Communications Guide	135
12.1	Communication Summary	135
12.1.1	Communication Channels	135
12.1.2	Industrial Ethernet	135
12.1.3	Image Export	135
12.2	Enabling Communications	136
12.2.1	Setting Up Ethernet Communications	136
12.2.2	Windows 7	136
12.2.3	Communications Channel Ports	137
13	Industrial Ethernet Overview	138
13.1	Industrial Ethernet Setup	138
13.1.1	Set the Industrial Ethernet Protocol (EtherNet/IP, PROFINET®, Modbus/TCP, PCCC)	138
13.1.2	Set the Trigger Mode	138
13.2	Supported Functions	138
13.2.1	Sensor Input Values	139
13.2.2	Sensor Output Values	139
13.3	EtherNet/IP	139
13.3.1	Inputs to the Sensor (Outputs from the PLC)	142
13.3.2	Outputs from the Sensor (Inputs to the PLC)	143
13.3.3	Input and Output Bits	144
13.3.4	Sensor Pass/Fail Bits	144
13.3.5	Tool-Specific Results: EtherNet/IP	144
13.3.6	Configuration Assembly Object	146
13.3.7	Data Formats	146
13.3.8	Minimum Requested Packet Interval (RPI) Value	146
13.3.9	VE Series Smart Camera EDS File Installation in ControlLogix Software	146
13.3.10	RSLogix5000 Configuration	152
13.4	Modbus/TCP	158
13.4.1	Sensor Input Values	163
13.4.2	Sensor Output Values	164
13.4.3	Input and Output Bits	164
13.4.4	Sensor Pass/Fail Bits	165
13.4.5	Tool-Specific Results: Modbus/TCP	165
13.5	PLC5 and SLC 5 (PCCC)	166
13.5.1	Configuration	169
13.5.2	Inputs to the Sensor (Outputs from the PLC)	173
13.5.3	Outputs from the Sensor (Inputs to the PLC)	173
13.5.4	Input and Output Bits	174
13.5.5	Sensor Pass/Fail Bits	174
13.5.6	Tool-Specific Results: PCCC	174
13.6	PROFINET	176
13.6.1	General Station Description (GSD) File	176
13.6.2	VE Series camera PROFINET IO Data Model	176
13.6.3	Configure the VE Series Smart Camera for a PROFINET IO Connection	176
13.6.4	Description of Modules and Submodules	177
13.6.5	Description of Submodules	178
13.6.6	Configuration Instructions	184
13.7	Troubleshooting	194
13.7.1	Industrial Ethernet Error Codes	194
13.7.2	PROFINET	194
14	Troubleshooting	197
14.1	Vision Manager Error Codes	197
15	Accessories	208
15.1	Cordsets	208
15.2	Brackets	208
15.3	Lenses	209
15.3.1	WVGA Lens Working Distance and Field of View	209
15.3.2	1.3 MP Lens Working Distance and Field of View	210
15.3.3	2 MP Lens Working Distance and Field of View	210
15.4	C-Mount Lens Filter Models	211
15.5	Lens Cover	211
15.6	Display Cover	212
15.7	Ring Lights	212
15.8	Interface Module	212
15.9	Product CD	213

16 Product Support and Maintenance .....	214
16.1 Repairs .....	214
16.2 Maintenance .....	214
16.2.1 Clean the Sensor .....	214
16.2.2 Clean the Lens .....	214
16.2.3 Update the Software and Firmware .....	214
16.3 Contact Us .....	214
16.4 Banner Engineering Corp Limited Warranty .....	215

# 1 Product Description

*Self-contained Smart Camera with User-Friendly Vision Manager Software*



- Banner's free and easy-to-use Vision Manager Software provides a number of tools and capabilities that enable VE Series smart cameras to solve a wide range of vision applications, such as item detection, part positioning, feature measurement and flaw analysis
- Runtime editing capability reduces costly downtime and the software emulator allows for offline building and troubleshooting of applications
- Factory communications (EtherNet IP, Modbus, and PROFINET) for integration on the manufacturing floor
- Six optically isolated I/O and an external light connector on the smart camera
- Two-line, eight-character onboard display provides smart camera information and focus number and makes it easy to update the smart camera settings, facilitating fast product changeover
- Robust metal housing with optional lens covers to achieve IP67 rating for use in harsh environments with heat, vibration, or moisture
- Bright indicator lights for easy viewing of smart camera status



**WARNING: Not To Be Used for Personnel Protection**

Never use this device as a sensing device for personnel protection. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.



**CAUTION: Electrostatic Discharge**

Avoid the damage that electrostatic discharge (ESD) can cause to the Sensor.

Always use a proven method for preventing electrostatic discharge when installing a lens or attaching a cable.



**CAUTION: Hot Surface**

Use caution when handling the camera. The surface of the camera may be hot during operation and immediately after use.

## 1.1 Models

Model <sup>1</sup>	Resolution
VE200G1A	WVGA, 752 × 480 pixels grayscale
VE201G1A	1.3 MP, 1280 × 1024 pixels grayscale
VE202G1A	2 MP, 1600 × 1200 pixels grayscale

<sup>1</sup> Model VE202G2A, 2 MP, 1600 × 1200 grayscale with 4-pin D-code M12 Ethernet connection is also available.

## 2 Overview

The VE Series Smart Camera is easy to use and has advanced visual inspection capabilities for automation or control applications. Users can quickly set up the sensor using the Vision Manager software to solve a diverse range of applications on the factory floor.

### 2.1 Features



Figure 1. Sensor Features

1. Display
2. Buttons
3. Pass/Fail indicator (green/red)
4. Ready/Trigger indicator (green/amber)
5. Power/Error indicator (green/red)
6. Ethernet indicator (amber), not shown
7. Ethernet connection
8. Light connection
9. Power, Discrete I/O connection

#### 2.1.1 Display



Figure 2. Display with Home Screen

The display is a 2-line, 8-character LCD. The main screen is the Home Screen, which shows the name of the current inspection and the slot number (inspection location). Use the display to view or change several sensor settings.

#### 2.1.2 Indicators

Four LED indicators provide ongoing indication of the sensing status.



- ! Power/Error Indicator
  - Green = Normal operation
  - Red = System error



- Ready/Trigger Indicator
  - Green = Ready for trigger
  - Yellow = Trigger is active
  - OFF = Not ready for a trigger, triggers will be missed



- ✘ Pass/Fail Indicator
  - Green = Previous inspection passed
  - Red = Previous inspection failed
  - OFF = No trigger since power up



- Ethernet Indicator
  - Amber solid = Ethernet connection
  - Amber flashing = Ethernet activity
  - OFF = no connection

#### 2.1.3 Buttons

Use the sensor buttons Down , Up , Enter , and Escape  to configure several sensor settings and to access sensor information. See [Figure 257](#) on page 132 for additional information on using the buttons.

## 2.2 Vision Manager Software

---

The VE Series Smart Camera is set up using the free Vision Manager Software, available for download at [www.bannerengineering.com](http://www.bannerengineering.com).

This easy-to-use image processing software provides a variety of tools and capabilities to solve a wide range of vision applications such as item detection, part positioning, feature measurement and flaw analysis. Run-time editing allows you to make changes to an inspection while the sensor is running, reducing costly downtime. Vision Manager also includes a full software emulator, allowing users to develop or troubleshoot inspections offline, without a sensor.

## 3 Specifications and Requirements

### 3.1 Specifications

#### Power

12 V dc to 30 V dc (24 V dc  $\pm$  10% if a Banner light source is powered by the sensor)  
 Current: 400 mA maximum (exclusive of load and lights)  
 Use only with a suitable Class 2 power supply, or current limiting power supply rated 12 V to 30 V dc, 1 A

#### Supply Protection Circuitry

Protected against reverse polarity and transient overvoltages

#### Discrete I/O

1 Trigger IN  
 5 Programmable I/O

#### Output Configuration

Optically isolated

#### Output Rating

Output Resistance: < 2  $\Omega$   
 Strobe Output Resistance: < 13  $\Omega$   
 Programmable Output: 100 mA  
 External Strobe Output: 100 mA  
 Off-State Leakage Current: < 100  $\mu$ A

#### External Light Maximum Current Draw

600 mA

#### Exposure Time

0.02 ms to 500 ms

#### Imager

VE200G1A: 6.9 mm  $\times$  5.5 mm, 8.7 mm diagonal (1/1.8-inch CMOS)  
 VE201G1A: 6.9 mm  $\times$  5.5 mm, 8.7 mm diagonal (1/1.8-inch CMOS)  
 VE202G1A: 7.2 mm  $\times$  5.4 mm, 9.0 mm diagonal (1/1.8-inch CMOS)  
 VE202G2A: 7.2 mm  $\times$  5.4 mm, 9.0 mm diagonal (1/1.8-inch CMOS)

#### Lens

C-mount

#### Pixel Size

VE200G1A: 5.3  $\mu$ m  
 VE201G1A: 5.3  $\mu$ m  
 VE202G1A: 4.5  $\mu$ m  
 VE202G2A: 4.5  $\mu$ m

#### Communication

10/100/1000<sup>2</sup> Mbps Ethernet

#### Memory

Device Settings and Inspection Storage Memory: 500 MB  
 Number of inspection files: 999

#### Acquisition

256 grayscale levels

Model	Frames Per Second <sup>3</sup>	Image Size
VE200G1A	60 fps, maximum	752 $\times$ 480 px
VE201G1A	60 fps, maximum	1280 $\times$ 1024 px
VE202G1A	50 fps, maximum	1600 $\times$ 1200 px
VE202G2A	50 fps, maximum	1600 $\times$ 1200 px

#### Torque—Tapped Holes for Mounting Screws

8 lbf-in (0.9 N-m) maximum torque

#### Construction

Housing: Aluminum  
 Display Label: Polyester

#### Connections

Ethernet: M12, 8-pin or 4-pin D-code Euro-style female  
 Light Connector: M8, 3-pin Pico-style female  
 Power, Discrete I/O: M12, 12-pin Euro-style male

#### Environmental Rating

IEC IP67 with an optional lens cover properly installed

#### Operating Conditions

Operating Temperature: 0  $^{\circ}$ C to +50  $^{\circ}$ C (+32  $^{\circ}$ F to +122  $^{\circ}$ F)  
 95% maximum relative humidity (non-condensing)  
 Stable Ambient Lighting: No large, quick changes in light level; no direct or reflected sunlight  
 Storage Temperature: -30  $^{\circ}$ C to +70  $^{\circ}$ C (-22  $^{\circ}$ F to +158  $^{\circ}$ F)

#### Vibration and Mechanical Shock

Meets EN 60947-5-2: 30 G Shock per IEC 60068-2-27; 1 mm amplitude from 10 - 60 Hz per IEC 60068-2-6

#### Certifications



Information  
 Technology  
 Equipment  
 E365235



### 3.2 PC Requirements

#### Operating System

Microsoft<sup>®</sup> Windows<sup>®</sup> operating system version 7, 8, or 10<sup>4</sup>

#### System Type

32-bit, 64-bit

#### Hard Drive Space

80 MB (plus up to 280 MB for Microsoft .NET 4.5, if not already installed)

#### Memory (RAM)

512 MB minimum, 1 GB+ recommended

#### Processor

1 GHz minimum, 2 GHz+ recommended

#### Screen Resolution

1024  $\times$  768 full color minimum, 1650  $\times$  1050 full color recommended

#### Third-Party Software

Microsoft .NET 4.5, PDF Viewer (such as Adobe Acrobat)

#### USB Port

USB 3.0, recommended if a USB to Ethernet adapter used to communicate with the sensor



**Important:** Administrative rights are required to install the Vision Manager software.


<sup>2</sup> 1000 Mbps communication speed not available on 4-pin Ethernet models

<sup>3</sup> This value can vary based on inspection settings.

<sup>4</sup> Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

### 3.3 Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.



## 3.4 Banner Engineering Corp. Software Copyright Notice

---

This software is protected by copyright, trade secret, and other intellectual property laws. You are only granted the right to use the software and only for the purposes described by Banner. Banner reserves all other rights in this software. For so long as you have obtained an authorized copy of this software directly from Banner, Banner grants you a limited, nonexclusive, nontransferable right and license to use this software.

You agree not to use, nor permit any third party to use, this software or content in a manner that violates any applicable law, regulation or terms of use under this Agreement. You agree that you will not reproduce, modify, copy, deconstruct, sell, trade or resell this software or make it available to any file-sharing or application hosting service.

**Disclaimer of Warranties.** Your use of this software is entirely at your own risk, except as described in this agreement. This software is provided "AS-IS." To the maximum extent permitted by applicable law, Banner, its affiliates, and its channel partners disclaim all warranties, expressed or implied, including any warranty that the software is fit for a particular purpose, title, merchantability, data loss, non-interference with or non-infringement of any intellectual property rights, or the accuracy, reliability, quality or content in or linked to the services. Banner and its affiliates and channel partners do not warrant that the services are secure, free from bugs, viruses, interruption, errors, theft or destruction. If the exclusions for implied warranties do not apply to you, any implied warranties are limited to 60 days from the date of first use of this software.

**Limitation of Liability and Indemnity.** Banner, its affiliates and channel partners are not liable for indirect, special, incidental, punitive or consequential damages, damages relating to corruption, security, loss or theft of data, viruses, spyware, loss of business, revenue, profits, or investment, or use of software or hardware that does not meet Banner minimum systems requirements. The above limitations apply even if Banner and its affiliates and channel partners have been advised of the possibility of such damages. This Agreement sets forth the entire liability of Banner, its affiliates and your exclusive remedy with respect to the software use. You agree to indemnify and hold Banner and its affiliates and channel partners harmless from any and all claims, liability and expenses, including reasonable attorney's fees and costs, arising out of your use of the Services or breach of this Agreement (collectively referred to as "Claims"). Banner reserves the right at its sole discretion and at its own expense, to assume the exclusive defense and control of any Claims. You agree to reasonably cooperate as requested by Banner in defense of any Claims.

## 4 Installation Instructions

### 4.1 Install the Accessories




Figure 3. Install the Accessories

1. VE sensor
2. O-ring (used with the lens cover)
3. C-mount lens (available separately)
4. Filter (optional)
5. Lens cover (optional)

An external light (optional) is not shown.



NOTE: A lens cover and a ring light cannot be used together.

1. If you are using a lens cover: Remove the black thread protector (not shown) from the sensor (1).
2. If you are using a lens cover: Fit a single o-ring (2) into the undercut area behind the sensor threads.
3. Remove the yellow temporary imager cover (not shown) from the sensor.



CAUTION: Do not remove the imager cover until you are ready to install the lens. Do not touch the imager. Dirt or dust on the imager can affect sensing reliability.

4. Remove any protective covers from the lens. Handle the lens carefully to avoid smudges and dirt on the optical elements.
5. Thread the lens (3) onto the sensor.
6. Make sure that the lens is focused; see [Acquire a Good Image](#) on page 16.
7. Use the thumbscrews on the lens to lock the focus and aperture rings and to prevent movement that can occur during cleaning or accidental contact.
8. If you are using a filter: Thread the filter (4) onto the front of the C-mount lens.
9. If you are using a linear polarization filter: Rotate the outer portion of the filter mount to determine the position where glare is reduced the most, and use the locking thumbscrew to fasten the filter in position.
10. If you are using a lens cover: Thread the lens cover (5) onto the threaded portion of the sensor.
11. Or, if you are using an external light bracket: Attach an external light bracket to the sensor using the provided hardware kit.



NOTE: For optimal imaging, provide adequate dissipation of heat. A good heat conductor, such as aluminum, may be required.

### 4.2 Mount the Sensor

1. If a bracket is needed, mount the sensor onto the bracket.
2. Mount the sensor (or the sensor and the bracket) to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.
3. Check the sensor alignment.
4. Tighten the mounting screws to secure the sensor (or the sensor and the bracket) in the aligned position.

### 4.3 Connect the Cables




Figure 4. Cable Connections

1. Power, Discrete I/O connection
2. Light connection
3. Ethernet connection
4. Ethernet indicator

1. Connect the Ethernet cable to the sensor (3) and to the computer or Ethernet switch.
2. Connect the power, discrete I/O cable to the sensor (1), and the leads to the appropriate locations. See [Table 1](#) on page 13 for the power, discrete I/O connections.

3. Connect the external light cable (optional) to the light connection (2) if the light is powered by the sensor.



**CAUTION: Use Appropriate Power**  
 If the light is powered by the sensor, the sensor power source must be 24 V dc. This connection is for Banner lights only.

Table 1: Power and I/O Pinouts

Pin	Wire Color	Description	Direction
1	White	Discrete I/O #3	Input/Output
2	Brown	12 V dc to 30 V dc	Input
3	Green	I/O output common   Important: For PNP (sourcing) outputs connect pin 3 to +V dc, for NPN (sinking) outputs connect pin 3 to 0 V dc. The discrete I/O pins are 1, 5, 8, 10, and 11.	-
4	Yellow	Reserved	-
5	Gray	Discrete I/O #5	Input/Output
6	Pink	Trigger input	Input
7	Blue	Common	Input
8	Red	Discrete I/O #2	Input/Output
9	Orange	I/O input common   Important: For PNP (sourcing) inputs connect pin 9 to 0 V dc, for NPN (sinking) inputs connect pin 9 to +V dc. The discrete I/O pins are 1, 5, 6, 8, 10, and 11.	-
10	Light Blue	Discrete I/O #4	Input/Output
11	Black	Discrete I/O #1	Input/Output
12	Violet	Reserved	-
Shield	Bare metal	Chassis ground	-

### 4.3.1 Wiring Diagrams




Figure 5. PNP Output




Figure 6. NPN Output




Figure 7. PNP Input




Figure 8. NPN Input





## 5 Getting Started

Power up the sensor, and verify that the  power/error LED is ON green and that the Ethernet indicator is ON amber to verify the Ethernet connection.

### 5.1 Connect to the Sensor

These instructions use Windows® operating system version 7, 8, or 10.<sup>5</sup>

1. Confirm the network connections.
  - a) Click the Start button, then on the Start menu, click Control Panel.
  - b) In Control Panel, click Network and Internet, then click Network and Sharing Center, and then click Change adapter settings.
  - c) Right-click on the connection that you want to change, then click Properties.  
If you are prompted for an administrator password or confirmation, enter the password or provide confirmation.
  - d) In the connection properties, click Internet Protocol Version 4 (TCP/IPv4), and then click Properties.




Figure 11. Local Area Connection Properties

- e) In the Internet Protocol (TCP/IPv4) Properties, select Use the following IP address.
- f) Make sure that the IP address is 192.168.0.2, and the subnet mask is 255.255.255.0.
2. Open Vision Manager from the desktop or the Start menu.  
The Sensor Neighborhood tab displays and lists the available sensors.
3. From Sensor Neighborhood, click  to connect to the desired sensor.  
The status changes from Available  to Connected  and the  Sensor screen displays. Click  to disconnect from the sensor.
4. If the desired sensor is not listed, verify that:
  - The network adapter connected to the sensor has the same subnet mask as the sensor (for example, 192.168.0.xxx); view the subnet mask in the Network Adapters list at  Home > Sensor Neighborhood > Network Adapters
  - The Ethernet cable is the correct type
  - The TCP/IPv4 settings are correct
 Or, manually enter the sensor's IP address.



NOTE: The sensor's IP address and subnet mask are also available from the sensor display.

### 5.2 Acquire a Good Image

The sensor needs to capture a good image of each part to ensure that it correctly passes good parts and fails bad parts.

<sup>5</sup> Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries.

1. Make sure that the lighting is appropriate for your target. Use supplementary lighting, such as a ring light, if necessary.
2. Click the  Sensor screen.
3. Click the  camera tool on Tools and Results.  
The Inputs parameters display.
4. Set the trigger.
  - a) Expand the Trigger parameters.
  - b) In the Trigger Mode list, click Internal (continuous images).
5. Run Auto Exposure.
  - a) Expand the Imager parameters.
  - b) Expand the Auto Exposure parameters, and click Start to run.
6. Check the lighting on the part.
  - Make sure that the lighting is constant and consistent (unchanging over time, no shadows or hot spots).
  - Capture the shape and form of the target object with lighting that optimizes its contrast and separates the feature of interest from the background. Depending on the target, consider other Banner lights.
  - Adjust the mounting angle to provide the clearest image of the part features you are inspecting.
7. After checking and adjusting the lighting, run Auto Exposure a second time or adjust the exposure manually by expanding the Exposure parameters and moving the slider or entering a specific exposure time.
8. Adjust the focus.
  - a) Place the part so that the area to be focused appears in the center of the Image pane.
  - b) Expand the Focus Info parameters.
  - c) Make sure that the Focus Info checkbox is selected.
  - d) Adjust the focus of the lens while monitoring the focus number.

The focus number is a number between 1 and 255. Use the Image pane to determine when the image is sharp enough, or use the focus number as a guide. Turn the focus ring on the lens until the focus number is at the highest possible number between 1 and 255. The focus number is also available on the sensor display.



NOTE: There is no optimal value for this number, but it can be used as a guide if you are setting up more than one sensor that are focused on the same target.

- e) Tighten the locking thumbscrews to secure the lens at the desired focus.

## 5.3 Set Up an Inspection

Vision Manager allows you to set up or make changes to an inspection while the sensor is running. Changes are automatically saved as they are made.

1. From the  Sensor screen, click  in the upper right corner to view the inspection list.
2. Click Add New Inspection.  
A new inspection is added to the list, the Image pane updates, and the Tools & Results tab shows only the camera tool.



NOTE: The camera tool for the new inspection inherits the parameters of the camera tool for the previous inspection, however the two are not linked together.

3. Add tools and adjust them as needed for the inspection.

### 5.3.1 Add a Tool

1. Click  on the Tools & Results tab.  
The Add Tool window opens.

- Click the desired tool.

Tool Name	Description
 Average Gray	Evaluates pixel brightness within an ROI and computes the average grayscale value. See <a href="#">Average Gray Tool</a> on page 49.
 Bead	Inspects parts for uniformity of adhesive or sealant material, or for uniformity of a gap. See <a href="#">Bead Tool</a> on page 53.
 Blemish	Determines whether flaws are present on a part, or detects whether a feature exists on a part. See <a href="#">Blemish Tool</a> on page 63.
 Blob	Detects and counts/locates groups of connected light or dark pixels within the ROI and designates them as blobs (Binary Large Objects). After blobs are found, they can be characterized by size and shape. See <a href="#">Blob Tool</a> on page 68.
 Edge	Detects and counts transitions between bright and dark pixels (edges). Counts the total number of edges, and determines the position of each edge. See <a href="#">Edge Tool</a> on page 79.
 Locate	Finds the first edge on a part and compensates for translation and rotation of downstream tools (if selected). See <a href="#">Locate Tool</a> on page 87.
 Match	Verifies that a pattern, shape, or part in any orientation matches a reference pattern. Can also compensate for translation and rotation of downstream tools (if selected). See <a href="#">Match Tool</a> on page 98.
 Object	Detects the edges of dark and bright segments and locates their midpoints. Counts dark and bright segments, and measures the width of each dark and bright segment. See <a href="#">Object Tool</a> on page 106.
 Math	Performs mathematical operations using tool data or user-supplied constants. Includes basic arithmetic, inequality expressions, and statistical information. See <a href="#">Math Tool</a> on page 115.
 Measure	Measures distance, calculates angles, and creates points and lines for use as inputs to other tools. See <a href="#">Measure Tool</a> on page 119.
 Logic	Uses Boolean logic to combine or convert tool results, or to drive discrete outputs from tool results. Logic tool data can be used to evaluate the results of a single tool or multiple tools. See <a href="#">Logic Tool</a> on page 125.

The tool is added to Tools & Results and the region of interest (ROI) appears on the Image pane.

- Configure the tool as needed for your application.
  - Resize  and rotate  the ROI around the feature to be analyzed.
  - Define or view parameters for the tool on the Input tab, such as ROI shape, threshold, or view the histogram.
  - Define pass or fail criteria on the Test tab, such as the count, size, or match.

### 5.3.2 Rename a Tool

The default tool name is *tool01*, *tool02*, and so on, where the word *tool* is replaced by the appropriate name (for example, *Locate01*, *Edge02*, etc.).

- On Tools & Results or on Tools Only, click the tool to select it.
- Highlight the tool name.
- Enter the desired tool name.



NOTE: Spaces and special characters are not allowed in the tool name.

### 5.3.3 Name an Inspection

The default inspection name is *Inspection01*, *Inspection02*, and so on. Rename the inspection to something meaningful to the application.

1. Click  Inspection Management, then click Manage.




Figure 12. Manage

2. Double-click the name of the desired inspection.
3. Enter the new inspection name.



NOTE: Special characters are not allowed in the inspection name.

4. Press Enter or click off of the name to save the new name.

### 5.3.4 Save an Inspection to a Computer, Network Drive, or Storage Device

Vision Manager automatically saves inspections to the VE as they are created and modified. Save a copy of the inspection to your computer or another network location if you want to be able to go back to previous settings.

Use the following procedure to save a copy of an inspection to your computer or a network location.

1. On the  Inspection Management screen, click Transfer.




Figure 13. Transfer

2. Change the destination folder, if desired.
  - a) Click  above the right column. An explorer window opens.
  - b) Navigate to the desired location, network location, or storage device.
  - c) Click Select Folder. The folder is selected and the window closes. The path to the location displays above the right column.
3. Select the desired inspection from the inspection list in the left column.
4. Click . *Inspection name.idb* displays in the right column and the inspection is transferred (saved) to the selected location.

### 5.3.5 Modify a Currently Running Inspection

1. On the  Sensor screen, select the desired inspection from the Inspection list. The inspection tools and parameters display.

2. Make the desired modifications to the inspection.



Important: Changes are automatically saved as they are made. Save a copy of the inspection if you want to be able to go back to previous settings. Use the Emulator to set up or make changes to an inspection offline.

### 5.3.6 Copy a Tool

Duplicate (copy) a tool to include more than one of the same tool in an inspection.

1. Click the desired tool to duplicate.
2. Click .  
A duplicate of the tool is created with the same input and test parameters.
3. Set the tool parameters as desired. The two tools are not linked; changes are independent of each other.

### 5.3.7 Delete a Tool

Use the following procedure to delete a tool from an inspection.

1. Click the tool on Tools & Results or Tools Only to select it.
2. Click .  
The tool is deleted.



NOTE: There is no undo option. A deleted tool cannot be recovered.

### 5.3.8 Delete a Tool and All Tools After It

Use the following procedure to delete a selected tool and all of the tools after it.

1. Click the tool on Tools & Results or on Tools Only to select it.
2. Click .  
The message "Remove selected tool and all tools after it?" displays.
3. Click Continue.  
The tools are deleted.



NOTE: There is no undo option. Deleted tools cannot be recovered.

### 5.3.9 Delete an Inspection

1. Click Inspection Management, then click Manage.
2. Select the inspection to be deleted.



NOTE: This inspection cannot be running and it cannot be selected to begin at startup.

3. Click .  
The inspection name turns red and "Inspection marked for deletion" displays.




Figure 14. Inspection Marked for Deletion

4. Click to another tab to delete the inspection, or click Undo to keep the inspection.

## 5.4 Configure the Discrete I/O

From the  System Settings screen, select Discrete I/O to change the discrete I/O settings.




Figure 15. Discrete I/O

For more details, see [Discrete I/O](#) on page 34.






Figure 17. Active Sensors Tab

To connect to a sensor, click next to the desired sensor. To disconnect from a sensor, click .

To view or change sensor Status, MAC Address, Sensor Name, IP Address, Subnet Mask, and Gateway, click .

To add the sensor to a Favorites Group, click . The icon changes to .

To manually connect to a sensor with a known IP address, enter the IP address in the Enter IP Address field and click .

### Favorites Tab

Save sensors to the Favorites tab for easy access to them. Sensors are saved to groups.

Navigate: Home > Sensor Neighborhood > Favorites.




Figure 18. Favorites Tab

Click Add New Group to create a new Favorites Group. To add a sensor to the group, on the Active Sensors tab, click or from the Favorites tab, enter the sensor IP address and click to verify the connection to the sensor and automatically save it to the selected group.

To manually add a sensor with a known IP address to the Favorites tab, enter the IP address in the Enter IP Address field and select the desired group.

To remove a sensor from a group, click the across from the sensor name. To move the sensor to another group, click the and select the desired group.

To remove a group and all the sensors within the group, click the across from the group name.

## Network Adapters Tab

Use the Network Adapters tab on Sensor Neighborhood to view the network adapters that the system searches to find sensors.

Navigate: Home > Sensor Neighborhood > Network Adapters.

Link Status	Adapter	IP Address	Subnet Mask
Connected	Realtek USB GBE Family Controller	192.168.0.3	255.255.255.0
Not Connected	Intel(R) Dual Band Wireless-N 7260	169.254.145.8	255.255.0.0
Connected	Intel(R) Ethernet Connection I217-V	10.10.30.152	255.255.254.0

Figure 19. Network Adapters Tab

Network adapter information including Link Status (connected/not connected), Adapter name, IP Address, and Subnet Mask is also available.

## 6.1.2 Sensor Maintenance

Use Sensor Maintenance on the Home screen to update the firmware on a sensor and to backup or restore the sensor.

Actions	Status	Sensor Name	IP Address	MAC Address	Model	Firmware Version	Favorites
	Available	VE202G1A Sensor 1	192.168.1.45	00:23:d9:00:79:d8	VE202G1A	0.1.1.BETA_2	
	Available	VE202G1A Sensor 2	192.168.1.44	00:23:d9:00:79:de	VE202G1A	0.1.1.BETA_2	
	Available	VE202G1A Sensor 3	192.168.1.41	00:23:d9:02:00:67	VE202G1A	0.1.1.BETA_2	
	Connected	VE202G1A Sensor 4	192.168.0.111	00:23:d9:02:00:6f	VE202G1A	0.1.1.BETA_2	

Figure 20. Sensor Maintenance Tab

Sensor Maintenance includes sensor information such as sensor Status, Sensor Name, IP address, MAC address, Model number, Firmware Version, and which sensors are tagged as favorites.

Actions include update firmware , view or change some sensor settings , and backup or restore sensor data .

### Update the Firmware

1. From the Home screen, click Sensor Maintenance.
2. Make sure that the desired sensor is not connected to the Vision Manager software and that the status is Available.
3. Click next to the sensor and follow the prompts.



NOTE: During the firmware update process, there are options to restore the sensor to the factory default settings and to create a backup before updating the firmware.



Important: All stored inspections are deleted when factory default settings are restored. Ethernet settings and favorites lists are retained.

This process can take several minutes. Do not close the program or remove power from the sensor during the update process.

When the process is complete, the sensor restarts and the status returns to Available. Vision Manager displays the new firmware version in the Firmware Version column.

## Backup or Restore the Sensor

System settings and inspections can be backed up and restored. Firmware is not included in the backup or restore.

The backup file is saved to the location of your choice.

1. From the  Home screen, click Sensor Maintenance.
2. Make sure that no sensors or emulators are connected to the Vision Manager software and that the desired sensor's status is Available.
3. Click , then click Backup.
4. Follow the prompts to save a backup file.  
A message displays saying that the backup was successful.
5. To restore the sensor data, click , then click Restore.
6. Follow the prompts to restore the sensor data. An Emulator backup file can be used to restore the sensor.



NOTE: This process can take several minutes.

A message displays saying that the restore was successful.

## 6.1.3 Emulators

Use Emulators on the  Home screen to connect to the emulator.




Figure 21. Emulators

Click  to connect to the desired emulator. This tab also displays the Image location on the computer, as well as the emulator version information.

Click  under Image Location to change the directory for the reference images. The default directory for images is C: > Users > Public > Documents > Banner Vision Manager > VE Series > VE xMP > Images. Both 8-bit monochrome bitmap (BMP) images and inspection logs are supported. Bitmap images should be the same resolution as the VE camera. If inspection logs are placed in the Images directory, the emulator automatically extracts the image out of the inspection log and uses it to run the currently loaded inspection.

The Emulators tab includes all available features and all tools function the same as they do when running on a sensor. On the emulator, execution time is not calculated.

## Backup or Restore the Emulator

Emulator settings and inspections can be backed up and restored.

The backup file is saved to the location of your choice.

1. From the  Home screen, click Emulators.
2. Make sure that no sensors or emulators are connected to the Vision Manager software.
3. Click , then click Backup.
4. Follow the prompts to save a backup file.  
A message displays saying that the backup was successful.
5. To restore the sensor data, click , then click Restore.
6. Follow the prompts to restore the sensor data. A sensor backup file can be used to restore the emulator.



NOTE: This process can take several minutes.


A message displays saying that the restore was successful.

### 6.1.4 About

Use About to view Vision Manager software information, including the version number.

## 6.2 Sensor Screen

The  Sensor screen displays the information needed to create or modify an inspection.



1. Screens—Home, Sensor, Inspection Logs, Inspection Management, System Settings
2. Manual Trigger button—Click to manually trigger the sensor
3. Inspection list—Select the desired inspection to start, and to view or modify the inspection
4. Summary pane—Includes the Inspection Summary and the I/O Summary
5. Parameters pane—Includes user-adjustable Inputs parameters or Test parameters for the tools in an inspection, depending on what is selected in the Tools and Results pane
6. Tools and Results pane—Includes Tools and Results, Tools Only, and All Results, which display the camera tool, the tools that are included in the current inspection, and the results of the inspection
7. Image Pane Parameters panel—Includes ROI view buttons, zoom, x and y coordinates, grayscale value, and full image display button, as well as sensor messages
8. Image pane—Displays the current image captured by the sensor; this includes the region of interest (ROI) for the tool for the selected inspection

Figure 22. Sensor Screen

### 6.2.1 Image Pane Parameters

Use the Image Pane Parameters to change how the Image pane displays and to view status messages.




Figure 23. Image Pane Parameters

ROI View Buttons

- Click  to view all tool ROIs and annotations.
- Click  to view the ROI and annotations for the selected tool only.
- Click  to hide all ROIs annotations and view the image only.



NOTE: The Image Overlays parameter for each tool also control which ROI is shown and this parameter overrides the ROI view buttons.

Zoom

Slide to zoom the Image pane in and out.

Status Messages

View status messages such as "Applying Changes" and "Waiting for Trigger". Some messages, such as "Applying Changes," display only momentarily while a parameter change is serviced by the sensor. Other messages such as "Waiting for Trigger" require an action to be completed.

X and Y Coordinates and Grayscale Value

Displays the current x and y coordinates and grayscale value for the location the pointer is at in the Image pane.

Full Image Display Mode Button

Click  to expand the image to fill the screen. The image pane and impage pane parameters are the only items shown. Click  to return to the standard view.

### 6.2.2 Summary Pane

The Summary pane includes both the Inspection Summary and the I/O Summary.

When expanded, the Inspection Summary displays inspection pass, fail, and missed trigger statistics since the last time the inspection summary results were reset. A green checkmark indicates that an inspection passed, and a red X indicates that an inspection failed. A dash indicates that there is no information to display.




Figure 24. Inspection Summary

The History Trend below the pass/fail statistics provides another visual indication of whether or not an inspection passed, as well as an indication of when changes are made.

- Green indicates that an inspection passed
- Red indicates that an inspection failed
- Blue indicates that a change was made to the inspection
- Pink indicates that a product change was made—either a new inspection was added or the inspection was changed to a different one

The History Trend holds up to 400 entries and updates after an inspection is completed. The entries are recorded first in, first out, with the newest entry displayed on the left of the History Trend. Point to an entry on the History Trend for information about the entry. For example, pointing to a green entry displays the frame number.

Click Reset to clear the Inspection Summary statistics. The History Trend does not reset.

When collapsed, the Inspection Summary displays only pass and fail information. A green number on the left represents the number of inspections that passed. A red number on the right represents the number of inspections that failed since the last reset.

When expanded, the I/O Summary displays input and output status information and system errors, if present. When collapsed, no I/O Summary information is visible.




Figure 25. I/O Summary

Inputs and outputs display on the I/O Summary after they are configured from the System Settings screen (see [Configure the Discrete I/O](#) on page 21). Green indicates that the I/O is active. Light gray indicates that the I/O is inactive.

The System Error indicator flashes red when an error is present. View and clear the error from the System Settings screen (see [Logs](#) on page 39).




Figure 26. IO Summary with Error

### 6.2.3 Tools & Results

Tools & Results shows the camera tool and the inspection tools that are included in the current inspection, as well as the results for the currently selected tool.




Figure 27. Tools & Results

Use Tool & Results to add and configure tools in an inspection and to view results. Click a camera tool or inspection tool on Tools & Results to access the Parameters pane for that camera or tool.

See [Using the Camera Tool](#) on page 45, [Using the Inspection Tools: Vision Tools](#) on page 49, and [Using the Inspection Tools: Analysis Tools](#) on page 115 for additional tools information.

### 6.2.4 Tools Only

Tools Only shows the camera tool and the inspection tools that are included in the current inspection.




Figure 28. Tools Only

Use Tools Only to add and configure tools in an inspection. Click a camera tool or inspection tool on Tools Only to access the Parameters pane for that camera or tool.

See [Using the Camera Tool](#) on page 45, [Using the Inspection Tools: Vision Tools](#) on page 49, and [Using the Inspection Tools: Analysis Tools](#) on page 115 for additional tools information.

## 6.2.5 All Results

All Results lists the results for the current inspection, camera tool, and inspection tools.




Tools & Results		Result	Time	Pass Count	Fail Count
Tools Only	+ Inspection 05	Pass	719.20	15356	135
All Results	+ Camera01	Ok	47.51	89	0
	+ Match01	2	146.97	89	0
	+ Blemish01	145612	464.62	89	0
	+ Blemish01	116	60.02	89	0

Figure 29. All Results

At a glance, view the Result (pass/fail/status), execution Time (in milliseconds), Pass Count, and Fail Count for each item. Expand each item for additional details.

## 6.3 Inspection Logs Screen

The  Inspection Logs screen displays saved images and inspection information. Inspections logs can be viewed when the camera is offline.



1. Log Sources pane—Choose the source for the inspections logs to view, and set the criteria for collecting logs
2. Loaded Logs pane—View and filter the inspection logs
3. Image pane—Displays the saved inspection image captured by the sensor. This includes the tools that were used in that inspection
4. Summary pane—Displays saved information from a specific inspection and frame number
5. Parameters pane—Displays the logged Input or Test parameters, depending on what is selected in the Tools & Results pane
6. Tools and Results pane—Includes the Tools & Results tab, the Tools Only tab, and the All Results tab, which display the camera tool, the tools that are included in the logged frame, and the results of the inspection
7. Image Pane Parameters panel—Includes ROI view buttons, zoom, x and y coordinates, and grayscale value, as well as sensor messages

Figure 30. Inspection Logs Screen

### 6.3.1 Log Sources

View logs from either the sensor or a network folder or storage device.

Click  to move the inspection logs from the sensor to the computer. Click  to navigate to saved inspection logs. Thumbnail views of the images display in the Loaded Logs pane. While inspection logs are loading, the Percent Bar displays and shows the percentage of inspection logs that have loaded; it is removed when all inspection logs have finished loading.

Expand Sensor to set the criteria for what is collected in the inspection logs. Set the Log Criteria:

- All
- Pass Only
- Fail Only
- By Slot Number
- Remote Teach All

- Remote Teach Pass
- Remote Teach Fail

Set the Strategy:

- First N Logs
- Last N Logs

Set the Capture Limit (limits the number of inspection logs the sensor holds in internal memory):

- Low Count
- Medium Count
- High Count

Filter logs to be viewed by pass , fail , remote teach **RT**, or inspection number using the buttons to the left of the inspection previews. Click  to clear all filters.

### 6.3.2 Loaded Logs

After log information is loaded from the Log Sources pane, click on a thumbnail to view the full frame in the Image pane.

The Inspection Summary shows whether or not the inspection passed, which inspection was being used, and which frame number you are viewing. Click the camera tool or an inspection tool in the Tools and Results pane to view additional logged information in the Parameters pane, such as camera exposure, the reference pattern, or the filters used during the inspection, as well as to view specific results for the frame.



NOTE: Some parameters are disabled in the Inspection Logs. For example, if histogram information was not collected during the inspection, it cannot be viewed from the log.

## 6.4 Inspection Management Screen

The  Inspection Management screen includes options to add inspections to the currently connected sensor, to rename an inspection, and to transfer inspections between a connected sensor and a network location or storage device.

The following are available from the Inspection Management screen:

- Manage
- Transfer

The inspection CRC is listed for each inspection on both the Manage and Transfer screens. When an inspection is created, it is assigned a Cyclic Redundancy Check code, or CRC. The CRC is generated by considering each setting within the inspection (this includes the input parameters of all tools). When a change is made to the input parameters of any tool within the inspection, a new CRC is generated. Because of this, CRC becomes a very simple yet powerful way to determine if a change was made to the inspection since the last time it was modified.



NOTE: Changing an inspection's name and slot number does not modify its CRC.

## 6.4.1 Manage

Use Manage to add new inspections, delete existing inspections, rename inspections, set an inspection to run at startup, or copy an inspection.




Figure 31. Manage

Also displayed are the sensor name, inspection name, and whether the inspection is running.

### Copy an Inspection

Duplicate (copy) an inspection to use as a starting point for a new inspection.

1. On the Inspection Management screen, click Manage.
2. Locate the inspection to copy and click . A duplicate of the inspection is created with the same tools and parameters and is added to the inspection list as *Inspection (#)*.
3. Adjust the inspection as desired. The two inspections are not linked; changes are independent of each other.

### Delete an Inspection

1. Click Inspection Management, then click Manage.
2. Select the inspection to be deleted.



NOTE: This inspection cannot be running and it cannot be selected to begin at startup.

3. Click . The inspection name turns red and "Inspection marked for deletion" displays.




Figure 32. Inspection Marked for Deletion

4. Click to another tab to delete the inspection, or click Undo to keep the inspection.

## Set an Inspection to Begin at Startup



NOTE: Only one inspection can begin at startup.

1. On the Inspection Management screen, click Manage.
2. Locate the desired inspection and click .  
The turns green and the inspection will begin at the next startup.

## 6.4.2 Transfer

Use Transfer to transfer inspections between a connected sensor and a computer, network drive, or storage device.




Figure 33. Transfer

Click to navigate to and select a different folder. Click to open the folder to view the files.

## Save an Inspection to a Computer, Network Drive, or Storage Device

Vision Manager automatically saves inspections to the VE as they are created and modified. Save a copy of the inspection to your computer or another network location if you want to be able to go back to previous settings.

Use the following procedure to save a copy of an inspection to your computer or a network location.

1. On the Inspection Management screen, click Transfer.




Figure 34. Transfer

2. Change the destination folder, if desired.
  - a) Click above the right column.  
An explorer window opens.
  - b) Navigate to the desired location, network location, or storage device.
  - c) Click Select Folder.  
The folder is selected and the window closes.  
The path to the location displays above the right column.
3. Select the desired inspection from the inspection list in the left column.
4. Click .  
*Inspection name.idb* displays in the right column and the inspection is transferred (saved) to the selected location.

## Save Inspections to a VE Sensor

Inspections stored on a computer or network drive or created in the emulator can be saved to the connected VE sensor.

1. On the Inspection Management screen, click Transfer.

2. Select the desired location.
  - a) Click  above the right column.
  - b) Navigate to the desired folder.

The path to the location displays above the right column.
3. In the list on the left, select (Next Empty Slot) to add the inspection to the list or select an existing inspection to replace.
4. Select the desired inspection from the list on the right.
5. Click .  
*Inspection name* displays in the left column and the inspection is transferred to the sensor.

## 6.5 System Settings Screen

The  System Settings screen provides access to view and adjust sensor information, discrete I/O, communications settings, system logs, and units.

The following are available from the System Settings screen:

- Sensor Info
- Discrete I/O
- Communications
- Logs
- Units
- System Reset

### 6.5.1 Sensor Info

Use Sensor Info to view or change sensor information, including sensor name, IP address, subnet mask, and gateway.



Figure 35. Sensor Info

Click  to access the sensor properties editing window. Click  to refresh the information.

- Sensor Name—View or change the sensor name
- Model—View the model number of the sensor
- Serial Number—View the serial number of the sensor
- Firmware Version—View the current firmware version of the sensor
- Up Time—View the amount of time the sensor has been running since it was last powered on
- Hour Count—View the number of hours the sensor has been powered on over its lifetime
- Boot Count—View the number of times the sensor has been powered on over its lifetime

### 6.5.2 Discrete I/O

Use Discrete I/O to view the I/O and pin numbers; view the status; and set the function, active level, output delay, latch type, and output duration for each pin.

From the  System Settings screen, select Discrete I/O to change the discrete I/O settings.




Figure 36. Discrete I/O

### I/O

The VE has five configurable I/O. These are pins 1, 5, 8, 10, and 11.

### Pin #

The pin number on the cable connection. See [Table 1](#) on page 13.

### Wire Color

The corresponding wire color for each pin. See [Table 1](#) on page 13.

### Status

Indicates whether or not the I/O is active.

Green = active

Gray = inactive

### Function

The following input and output options are available:

- Disabled—The pin is not configured
- General Output—Used in conjunction with the Logic Tool to configure individual discrete outputs based on specific tool results.
- Pass—Active when the inspection passes.
- Fail—Active when the inspection fails
- Ready—Active when the sensor is ready to accept another trigger
- System Error—Active when a system error occurs
- Online—Active when the Camera is connected
- Missed Trigger—Active when a trigger is missed
- Product Change—The input is used in conjunction with one of the four I/O points programmed as Product Select lines. The inspection loaded will be executed following a valid trigger. See [Function: Product Change](#) on page 36 for additional details on Product Change
- Product Select Bit 0/1/2/3—Available when Product Change is selected on another I/O; used in conjunction with Product Change to select inspection locations at which to begin execution. See [Function: Product Change](#) on page 36
- Remote Teach—Sets the pin to accept input pulses for remote teaching the sensor

### Invert

Select to switch when the I/O is active or inactive.

### Output Delay (ms)

The time from when a trigger starts an inspection until the sensor output turns on. It is available for the General Output, Pass, Fail, and Missed Trigger functions of the selected pin.



**NOTE:** If the inspection execution time is longer than the output delay, the output becomes active immediately after the processing is finished.

### Latch Type

Select the behavior of the I/O pin when in active state; available when the I/O is configured as an output.

- Latched—Maintains state until the condition of the associated function changes; available for the following functions: General Output, Pass, Fail, Ready, System Error, Online, and Missed Trigger
- Pulsed—Maintains active state for a selected period of time, then returns to the inactive state; available for the following functions: General Output, Pass, Fail, System Error, and Missed Trigger
- Trigger Gated—Output signal is only active upon trigger signal being active

### Output Duration (ms)

The length of time the output is active.

This option is available for the Latch Type = Pulsed.

## Function: Product Change

The sensor can be commanded to load inspections from slots 1 to 15 using the combination of Product Change and Product Select functions of the discrete I/O pins.

Set the state of the Product Select pins as described in [Product Select Inputs](#) on page 36. Then set the state of the Product Change pin to Active when the sensor is in the Ready state. The sensor immediately loads the selected inspection and is ready to execute when it receives a trigger. For Product Change to be successful, select at least one of the I/O pins to function as Product Select.

## Product Select Inputs

The VE has four dedicated Product Select lines that can be thought of as making a Binary Code Decimal (BCD) table. Access inspections 0 through 15 using the following pin combinations:

Inspection Number	Product Select #3	Product Select #2	Product Select #1	Product Select #0
0	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	ON
2	OFF	OFF	ON	OFF
3	OFF	OFF	ON	ON
4	OFF	ON	OFF	OFF
5	OFF	ON	OFF	ON
6	OFF	ON	ON	OFF
7	OFF	ON	ON	ON
8	ON	OFF	OFF	OFF
9	ON	OFF	OFF	ON
10	ON	OFF	ON	OFF
11	ON	OFF	ON	ON
12	ON	ON	OFF	OFF
13	ON	ON	OFF	ON
14	ON	ON	ON	OFF
15	ON	ON	ON	ON

## 6.5.3 Communications

Use Communications to view or change communication information, to set the industrial protocol, and to set image export settings.

### Ethernet Settings Tab

Use the Ethernet Settings tab to view or change some Ethernet settings.

Navigate:  System Settings > Communications > Ethernet Settings.




Figure 37. Ethernet Settings Tab

On the Ethernet Settings tab, click  to access the sensor properties editing window and view or change the following:

- IP Address—View or change the IP address of the sensor
- Subnet Mask—View or change the subnet address of the sensor
- Gateway—View or change the gateway address of the sensor
- MAC Address—View the MAC address of the sensor

To change the Max Speed, the maximum negotiation speed with the network, select the desired speed from the list:

- 1000 Full Duplex
- 100 Full Duplex (default)
- 100 Half Duplex

## Industrial Protocols Tab

Use the Industrial Protocols tab to set the protocol the sensor uses to communicate and to select output data (map) to send to a PLC.

Navigate:  System Settings > Communications > Industrial Protocols.




Figure 38. Industrial Protocols Tab

On the Industrial Protocols tab, select the desired protocol to enable it.

- Disabled (default)
- EtherNet/IP
- PROFINET
- Modbus/TCP
- PCCC

A 32 Bit Format setting displays if Ethernet/IP, Modbus/TCP, or PCCC is chosen. Select LSW-MSW or MSW-LSW from the list.




Figure 39. Industrial Protocols Tab—EtherNet/IP Selected

A customizable map to output camera or inspection tool-specific results also displays. The map includes the following:

- Register/Byte/Word (depending on the protocol selected)
- Inspection Slot #
- Tool Type
- Tool Name
- Result
- Type
- Actions



**NOTE:**

- Inspection Slot # changes automatically depending on which inspection includes the tool.
- Type changes automatically depending on how much space is available.
- Data in registers 1–16 are fixed and contained in the PLC input assemblies (EtherNet/IP, Modbus/TCP, and PCCC).

Click Apply Changes to send the current map to the camera.

Click to print and save a PDF of the current map. The PDF includes all data, whether system-defined or user-defined.

Click above the map to return the map to the default settings. All user-defined output data is deleted. Click in the Actions column to delete an individual result.

For additional information see:

- [Set the Industrial Ethernet Protocol \(EtherNet/IP, PROFINET®, Modbus/TCP, PCCC\)](#) on page 138
- [Tool-Specific Results: EtherNet/IP](#) on page 144
- [Tool-Specific Results: Modbus/TCP](#) on page 165
- [Tool-Specific Results: PCCC](#) on page 174
- [Tool-Specific Results: PROFINET](#) on page 183

### Image Export Tab

Use the Image Export tab to set the parameters used to export images.

Navigate: System Settings > Communications > Image Export.




Figure 40. Image Export Tab

On the Image Export tab, set the image export parameters:

#### Export

Set which images to export:

- Disabled
- All (default)
- Pass only
- Fail only

#### Port Number

Set the port number to use for the export. The default is 32200.

#### Hold READY

Select to prevent new triggers from being accepted until the current image has been exported.

Clear the checkbox to accept new triggers while the current image is exported.



**Important:** When the checkbox is cleared, not all images will be exported. When the checkbox is selected, the ready signal is held active until the image has been exported across Ethernet; inspection times will increase based on network throughput.

For additional information, see [Image Export](#) on page 135.

## 6.5.4 Logs

The Logs default view is the System tab. Use the System Tab to view, export, or clear system logs and communication logs. Select or clear the Display checkboxes to customize which events are shown.

Navigate: System Settings > Logs > System.




Figure 41. System Tab

To clear a system error flag (or state), click Clear System Error.



NOTE: The system error log entry will not be cleared from the log.

To export system logs, click Export Log and follow the prompts. Logs are exported as a .slog file.

To clear the log, click Clear Log.

View a system log exported from another sensor using the View Exported Logs tab.

Navigate: System Settings > Logs > View Exported Log. Click Load Log and navigate to the desired log file to view it.




Figure 42. View Exported Log Tab

## 6.5.5 Units

Use Units to select a unit to display and to publish results that represent distance, size, and location calculations.




Figure 43. Units

By default, distance, size, and location calculations are shown in pixels. To change the displayed units, from the Mode list, select Scaling and then select the desired measurement unit and parameters. The following Measurement Units are available:

- Microns ( $\mu\text{m}$ )
- Millimeters (mm)
- Centimeters (cm)
- Meters (m)
- Mils (mil)
- Inches (in)

- Feet (ft)
- Yard (yd)

Click Apply Changes to save the changes. Applying a scaling factor changes the measurements listed in the Tools and Results to the selected unit and applies the scale to all inspections.

### Scale Units Using a Known Measurement

Use a known measurement, such as ruler, to configure the scaling factor for converting pixels to the desired unit.

The conversion factor for using scaled units can be determined using any object of a known size. For illustration purposes, this example uses a ruler as the object. This procedure is an example only.



**NOTE:**

- Make sure the camera focus is as sharp as possible.
- Span more pixels for increased accuracy.
- Use objects closer to the center of the FOV to limit the distortion that naturally occurs closer to the edges of the FOV.

1. Place the ruler in the FOV.
2. Add a Measure tool.
3. Point to the 0 line on the ruler and write down the x and y coordinates shown in the Image Parameters pane.




Figure 44. X and Y Coordinates

4. Expand Measure from... and select Constant.
5. In the Point (X, Y) field, enter the x and y coordinates from step 3.
6. Point to the 10 mm (1 cm) line on the ruler and write down the x coordinate shown in the Image Parameters pane.
7. Expand Measure to... and select Constant.
8. In the Point (X, Y) field, enter the x you wrote down in step 6 and y coordinate from step 3. (The y coordinates must be the same.)  
The Measure tool measures between the two points.

9. Write down the Distance (px) show in Tools & Results.  
In this example, the distance is 101.00 px.




Figure 45. Distance Measurement Between the Two Points

10. On the System Settings screen, click Units.
11. From the Mode list, select Scaling.  
The scaling parameters display.
12. Select the desired Measurement Unit. For this example, the unit is Millimeters.
13. In the Measurement in Pixels field, enter the distance from step 9.
14. In the Measurement in Millimeters field, enter 10 because the known distance was 10 mm.




Figure 46. Units Configured

15. Click Apply Changes.

Applying a scaling factor affects all existing inspections. The currently running inspection is immediately modified on the next trigger and other inspections are modified when they are loaded.




Figure 47. Tools and Results Showing the New Units

## 6.5.6 System Reset

Use System Reset to reboot the sensor or to restore the sensor to the factory default settings.

Click Reboot Sensor to stop, shutdown, and restart the sensor. The start up inspection is loaded after the sensor reboot.

Click Reset to Factory Defaults to restore the sensor to the factory default settings.



Important: All stored inspections are deleted when factory default settings are restored. Ethernet settings and favorites lists are retained.

## 7 Using the Camera Tool

The camera tool controls the sensor's camera function during an inspection. Configure the camera tool using the parameters in the Parameters pane:

- Imager
- Focus Info
- Trigger
- External Strobe
- Image Histogram




Figure 48. Camera Tool Input Parameters

When the camera tool is selected, it is highlighted orange in Tools & Results and in Tools Only, the Inputs tab displays on the Parameters pane, and the camera tool results are highlighted in All Results.

### 7.1 Imager

Use the Imager parameters to adjust the exposure and gain.




Figure 49. Imager

#### Exposure

Exposure time is the amount of time the camera allows light to energize the imager chip. Increasing the exposure time allows more light to energize the imager chip, which brightens the picture. Use the slider or enter the desired exposure time in milliseconds.

Gain

Gain is an electronic boost to the image signal. Increasing gain increases image brightness without increasing exposure time. Use the slider or enter the desired gain number.



NOTE: Gain brightens both the light pixels and the dark pixels. High gain values will make the image appear grainy.

Auto Exposure

During Auto Exposure, the exposure time and gain are optimized for the current inspection. Click Start to begin Auto Exposure.



NOTE: Several triggers may be required to calculate the optimized values for exposure and gain.

## 7.2 Trigger

Use the Trigger parameters to set the method and rate at which the sensor captures images. Trigger parameters are stored in the inspection file and can be different for each inspection.




Figure 50. Trigger

Internal (default)

The sensor triggers itself at a user-defined rate. Use the slider or enter the desired rate, from 10 ms to 10,000 ms. The default rate is 100 ms.

External

The sensor is triggered either manually using the trigger button  in the Vision Manager software or it is triggered by an external source (via the trigger pin), such as a photoelectric sensor. The external trigger option has the following parameters:

- **Trigger Polarity**—Sets when the image is captured compared to the trigger signal. Choose Leading Edge to capture images at the leading edge of a trigger signal. Choose Trailing Edge to capture images at the trailing edge of the trigger signal. The default is Leading Edge.
- **Trigger Delay**—Sets the fixed time from the instant the sensor receives a valid trigger to the instant the sensor captures the image. Use the slider or enter the desired time in milliseconds, from 0 ms to 10,000 ms. The default is 0 ms.
- **Minimum Trigger Width**—Eliminates unwanted triggers by accepting triggers only if they last for a specified duration. Use the slider or enter the desired minimum trigger width in milliseconds, from 1 ms to 5,000 ms. The default is 1 ms.
- **Trigger Divide**—Sets the logic for how valid trigger inputs are related to actual images taken. If the Trigger Divide is set to 1, an image is captured in response to every valid trigger. If it is set to 2, an image is captured in response to every second valid trigger, and so on. Use the slider or enter the desired trigger divide, from 1 to 1,000. The default is 1.

### Free Run

The sensor immediately issues a new trigger at the end of an inspection.

### Industrial Ethernet

The Industrial Ethernet communications channel controls the trigger. A PLC or HMI triggers the camera tool over an Industrial Ethernet protocol such as EtherNet/IP or PROFINET.

## 7.3 Focus Information

Select the Focus Info checkbox and expand the parameter to view the current focus number for the installed lens.



Figure 51. Focus Info

The focus number is a number between 1 and 255. Use the Image pane to determine when the image is sharp enough, or use the focus number as a guide. Turn the focus ring on the lens until the focus number is at the highest possible number between 1 and 255. The focus number is also available on the sensor display.



NOTE: There is no optimal value for this number, but it can be used as a guide if you are setting up more than one sensor that are focused on the same target.

## 7.4 External Strobe

Use External Strobe to control an external light connected to the sensor.




Figure 52. External Strobe

### Strobe Type

The strobe type of the VE Series camera should match the style of external light used, otherwise the ON/OFF behavior of the light will be inverted.

- Active Low—A 0 V dc external strobe signal is provided by the VE Series camera when the external light should be ON. A +5 V dc external strobe signal is provided by the VE Series camera when the external light should be OFF. This is the default strobe type setting for the VE Series camera and many of the external vision lights Banner offers.
- Active High—A +5 V dc external strobe signal is provided by the VE Series camera when the external light should be ON. A 0 V dc external strobe signal is provided by the VE Series camera when the external light should be OFF.

### Mode

- Always Off—The external light is always OFF
- Always On—The external light is always ON
- Exposure Based—The external light is ON for the duration of the camera exposure time
- Time Based—The external light is ON for the duration of a user-defined time period

#### Exposure Delay

The external light turns ON after a user-defined time delay, in milliseconds, after a valid trigger. Available only when the Mode is Exposure Based or Time Based.

#### Duration

The external light is ON for a user-defined amount of time, in milliseconds. Available only when the Mode is Time Based.

## 7.5 Camera Tool: Results

Click the camera tool on Tools & Results or expand the camera tool on All Results to view camera information.




Figure 53. Camera Tool Results

#### Focus Number

The focus number for the frame being viewed, if the Focus Number parameter is enabled in the Camera tool. See [Focus Information](#) on page 47 for more information on the Focus Number.

#### Execution Time

The execution time for the camera tool. This is the total time required to capture an image.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

#### Status

Status and error messages display as appropriate.

## 8 Using the Inspection Tools: Vision Tools

Vision sensor tools include Average Gray, Bead, Blemish, Blob, Edge, Locate, Match, and Object.

Click a tool on Tools & Results or on Tools Only to access the Parameters pane for that tool. The Parameters pane contains both an Inputs tab and a Test tab. Define parameters for the tool itself on the Inputs tab. Define pass or fail criteria for the tool on the Test tab. When a tool is selected, the tool is highlighted orange in Tools & Results and in Tools Only, the tool ROI is selected in the Image pane, and the tool results are highlighted in All Results.

For many of the parameters, move the slider to set the desired number, or move both sliders to set minimum and maximum limits, where applicable. Numbers and limits can also be entered manually.

In parameters with colors in the sliders, vertical green bars represent current image information. Light gray backgrounds indicate the range over which a value has varied over time.

### 8.1 Average Gray Tool

Use the Average Gray tool to determine the brightness levels of pixels found within the ROI.

Each pixel has a grayscale intensity value from 0 to 255, where 0 is black and 255 is white. The tool records the grayscale value of each pixel in an ROI and averages them. With this information, the tool can detect changes in intensity that can indicate several conditions, such as missing objects, holes, texture changes, and possible color changes.

Example applications:

- Spot-check for holes
- Check for a change in surface texture
- Check for presence/absence of a label or other objects

#### 8.1.1 Average Gray Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 54. Average Gray Tool—Input Parameters

#### ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.



Figure 55. ROI Shape Selection

Resize  and rotate  the ROI around the feature to be analyzed. Change the shape of the ROI to a square, ellipse, or circle as needed by expanding ROI on the Parameters pane and selecting the desired shape. An ROI can be as large as the entire Field of View (FOV). The ROI automatically displays on the Image pane when a tool is added.

## Masks

Add and define a mask to exclude a group of pixels from the tool analysis.



Figure 56. Masks Parameters

A mask created for a tool will not apply to any other tool in the inspection. Up to 10 masks can be added to a tool.

1. Expand Masks on the Inputs tab.
2. Click . The mask ROI automatically displays on the Image pane.
3. Select the mask shape. The mask ROI can be rectangular, elliptical, or circular.
4. Resize and rotate the mask ROI around the pixels to be excluded.
5. To delete a mask, click .

## Pixel Intensity Range

Set the intensity range of pixels to analyze. Pixels with brightness values outside of this range are ignored.




Figure 57. Pixel Intensity Range Parameters

The default settings of 0 to 255 allow all pixels to be included in the average calculation.



NOTE: An average grayscale result of – indicates that all pixels in the ROI have been excluded by the pixel intensity range parameter.

## Image Overlays

Choose whether to display or hide the ROI or masks.



Figure 58. Image Overlays—Default

These options override the ROI view buttons on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide ROI

Hides the ROI when the tool is not selected.

### Hide Masks

Hides the Mask ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 59. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 60. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 8.1.2 Average Gray Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 61. Average Gray Tool—Test Parameters

Average Grayscale

The grayscale value range.

Standard Deviation

The standard deviation range.

### 8.1.3 Average Gray Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

Average Grayscale

The average grayscale value of the pixels in the ROI.

Standard Deviation

The standard deviation of the average grayscale value for the pixels in the ROI.

Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

Status

Status and error messages display as appropriate.

### 8.1.4 Using the Average Gray Tool

Follow these steps for a typical presence/absence Average Gray inspection.



NOTE: This procedure is an example only.

1. Add an Average Gray tool to the inspection.
2. Adjust the ROI to frame the desired feature.
3. Set the Test parameters to set the pass/fail criteria.

- a) On the Test tab, select the Average Grayscale checkbox.

This option sets the grayscale range that must be present in the ROI so that a part passes.

- b) Move the sliders or enter the minimum and maximum grayscale. Inspections outside of this range will fail. For this example, the minimum is 56.12 and the maximum is 74.83.

The green bar indicates the current grayscale and the light gray background indicates the grayscale over time since the last reset.

4. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 62. Average Gray—Pass




Figure 63. Average Gray—Fail

## 8.2 Bead Tool

Use the Bead tool to inspect parts for uniformity of adhesive or sealant material, or for uniformity of a gap. In an industrial setting, this "bead" of material is commonly applied in a strip along a known path. The Bead tool looks at this pre-defined path and verifies whether the adhesive or sealant has been correctly applied.

For the purposes of this tool, a bead is any long, narrow strip of approximately consistent width and approximately consistent color. The bead must have sufficient contrast with the background so that a simple grayscale threshold scheme can separate the two. Background clutter and optical noise, such as shiny spots or holes in the bead, are permitted, but their presence may degrade the robustness of a bead inspection.

The Bead tool assumes that the bead material has been applied by a mechanized system and is consistent in location and direction. The tool does not attempt to detect, follow, or account for variations in bead location.

Example applications:

- Detect uniformity of a bead of adhesive
- Detect uniformity of a gap between two adjacent materials

### 8.2.1 Bead Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 64. Bead Tool—Input Parameters

## ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.




Figure 65. Bead Tool ROI

The ROI is configurable to follow the desired path of the adhesive or sealant being analyzed. Adjust the width of the ROI and set the sample rate. From the list select the frequency of bead width measurements: Every Pixel, Every 2nd Pixel, or Every 4th Pixel. See [Bead Tool: Adjust the ROI](#) on page 59.

## Masks

Add and define a mask to exclude a group of pixels from the tool analysis.



Figure 66. Masks Parameters

A mask created for a tool will not apply to any other tool in the inspection. Up to 10 masks can be added to a tool.

1. Expand Masks on the Inputs tab.
2. Click . The mask ROI automatically displays on the Image pane.
3. Select the mask shape. The mask ROI can be rectangular, elliptical, or circular.
4. Resize and rotate the mask ROI around the pixels to be excluded.
5. To delete a mask, click .

## Threshold

The threshold parameter separates the bead from the background, in terms of contrast.

### Threshold Type: Adaptive

Select Adaptive when there are lighting changes that cause the acquired image to change.




Figure 67. Threshold Type—Adaptive

An adaptive threshold is a technique that adjusts the threshold for the tool based upon lighting changes and image content within the ROI. It performs best if used with bi-modal images, which have a clear contrast in the ROI. Adaptive threshold chooses the current threshold value by converging to a value based on the average value of the pixels above and below

the previous threshold value; it will not move the value of the threshold above or below the minimum and maximum limits.

#### *Adaptive Threshold: Bead/Blob Type*

Defines whether the bead/blob is dark against a relatively brighter background or bright against a darker background.

This parameter defines the appearance of the feature of interest. For example, if you have a dark adhesive or part on a bright background, choose Dark.

Choosing Dark with an adaptive threshold type causes the tool to limit the threshold to the range specified by the threshold level minimum and maximum limits. The tool identifies all grouped pixels below the threshold chosen as dark beads/blobs.

Choosing Bright with an adaptive threshold type causes the tool to limit the threshold to the range specified by the threshold level minimum and maximum limits. The tool identifies all grouped pixels above the specified minimum limit and less than or equal to the maximum limit as bright beads/blobs.

#### *Adaptive Threshold: Threshold*

Use the sliders or enter the desired minimum and maximum possible grayscale threshold.

The green line is the current threshold value, chosen by the tool, and the sliders represent boundaries beyond which you do not want the tool to move the threshold settings.

#### *Reject Level*

When the Bead/Blob Type is set to Bright, use the Reject Level to narrow the range of pixel intensities to be considered in an inspection.

Leaving the defaults at 0 for low and 255 for high means that the tool takes into consideration all grayscale levels in the ROI from 0 (black) to 255 (white).

#### *Reject Level Example*

Consider setting up an inspection for a relatively bright object that ranges from 180 to 200 in pixel intensity and takes up 15 percent of the FOV. The remaining 85 percent of the FOV ranges from 230 to 255 in pixel intensity. Setting a Reject Level of 220 allows the tool to pay attention to only the bright object being inspected. Masking the bright parts of the FOV is not necessary because only pixels whose intensity is less than the Reject Level will contribute to bright beads/blobs.

#### *Threshold Type: Fixed*

Select Fixed when the lighting and image content remain relatively constant for all inspections.




Figure 68. Threshold Type—Fixed

#### *Fixed Threshold: Bead/Blob Type*

Defines whether the bead/blob is dark against a relatively brighter background or bright against a darker background.

This parameter defines the appearance of the feature of interest. For example, if you have a dark adhesive or part on a bright background, choose Dark.

Choosing Dark with a fixed threshold type causes the tool to fix the threshold at the level specified by the Threshold level parameter. The tool identifies all grouped pixels below the specified threshold as dark beads/blobs.

Choosing Bright with a fixed threshold type causes the tool to fix the threshold at the Bright level specified by the Threshold level parameter. The tool identifies all grouped pixels above the specified Bright threshold and less than or equal to the Reject level as bright beads/blobs.

#### *Fixed Threshold: Threshold*

Use the slider to define the dark/bright cutoff point.

Any pixels brighter than this point define the bright bead while those darker than this point define the dark bead.

### Reject Level

When the Bead/Blob Type is set to Bright, use the Reject Level to narrow the range of pixel intensities to be considered in an inspection.

Leaving the defaults at 0 for low and 255 for high means that the tool takes into consideration all grayscale levels in the ROI from 0 (black) to 255 (white).

### Reject Level Example

Consider setting up an inspection for a relatively bright object that ranges from 180 to 200 in pixel intensity and takes up 15 percent of the FOV. The remaining 85 percent of the FOV ranges from 230 to 255 in pixel intensity. Setting a Reject Level of 220 allows the tool to pay attention to only the bright object being inspected. Masking the bright parts of the FOV is not necessary because only pixels whose intensity is less than the Reject Level will contribute to bright beads/blobs.

### Good Bead Width

Move the sliders or enter the desired minimum and maximum bead width.

The red section is bead that is too narrow or is a gap. The green section is good bead width. The blue section is bead that is too wide.




Figure 69. Good Bead Width

### Filters

Select the checkbox to ignore boundary pixels.




Figure 70. Bead Tool Filters

Boundary pixels are bead pixels that touch the ROI. If boundary pixels are ignored, one or more segments may also be ignored.

### Image Overlays

Chose whether to display or hide the annotations, ROI, or masks when this tool is not selected. Masks are hidden by default.




Figure 71. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

**Hide Annotations**

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 72. Show Bead Tool Annotations




Figure 73. Hide Bead Tool Annotations

**Hide ROI**

Hides the ROI when the tool is not selected.

**Hide Masks**

Hides the Mask ROI when the tool is not selected.

**Tool Histogram**

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 74. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

**Inspection Pass/Fail**

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 75. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

## 8.2.2 Bead Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 76. Test Parameters

Count—Good

The number of good beads.

Count—Narrow/Gap

The number of narrow beads.

Count—Wide

The number of wide beads.

Largest Width

The maximum width found.

Smallest Width

The minimum width found.

Average Width

The average width found.

Total Length—Good

The total length of good beads.

Total Length—Narrow/Gap

The total length of narrow beads.

Total Length—Wide

The total length of wide beads.

Longest Length—Good

The longest good bead length.

Longest Length—Narrow/Gap

The longest narrow bead length.

Longest Length—Wide

The longest length of wide beads.

## 8.2.3 Bead Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

Count - Good

The number of beads that fall within the user-defined good bead width.

Expand Count - Good to see the length of each bead, the total length of all beads, and the longest length.

Count - Narrow/Gap

The number of narrow beads or gaps that qualify as having a narrow bead width.

Expand Count - Narrow/Gap to see the length of each bead, the total length of all beads, and the longest length.

Count - Wide

The number of wide beads that qualify as having a wide bead width.

Expand Count - Wide to see the length of each bead, the total length of all beads, and the longest length.

Average Width

The average width of all beads.

Expand Average Width to see the largest width and the smallest width.

Adaptive Threshold

The grayscale value used to detect the bead when the Threshold Type is Adaptive. If the tool cannot calculate this value, or if the Threshold Type is Fixed, this value displays as --.

Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

Status

Status and error messages display as appropriate.

### 8.2.4 Bead Tool: Adjust the ROI

Follow these steps to adjust the Bead tool ROI.



NOTE: This procedure is an example only. Use the appropriate steps to adjust the Bead tool ROI for your application.

1. Add a Bead tool to the inspection.




Figure 77. Add a Bead Tool

2. Move the ROI over the bead to be inspected.
3. Move an ● anchor point to a new position by clicking on the anchor point when the Hand icon displays.




Figure 78. Click to Move Anchor Point

4. Click the + plus sign on either end of the bead ROI to add more anchor points.




Figure 79. Add Anchor Point

5. Click on a line to add an inline anchor point.
  - a) Point to the ROI line; the pointer changes to a +.




Figure 80. Add Inline Anchor Point

- b) Click to select the location for the new anchor point; + is added on the line.




Figure 81. Inline Anchor Point Location Selected

- c) Click the point again to set the location on the line. The + changes to a solid yellow circle.




Figure 82. Inline Anchor Point Set

6. Click on a solid yellow circle anchor point and the Trash icon displays above it; click the Trash to delete the point.




Figure 83. Click to Delete Anchor Point

7. Use the ROI sliders in the Input tab to change the ROI width.





Figure 84. Bead Tool ROI Width

- Use the Good Bead Width parameter under Characteristics to define the good bead width. Green indicates that the bead width is acceptable. Red indicates that the bead width is too narrow or that a gap exists. Blue indicates that the bead width is too wide.




Figure 85. Good, Narrow, and Wide Adhesive Widths

### 8.2.5 Using the Bead Tool

Follow these steps to configure a Bead tool for a dark adhesive on a bright background.



NOTE: This procedure is an example only.

In this example, scaling is on (System Settings > Units > Scaling) with the Measurement Unit set at Millimeters, the Measurement in Pixels set at 810, and the Measurement in Millimeters set at 70.

- Add a Bead tool to the inspection.
- Adjust the ROI path and width to match the adhesive bead.

See [Bead Tool: Adjust the ROI](#) on page 59.




Figure 86. Bead ROI

3. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) From the Threshold Type list, select Fixed.
 

Select Fixed when the lighting and image content remain relatively constant for all inspections.
  - c) From the Bead Type list, select Dark because in this case the adhesive is dark against a bright background.
  - d) Expand the Threshold parameters.
  - e) Move the slider until the adhesive bead shows as green in the ROI and the background is ignored. In this example, that number is 137.




Figure 87. Threshold

4. Set the bead width.
  - a) Expand the Good Bead Width parameter.
  - b) Move the sliders to define the minimum and maximum acceptable bead width. In this example, the minimum bead width is 1.72 mm and the maximum bead width is 4.83 mm.




Figure 88. Good Bead Width

5. Set the test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Count - Good checkbox to enable the test parameter.  
This option sets the number of good beads that must be present with the tool parameters so that a part passes.
  - b) Expand Count - Good and move the sliders or enter the minimum and maximum as 1 and 1.  
This means that the inspection must find one and only one bead within the ROI that meets the Good Bead Width definition.
  - c) Select the Count - Narrow/Gap checkbox to enable the test parameter.  
This option sets the allowable number of gaps in the bead.
  - d) Move the sliders or enter the minimum and maximum as 0 and 0.  
This means that no gaps are allowed. If gaps are found, the inspection fails.



Figure 89. Test Criteria

6. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 90. Bad Part—Narrow Bead Width




Figure 91. Bad Part—Gap

## 8.3 Blemish Tool

Use the Blemish tool to determine whether flaws are present on a part (for example, scratches on a disc), or to make sure that a feature exists on a part.

Although finding features is more commonly an application for a Blob tool, the Blemish tool may be a better option to find a feature when dealing with variable materials or inconsistent lighting.

Example applications:

- Check for scratches on a part, and reject parts where the scratches are too numerous or larger than acceptable
- Check for the presence of a label or marking on a part that may vary in brightness level

### 8.3.1 Blemish Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 92. Blemish Tool—Input Parameters

#### ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.



Figure 93. ROI Shape Selection

Resize  and rotate  the ROI around the feature to be analyzed. Change the shape of the ROI to a square, ellipse, or circle as needed by expanding ROI on the Parameters pane and selecting the desired shape. An ROI can be as large as the entire Field of View (FOV). The ROI automatically displays on the Image pane when a tool is added.

#### Masks

Add and define a mask to exclude a group of pixels from the tool analysis.



Figure 94. Masks Parameters

A mask created for a tool will not apply to any other tool in the inspection. Up to 10 masks can be added to a tool.

1. Expand Masks on the Inputs tab.
2. Click . The mask ROI automatically displays on the Image pane.
3. Select the mask shape. The mask ROI can be rectangular, elliptical, or circular.
4. Resize  and rotate  the mask ROI around the pixels to be excluded.
5. To delete a mask, click .

## Sensitivity

Set the Sensitivity to define how sensitive the sensor is to finding blemish or other edges within the ROI. The sensitivity value helps account for light variations that can affect how well the sensor detects edges on inspected parts.




Figure 95. Sensitivity

The Sensitivity scale is from 0 to 100 where 0 means least sensitive and 100 means most sensitive. If set near 0, the sensor finds very sharp edges with strong contrast. If set near 100, the sensor finds very dim or blurry edges, and may be unstable. The default is 80.

## Edge Length Range

Shows the different contiguous edge segments found.




Figure 96. Edge Length Range

Use the sliders to specify the edge length range in pixels. Edges found within this range will be considered when calculating the Pass Count. Green represents lengths within the specified range and yellow represents lengths outside of the specified range.

## Image Overlays

Chose whether to display or hide the annotations, ROI, or masks when this tool is not selected. Masks are hidden by default.




Figure 97. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 98. Show Blemish Tool Annotations




Figure 99. Hide Blemish Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

Hide Masks

Hides the Mask ROI when the tool is not selected.

Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 100. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 101. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

8.3.2 Blemish Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 102. Blemish Tool—Test Parameters

Count

The total number of edge pixels.

### 8.3.3 Blemish Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Count

The total number of edge pixels counted.

#### Length Range

The minimum and maximum edge lengths found.

Expand Length Range to see the minimum and maximum edge pixels counted, and the total edge pixels for each blemish.

#### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

#### Status

Status and error messages display as appropriate.

### 8.3.4 Using the Blemish Tool

Follow these steps for an example Blemish inspection to check for a date/lot code on a product.



NOTE: This procedure is an example only.

1. Add a Blemish tool to the inspection.
2. Adjust the ROI to frame the date/lot code.
3. Set the sensitivity.
  - a) Expand the Sensitivity parameters.
  - b) Move the slider or enter 75 for this example.

A low sensitivity setting finds only high contrast edges, while a high sensitivity setting finds lower contrast edges as well. Note that the color does not matter; the tool will still find the edges of the date/lot code.



Figure 103. Light Date/Lot Code on a Dark Background




Figure 104. Dark Date/Lot Code on a Light Background

4. Leave the default minimum and maximum edge length range (100 px and 165000 px).  
This defines how long the edge has to be before it is counted and how small it can be before it is ignored. Green means that the edge is within the criteria to be counted and yellow means it is outside of the criteria and is being ignored.
5. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Count checkbox.  
This options sets the number of edges that must be present within the ROI that match the inspection parameters so that the tool passes.
  - b) Move the sliders or enter the minimum count at 242 and the maximum count at 233230.  
For example, a minimum and maximum count of 0 and 0 means that the part must have zero edges within the ROI that match the inspection parameters. In this case, the part must be blemish-free.



NOTE: The green bar indicates the current count and the light gray background indicate the count over time since the last reset.

6. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 105. Bad Part—Missing Date/Lot Code

## 8.4 Blob Tool

Use the Blob tool to detect and count groups of like-colored pixels within the ROI.

A user-selected range of brightness levels defines the pixels of interest. Then, the Blob tool merges pixels of interest that touch each other into groups, called blobs. The Blob tool then counts the number of blobs in the ROI, calculates their size in pixel area, and defines each blob's center of mass location.

Example applications:

- Count pills
- Measure hole size
- Verify the number of characters in a date/lot code
- Detect LCD segments
- Detect missing products during packaging

### 8.4.1 Blob Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 106. Blob Tool—Input Parameters

### ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.




Figure 107. ROI Shape Selection

Resize  and rotate  the ROI around the feature to be analyzed. Change the shape of the ROI to a square, ellipse, or circle as needed by expanding ROI on the Parameters pane and selecting the desired shape. An ROI can be as large as the entire Field of View (FOV). The ROI automatically displays on the Image pane when a tool is added.

## Masks

Add and define a mask to exclude a group of pixels from the tool analysis.




Figure 108. Masks Parameters

A mask created for a tool will not apply to any other tool in the inspection. Up to 10 masks can be added to a tool.

1. Expand Masks on the Inputs tab.
2. Click . The mask ROI automatically displays on the Image pane.
3. Select the mask shape. The mask ROI can be rectangular, elliptical, or circular.
4. Resize  and rotate  the mask ROI around the pixels to be excluded.
5. To delete a mask, click .

## Threshold

The threshold parameter is used to mark a transition point.

Threshold Type: Adaptive

Select Adaptive when there are lighting changes that cause the acquired image to change.




Figure 109. Threshold Type—Adaptive

An adaptive threshold is a technique that adjusts the threshold for the tool based upon lighting changes and image content within the ROI. It performs best if used with bi-modal images, which have a clear contrast in the ROI. Adaptive threshold chooses the current threshold value by converging to a value based on the average value of the pixels above and below the previous threshold value; it will not move the value of the threshold above or below the minimum and maximum limits.

### Adaptive Threshold: Bead/Blob Type

Defines whether the bead/blob is dark against a relatively brighter background or bright against a darker background.

This parameter defines the appearance of the feature of interest. For example, if you have a dark adhesive or part on a bright background, choose Dark.

Choosing Dark with an adaptive threshold type causes the tool to limit the threshold to the range specified by the threshold level minimum and maximum limits. The tool identifies all grouped pixels below the threshold chosen as dark beads/blobs.

Choosing Bright with an adaptive threshold type causes the tool to limit the threshold to the range specified by the threshold level minimum and maximum limits. The tool identifies all grouped pixels above the specified minimum limit and less than or equal to the maximum limit as bright beads/blobs.

### Adaptive Threshold: Threshold

Use the sliders or enter the desired minimum and maximum possible grayscale threshold.

The green line is the current threshold value, chosen by the tool, and the sliders represent boundaries beyond which you do not want the tool to move the threshold settings.

### Reject Level

When the Bead/Blob Type is set to Bright, use the Reject Level to narrow the range of pixel intensities to be considered in an inspection.

Leaving the defaults at 0 for low and 255 for high means that the tool takes into consideration all grayscale levels in the ROI from 0 (black) to 255 (white).

### Reject Level Example

Consider setting up an inspection for a relatively bright object that ranges from 180 to 200 in pixel intensity and takes up 15 percent of the FOV. The remaining 85 percent of the FOV ranges from 230 to 255 in pixel intensity. Setting a Reject Level of 220 allows the tool to pay attention to only the bright object being inspected. Masking the bright parts of the FOV is not necessary because only pixels whose intensity is less than the Reject Level will contribute to bright beads/blobs.

### Threshold Type: Fixed

Select Fixed when the lighting and image content remain relatively constant for all inspections.




Figure 110. Threshold Type—Fixed

### Fixed Threshold: Threshold

Use the sliders to define the range of brightness values of interest.

### Area Range

Set the size range of blobs that the tool will count.




Figure 111. Area Range

Green represents blobs that are within the set range, and yellow represents blobs that are outside of the set range.

### Blob Statistics

Select to calculate and display advanced results on Tools & Results and All Results.




Figure 112. Blob Statistics

When enabled, Perimeter, Compactness, Major Axis Length, Minor Axis Length, Major Axis Angle, Eccentricity, Minimum Radius, Maximum Radius, Minimum Radius Position, and Maximum Radius Position will be calculated in addition to Area and Centroid.

## Filters

Set filters for tool analysis.




Figure 113. Blob Tool Filters

### Discard Blobs that Touch ROI

Select to exclude blobs that touch the perimeter of the ROI.

### Fill Holes within Blob

Select to ignore (by filling) small features such as scratches and glare that might otherwise appear as small imperfections or non-blobs within a larger blob. After selecting this option, use the slider or enter the size of the largest hole to fill.

## Image Overlays

Chose whether to display or hide the annotations, ROI, or masks when this tool is not selected. Masks are hidden by default.




Figure 114. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 115. Show Blob Tool Annotations




Figure 116. Hide Blob Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

### Hide Masks

Hides the Mask ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 117. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 118. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 8.4.2 Blob Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 119. Blob Tool—Test Parameters

#### Count

The number of blobs found.

#### Total Area

The total area of all of the blobs found.

#### Individual Blobs

From the Specific Blob dropdown list, select All Blobs, First Blob, or Specific Blob, to view area and centroid information about the blobs.

When Specific Blob is selected, choose the specific blob using the Blob Index.

To verify if blobs within the ROI are of a specific area, select the Area checkbox and use the sliders or enter the minimum and maximum blob size.

When Calculate Blob Statistics is enabled, additional parameters for the selected blob become available. These include Perimeter, Compactness, Major Axis Length, Minor Axis Length, Eccentricity, Minimum Radius, Maximum Radius, and Major Axis Angle.

### 8.4.3 Blob Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Count

The number of blobs found.

#### Total Area

The total area of all of the blobs found.

#### Area Range

The minimum and maximum areas of the blobs found.

Expand Area Range to see the area and centroid (center point) for each blob.

#### Statistics

Advanced statistical information about each blob.

When enabled, Perimeter, Compactness, Major Axis Length, Minor Axis Length, Major Axis Angle, Eccentricity, Minimum Radius, Maximum Radius, Minimum Radius Position, and Maximum Radius Position will be calculated in addition to Area and Centroid.

Available when Calculate Blob Statistics is checked. See the following sections for more details.

#### Adaptive Threshold

The grayscale value for the software-selected threshold value used to generate the blobs.

This result is blank if the threshold type is set to Fixed.

#### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

#### Status

Status and error messages display as appropriate.

## Area

The area (A) is a count of the total number of pixels that belong to the blob.

## Centroid

The centroid ( $x_c, y_c$ ) is the point at the center of mass of the blob.

For simple blobs such as solid circles, ellipses, or rectangles, this is the center of the shape. For more complicated shapes it is helpful to imagine a piece of cardboard cut in the shape of the blob. The centroid is the point where you could balance the cardboard on the tip of a pencil. For complicated shapes—especially shapes with unfilled holes—the centroid might lie outside of the shape.


The x coordinate of the centroid is calculated by adding the x coordinates of each pixel in the blob and dividing by the area. The y coordinate is similar:

$$x_c = \frac{\sum_{i=1}^A x_i}{A} \qquad y_c = \frac{\sum_{i=1}^A y_i}{A}$$



## Perimeter

The perimeter (P) gives an approximate measurement of the length of the circumference of the blob.



Because blobs are built from individual pixels, it is most practical to estimate the perimeter by counting the contributions of individual pixels on the blob's boundary. The following describes the exact values that are added to the perimeter for each possible pixel configuration. In each example, the description refers to the center pixel in the corresponding pictures.





A pixel with no neighbors that belong to the same blob contributes 3.14 linear pixels to the perimeter of the blob. This can happen only in a blob that has an area of one. Since such small blobs are usually ignored, this circumstance is rare.





A pixel with one neighbor that belongs to the same blob contributes 2.571 linear pixels to the perimeter of the blob.





A pixel with two neighbors that belong to the same blob, forming a straight line, contributes exactly 2 linear pixels to the perimeter of the blob.



A pixel with two neighbors that belong to the same blob, forming a corner, contributes 1.414 linear pixels to the perimeter of the blob.



A pixel with three neighbors that belong to the same blob contributes exactly 1 linear pixel to the perimeter of the blob.



A pixel with four neighbors that belong to the same blob contributes nothing to the perimeter of the blob.

This method of counting slightly overestimates the "true" perimeter. For example, a circle with a radius of 100 pixels has a computed perimeter of approximately 660 pixels, compared with the expected value of 628 pixels.

If the sensor is configured to convert pixel distances to other units, (for example, millimeters), the perimeter is given in those units. If the blob contains holes that have not been filled, the length of the perimeter includes the points on the perimeters of these holes.

### Compactness

Compactness is a measurement of the space a blob occupies.

The compactness is high for blobs that are nearly circular and low for blobs that are elongated or complicated.

$$\frac{400\pi A}{P^2}$$

compactness =

Where A is the area and P is the perimeter of the Blob in question. An idealized circle would have a compactness of 100, but because the perimeter is approximated (see above), the highest realistic value for most blobs is roughly 90. Very small blobs with just a handful of pixels may reach or even exceed the theoretical maximum of 100, again because of the approximations in the perimeter calculation.

### Major Axis Length, Minor Axis Length, and Major Axis Angle

Major Axis Length, Minor Axis Length, and Major Axis Angle are determined using a best fit ellipse.

To understand Major Axis Length, Minor Axis Length, and Major Axis Angle, it is important to note that these are not measurements of the blob itself because the blob may be an irregular shape. Rather, these measurements are determined by a well-defined shape, a "best fit ellipse".




Figure 120. Best Fit Ellipse

These three results combine to give information about the elongation and orientation of a blob. The equations used to compute these statistics are complicated, but the results usually have an intuitively useful meaning, described below. The first step in computing these results is to compute the  $M_{2,0}$ ,  $M_{0,2}$  and  $M_{1,1}$  statistical moments:

$$M_{2,0} = \frac{\sum_{i=1}^A (x_i - x_c)^2}{A}$$

$$M_{0,2} = \frac{\sum_{i=1}^A (y_i - y_c)^2}{A}$$

$$M_{1,1} = \frac{\sum_{i=1}^A ((x_i - x_c)(y_i - y_c))}{A}$$

where A is the area,  $(x_c, y_c)$  are the coordinates of the centroid, and  $(x_i, y_i)$  are the coordinates of pixel i. These values represent the variance with respect to x, the variance with respect to y, and the covariance, respectively. The final results can be calculated as follows:

$$Major\ Axis\ Length = 2\sqrt{2\left(M_{2,0} + M_{0,2} + \sqrt{4M_{1,1}(M_{2,0} - M_{0,2})^2}\right)}$$

$$Minor\ Axis\ Length = 2\sqrt{2\left(M_{2,0} + M_{0,2} - \sqrt{4M_{1,1}(M_{2,0} - M_{0,2})^2}\right)}$$

$$Major\ Axis\ Angle = \frac{\tan^{-1}\left(\frac{2M_{1,1}}{M_{2,0} - M_{0,2}}\right)}{2}$$

The following table gives a more practical perspective on how to interpret these results. If the sensor is configured to convert pixels to other units, the major and minor axis lengths are given in those units. The major axis angle is always given in degrees.

Blob Shape	Meaning of Major Axis Length	Meaning of Minor Axis Length	Meaning of Major Axis angle
Circular, no holes	Diameter of the circle	Equal to the major axis length	Unstable
Elliptical, no holes	Length of the ellipse	Width of the ellipse	Orientation of the ellipse
Square, no holes	Diameter of a circle that best approximates the square	Equal to the major axis length	Unstable
Rectangular, no holes	Length of an ellipse that best approximates the rectangle	Width of an ellipse that best approximates the rectangle	Orientation of the rectangle
Complicated shape, no holes	Length of an ellipse that best approximates the shape	Width of an ellipse that best approximates the shape	Orientation of the shape—unstable if length and width are nearly equal
Any shape with holes	Results vary depending on exact shape—experiment on your particular shape	Results vary depending on exact shape—experiment on your particular shape	Results vary depending on exact shape—experiment on your particular shape

### Eccentricity

The eccentricity of a blob is the length of the major axis divided by the length of the minor axis.

For circular regions and other regions with radial symmetry (such as a square), the value will be very close to 1. For elongated regions, the value will increase.

### Max Radius and Max Radius Position

The Maximum Radius of a blob is the distance from the centroid of the blob to the farthest pixel on that blob's perimeter. The Maximum Radius Position gives the pixel coordinates of that farthest perimeter point.

If the sensor is configured to convert pixels to other units, the maximum radius will be given in those units.

### Min Radius and Min Radius Position

The Minimum Radius of a blob is the distance from the centroid of the blob to the closest pixel on that blob's perimeter. The Minimum Radius Position gives the pixel coordinates of that closest perimeter point.

If the blob contains unfilled holes, the minimum radius position may be on the perimeter of a hole. If the sensor is configured to convert pixels to other units, the minimum radius will be given in those units.

## 8.4.4 Using the Blob Tool

Follow these steps for an example blob inspection in a pill counting application.



NOTE: This procedure is an example only.

1. Add a Blob tool to the inspection.
2. Adjust the ROI to frame the first set of pills in the blister pack.




Figure 121. Adjust ROI

3. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) From the Threshold Type list, select Fixed.
 

Select Fixed when the lighting and image content remain relatively constant for all inspections.
  - c) Expand the second Threshold parameters.
  - d) Move the sliders to define the minimum and maximum threshold.
 

This sets a minimum and maximum brightness within the ROI to include or exclude.




Figure 122. Threshold

4. Set the area range.

This defines the size range of pixel groups to include or exclude.

- a) Expand the Area Range parameters.
- b) Move the sliders to define the minimum and maximum size of pixel groups. Yellow indicates that a group of pixels is outside of the set range.




Figure 123. Area Range

5. Set the Test parameters to set the pass/fail criteria.

- a) On the Test tab, select the Count checkbox to enable the test parameter. This options sets the number of blobs that must be present within the ROI that match the inspection parameters so that the tool passes.
- b) Expand Count and move the sliders or enter the minimum and maximum count as 10 and 10.

 NOTE: The green bar indicates the current count and the light gray background indicates the count over time.

6. Copy the Blob tool.

- a) With the Blob tool selected, click . The tool and all of the settings are duplicated (copied) and all of the tools are deselected.
- b) Select one of the Blob tools and click  a second time. There are now three Blob tools with the same settings.

7. Click Blob02 (the second Blob tool) and move the ROI over the second blister pack.

8. Click Blob03 (the third Blob tool) and move the ROI over the third blister pack.

9. Click  to show all three ROI at the same time.

10. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 124. Bad Part—Missing Pill




Figure 125. Bad Part—Broken Pill

## 8.5 Edge Tool

Use the Edge tool to detect and count transitions between bright and dark pixels (edges).

The Edge tool counts the total number of edges, and determines the position of each edge. Edge position information can be used for distance or angle measurements when used with a Measure tool.

Example applications:

- Measure the height and width of a part
- Count the pins on a integrated circuit
- Measure the height of a needle
- Measure the deflection of an automotive gauge
- Detect the edge of a web
- Verify that a bottle cap is on completely

### 8.5.1 Edge Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 126. Edge Tool—Input Parameters

### ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.




Figure 127. ROI Parameters

The ROI is a line of pixels that can be shortened, lengthened, or widened as needed for the inspection. Tool analysis follows the direction of the arrow. Set the width and the sample rate for the region of interest. The ROI automatically displays on the I image pane when a tool is added.

### ROI Width

The ROI width increases in increments of 4 pixels (for example, 1, 5, 9, 13, ...) up to the total FOV size.

Note that:

- Narrow ROIs execute faster but could miss the edge
- Wide ROIs are more consistent but don't execute as fast
- A wide ROI provides an average value/location, which results in improved repeatability
- The ROI must be 13 pixels or wider to calculate the rotation of a part (Locate tool only)

### Sample Rate

The sample rate sets the number of samples per pixels (one sample per pixel, two samples per pixel, etc.). The sample rate determines the sub-pixel resolution, which increases the resolution of the tool, and increases the inspection time.




Figure 128. 1 px Wide ROI




Figure 129. 13 px Wide ROI

## Threshold

The Threshold parameter marks the grayscale transition point.

The tool marks the edge where the pixel intensity crosses the threshold level. From the Threshold Type list, select one of the following:

- Absolute
- Relative (default)
- Edge Strength

### Threshold Type: Absolute

Finds an edge at a specific grayscale level.




Figure 130. Absolute Threshold Parameters

While Absolute threshold is less likely to find a false edge than Relative threshold, it may miss edges if the light level changes between inspections.

### Absolute Threshold: Value

Enter a specific grayscale value from 0 to 255.

### Edge Polarity

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

### Absolute Threshold: Edge Profile Graph




Figure 131. Absolute Threshold—Edge Profile Graph

For absolute threshold, the x axis is the length of the ROI. The y axis is the actual grayscale value from 0 to 255. The light blue line shows the absolute pixel intensity. The horizontal gray threshold line moves up or down with the threshold value.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

### Threshold Type: Relative

Finds an edge at a relative pixel intensity. This is the default threshold setting.




Figure 132. Relative Threshold Parameters

The brightest grayscale level found along the ROI is 100% and the darkest is 0%. While Relative threshold is more tolerant of light fluctuations between inspections than other transition types, it may find false edges.

### Relative Threshold: Percent

Choose the percentage value at which the edge should be marked.

### Edge Polarity

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

*Relative Threshold: Edge Profile Graph*




Figure 133. Relative Threshold—Edge Profile Graph

For relative threshold, the x axis is the length of the ROI. The y axis is the pixel intensity along the ROI, with 0% as the darkest pixel in the ROI and 100% as the lightest pixel in the ROI. The light blue line shows the percentage pixel intensity relative to the horizontal threshold line. The threshold line moves up or down with the percent value.



NOTE: Because the pixel intensity is relative to what is seen in the ROI, this does not necessarily mean that 0% = pure black or that 100% = pure white.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

**Threshold Type: Edge Strength**

Measures the rate of change of grayscale values and needs sharply-defined transitions to find edges.




Figure 134. Edge Strength Threshold Parameters

Edge strength ignores gradual changes in light levels across the tool better than other threshold types and it filters out weak or gradual edges.

*Edge Strength Threshold: Edge Strength*

Enter an edge strength value from 1 to 255.

Edges are selected by the edge strength method, which measures the rate of change from bright to dark or dark to bright. Enter an edge strength threshold in the range from 1 to 255. The default value is 20. As this value is reduced, the tool finds weak, blurry, or more gradual edges.

*Edge Polarity*

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

### Edge Strength Threshold: Edge Profile Graph




Figure 135. Edge Strength Threshold—Edge Profile Graph

For edge strength threshold, the x axis is the length of the ROI. The y axis has two measurements. The first is the light blue axis. It represents Edge Strength, a measure of the rate of change of pixel grayscale values. The second is the dark gray axis. It represents Edge Profile, which gives the absolute grayscale level across the tool ROI. The blue line is the rate of change of the grayscale value along the ROI. The two horizontal gray lines are the edge strength threshold plus and minus.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

### Filters

Set filters for tool analysis.




Figure 136. Edge Tool Filters

#### Smoothing

Runs a rolling average along the ROI length. It filters out sharp changes in the edge profile.



NOTE: A high filter number may miss the edge of a narrow line.

#### Minimum Edge Width

Filters out small spike-of-intensity changes, and narrow dark or bright bands. It determines the distance before and after an edge that must be free from additional transitions or the end of the ROI before the edge is recognized as valid.



NOTE: A high filter number may miss the edge of a narrow line.

## Edge Profile

The Edge Profile graph changes depending on which threshold type is selected. Refer to the Threshold section and the specific threshold types for details on the Edge Profile graph.

## Image Overlays

Chose whether to display or hide the annotations or the ROI when this tool is not selected.




Figure 137. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 138. Show Edge Tool Annotations




Figure 139. Hide Edge Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 140. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 141. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

## 8.5.2 Edge Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.



Figure 142. Edge Tool—Test Parameters

### Total Count

The total number of edges.

### Dark to Bright Count

The total number of edges that start below the threshold value and cross above the threshold value.

### Bright to Dark Count

The total number of edges that start above the threshold value and cross below the threshold value.

### Maximum Edge Strength

The greatest rate of change value observed by the tool.

Available when the Threshold Type is set to Edge Strength.

## 8.5.3 Edge Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

### Total Count

The total number of edges.

Expand Total Count to see the location of each edge.

### Dark to Bright Count

The total number of edges that start below the threshold value and cross above the threshold value.

Expand Dark to Bright Count to see the location of each edge.

### Bright to Dark Count

The total number of edges that start above the threshold value and cross below the threshold value.

Expand Bright to Dark Count to see the location of each edge.

### Maximum Edge Strength

The greatest rate of change value observed by the tool.

Available when the Threshold Type is set to Edge Strength.

### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

### Status

Status and error messages display as appropriate.

## 8.5.4 Using the Edge and Measure Tools

Follow these steps for an example Edge inspection to check the position of a plunger in a syringe.

This procedure uses two Edge tools and a Measure tool to determine the position of the plunger in the barrel.



NOTE: This procedure is an example only.

1. Add an Edge tool to the inspection.
2. Adjust the ROI position, length, and width.
  - a) Position the ROI vertically over the top of the plunger.
  - b) Expand ROI, then expand ROI Width.
  - c) Set the ROI width to 161 px.




Figure 143. ROI Over the Top of the Plunger

3. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) Set the Threshold Type to Edge Strength.
  - c) Leave Edge Strength at the default (20).
  - d) Select Bright to Dark from the Edge Polarity list.

The tool finds the top of the plunger.

4. Add a second Edge tool.
5. Adjust the ROI position, length, and width.
  - a) Position the ROI vertically over the top of the barrel.
  - b) Expand ROI, then expand ROI Width.
  - c) Set the ROI width to 97 px.




Figure 144. ROI Over the Top of the Barrel

6. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) Set the Threshold Type to Edge Strength.
  - c) Expand Edge Strength and set it to 21.
  - d) Select Dark to Bright from the Edge Polarity list.

The tool finds the lower edge of the barrel.

7. Add a Measure tool.
  - a) Expand Measure From... and select Edge02 from the Tool list.
  - b) Expand Measure To... and select Edge01 from the Tool list.




Figure 145. Measure Tool

8. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Distance Y checkbox to enable the test parameter.
  - b) Move the sliders slightly above and below the green line to allow for very slight variations in the distance.



NOTE: The green bar indicates the current distance and the light gray background indicates the distance over time.

9. Click  to show all ROIs at the same time.




Figure 146. All Tools Shown

10. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 147. Good Part




Figure 148. Bad Part—Plunger Too High

## 8.6 Locate Tool

Use the Locate tool to find the edge of a part and to compensate for translation and rotation (if selected).

This tool finds and marks the position of the first edge along the ROI line and aligns and positions related tools consistently over a feature of interest. When Rotation is enabled, the Locate tool calculates the angle at which the tool intersects the feature's edge and rotates the Regions of Interest (ROIs) of downstream tools accordingly.

When a Locate tool is added to an inspection, the inspection fails and there is a red box around Use as Reference. This is because a reference point has not yet been set. Configure the Locate tool as desired, and then set the reference point.

Example application: Adjust inspection tools for a part that moves and/or rotates in the FOV.

## 8.6.1 Locate Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 149. Locate Tool—Input Parameters

Note that the Use as Reference parameter appears as an error until the reference point is set.

### ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.




Figure 150. ROI Parameters

The ROI is a line of pixels that can be shortened, lengthened, or widened as needed for the inspection. Tool analysis follows the direction of the arrow. Set the width and the sample rate for the region of interest. The ROI automatically displays on the Image pane when a tool is added.

#### ROI Width

The ROI width increases in increments of 4 pixels (for example, 1, 5, 9, 13, ...) up to the total FOV size.

Note that:

- Narrow ROIs execute faster but could miss the edge
- Wide ROIs are more consistent but don't execute as fast
- A wide ROI provides an average value/location, which results in improved repeatability
- The ROI must be 13 pixels or wider to calculate the rotation of a part (Locate tool only)

#### Sample Rate

The sample rate sets the number of samples per pixels (one sample per pixel, two samples per pixel, etc.). The sample rate determines the sub-pixel resolution, which increases the resolution of the tool, and increases the inspection time.




Figure 151. 1 px Wide ROI




Figure 152. 13 px Wide ROI

## Threshold

The Threshold parameter marks the grayscale transition point.

The tool marks the edge where the pixel intensity crosses the threshold level. From the Threshold Type list, select one of the following:

- Absolute
- Relative (default)
- Edge Strength

### Threshold Type: Relative

Finds an edge at a relative pixel intensity. This is the default threshold setting.




Figure 153. Relative Threshold Parameters

The brightest grayscale level found along the ROI is 100% and the darkest is 0%. While Relative threshold is more tolerant of light fluctuations between inspections than other transition types, it may find false edges.

### Relative Threshold: Percent

Choose the percentage value at which the edge should be marked.

### Edge Polarity

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

### Relative Threshold: Edge Profile Graph




Figure 154. Relative Threshold—Edge Profile Graph

For relative threshold, the x axis is the length of the ROI. The y axis is the pixel intensity along the ROI, with 0% as the darkest pixel in the ROI and 100% as the lightest pixel in the ROI. The light blue line shows the percentage pixel intensity relative to the horizontal gray threshold line. The threshold line moves up or down with the percent value.



NOTE: Because the pixel intensity is relative to what is seen in the ROI, this does not necessarily mean that 0% = pure black or that 100% = pure white.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

*Threshold Type: Absolute*

Finds an edge at a specific grayscale level.




Figure 155. Absolute Threshold Parameters

While Absolute threshold is less likely to find a false edge than Relative threshold, it may miss edges if the light level changes between inspections.

*Absolute Threshold: Value*

Enter a specific grayscale value from 0 to 255.

*Edge Polarity*

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

*Absolute Threshold: Edge Profile Graph*




Figure 156. Absolute Threshold—Edge Profile Graph

For absolute threshold, the x axis is the length of the ROI. The y axis is the actual grayscale value from 0 to 255. The light blue line shows the absolute pixel intensity. The horizontal gray threshold line moves up or down with the threshold value.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

## Threshold Type: Edge Strength

Measures the rate of change of grayscale values and needs sharply-defined transitions to find edges.




Figure 157. Edge Strength Threshold Parameters

Edge strength ignores gradual changes in light levels across the tool better than other threshold types and it filters out weak or gradual edges.

### Edge Strength Threshold: Edge Strength

Enter an edge strength value from 1 to 255.

Edges are selected by the edge strength method, which measures the rate of change from bright to dark or dark to bright. Enter an edge strength threshold in the range from 1 to 255. The default value is 20. As this value is reduced, the tool finds weak, blurry, or more gradual edges.

### Edge Polarity

Edge Polarity defines the type of edges the tool will find.

- Dark to Bright—Finds edges where pixel intensities start below the threshold value and cross above the threshold value
- Bright to Dark—Finds edges where pixel intensities start above the threshold value and cross below the threshold value
- Bright or Dark—Finds any edge

### Edge Strength Threshold: Edge Profile Graph




Figure 158. Edge Strength Threshold—Edge Profile Graph

For edge strength threshold, the x axis is the length of the ROI. The y axis has two measurements. The first is the light blue axis. It represents Edge Strength, a measure of the rate of change of pixel grayscale values. The second is the dark gray axis. It represents Edge Profile, which gives the absolute grayscale level across the tool ROI. The blue line is the rate of change of the grayscale value along the ROI. The two horizontal gray lines are the edge strength threshold plus and minus.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

## Filters

Set filters for tool analysis.



Figure 159. Locate Tool Filters

### Smoothing

Runs a rolling average along the ROI length. It filters out sharp changes in the edge profile.



NOTE: A high filter number may miss the edge of a narrow line.

### Minimum Edge Width

Filters out small spike-of-intensity changes, and narrow dark or bright bands. It determines the distance before and after an edge that must be free from additional transitions or the end of the ROI before the edge is recognized as valid.



NOTE: A high filter number may miss the edge of a narrow line.

### Enable Rotation

Runs a rotation compensation calculation when enabled. ROIs that follow rotate according to the difference between the reference image and the current inspection image.

## Edge Profile

The Edge Profile graph changes depending on which threshold type is selected. Refer to the Threshold section and the specific threshold types for details on the Edge Profile graph.

## Use as Reference

Choose whether to use this tool as a reference for other tools.




Figure 160. Use As Reference—No Reference Point Set




Figure 161. Use As Reference—Reference Point Set

### Adjust Downstream Tool ROIs

Select Adjust Downstream Tool ROIs to have tools added after this tool use the this tool to set the location of the additional ROIs.

Click Set Reference Point button so that the tool affects the related tools, otherwise the tool and all related tools will fail. If changes are made to the tool parameters that affect the reference point, the reference point must be set again.

### Force to Absolute

Select Force to Absolute to change this tool from relative positioning to absolute positioning.

When disabled, the tool ROI positions itself independent to any other locational tool preceding it in the inspection.

## Image Overlays

Chose whether to display or hide the annotations or the ROI when this tool is not selected.




Figure 162. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 163. Show Locate Tool Annotations




Figure 164. Hide Locate Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 165. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 166. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail

- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 8.6.2 Locate Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 167. Locate Tool—Test Parameters

#### Edge Point X

The x coordinate of the Edge Point; the first suitable edge that the Locate tool found.

#### Edge Point Y

The y coordinate of the Edge Point; the first suitable edge that the Locate tool found.

#### Edge Angle

The angle with respect to horizontal at which the Locate tool intersects the part.

#### Offset Point X

The x-dimension offset between the current Edge Point and the reference point.

Available when Adjust Downstream Tool ROI s is enabled.

#### Offset Point Y

The y-dimension offset between the current Edge Point and the reference point.

Available when Adjust Downstream Tool ROI s is enabled.

#### Offset Angle

The angular difference between the current Edge Angle and the angle from the reference point.

Available when Adjust Downstream Tool ROI s is enabled.

#### Maximum Edge Strength

A measure of how much bright/dark contrast is found in the current Edge Point. A high number indicates an edge for which the grayscale value changed rapidly.

Available when the Threshold is set to Edge Strength.

### 8.6.3 Locate Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Edge Point

The x and y coordinates of the Edge Point; the first suitable edge the Locate tool found.

#### Edge Angle

The angle with respect to horizontal at which the Locate tool intersects the part.

### Offset

The offset between the Edge Point and the reference point.

Expand Offset to see the coordinates of the Reference Point, the Reference Angle, the Offset Point, and the Offset Angle.

### Maximum Edge Strength

The greatest rate of change value observed by the tool.

Available when the Threshold Type is set to Edge Strength.

### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

### Status

Status and error messages display as appropriate.

## 8.6.4 Using the Locate Tool

Follow these steps for an example Locate inspection to adjust for a target that moves in the field of view, allowing for the precise placement of the vision tools that follow the Locate tool.

This procedure uses a Locate tool to determine the position of the vial. Using the vial position information, three Edge tools and two Measure tools determine the position of the stopper. The Locate tool is used to ensure that the Edge02 and Edge03 tools are placed correctly alongside (but not on top of) the vial, even if the vial targets move from side to side in the field of view from inspection to inspection. See [Using the Edge and Measure Tools](#) on page 86 for details on how to set up an Edge tool and a Measure tool.



NOTE: This procedure is an example only.

1. Add a Locate tool to the inspection.
2. Adjust the ROI position, length, and width.
  - a) Position the ROI horizontally across the side of the vial.
  - b) Leave the ROI Width at the default (13 px).




Figure 168. Locate ROI

3. Find the edge that you want the tool to locate.
  - a) Expand the Edge Profile parameters. Use the graph as a guide for the remaining steps.
 

To make sure that you find the edge you want, observe how the Edge Profile graph changes as the Inputs change. Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image. The horizontal gray line is the Threshold percent.
  - b) Expand the Threshold parameters.
  - c) Select Edge Strength from the Threshold Type list.
  - d) Select Bright to Dark from the Edge Polarity list.
  - e) Adjust the Edge Strength until only the desired edge is found. In this example it is 20.
4. Expand Filters and set Smoothing to Smooth3 to filter out sharp changes in the edge profile.
5. Set the reference point.
  - a) Expand the Use as Reference parameters.
  - b) Leave Adjust Downstream Tool ROI's checked so that it is enabled (default).
  - c) Click Set Reference Point.
 

A blue circle displays on the Image pane at the location of the reference point and all following tools use this point as a reference.




Figure 169. Reference Point

6. If the blue circle does not represent the desired reference point, repeat steps 3 to 5 and adjust the parameters until the desired reference point is found.
7. Add an Edge tool to detect the top of the stopper.



Figure 170. Edge Tool at the Top of the Stopper

8. Add an Edge tool to detect the bottom of the lip on the left side of the vial.




Figure 171. Edge Tool at the Left Side of the vial

9. Add an Edge tool to detect the bottom of the lip on the right side of the vial.




Figure 172. Edge Tool at the Right Side of the vial

10. Add a Measure tool to measure from Edge02 (the left side of the vial) to Edge03 (the right side of the vial).



Figure 173. Measure Tool from Edge02 to Edge03

11. Add a Measure tool to measure from Edge01 to Measure01 to determine the position of the stopper in the vial.



Figure 174. Measure Tool from Edge01 to Measure01

12. Adjust the Measure02 Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Distance Y checkbox to enable the test parameter.
  - b) Move the sliders slightly above and below the green line to allow for very slight variations in the distance.



NOTE: The green bar indicates the current distance and the light gray background indicates the distance over time.

13. Click  to show all ROIs at the same time.



Figure 175. All Tools Shown

14. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.



Figure 176. Bad Part—Stopper Too High



Figure 177. Bad Part—Missing Stopper

## 8.7 Match Tool

Use the Match tool to verify that a pattern, shape, or part in any orientation matches a reference pattern. The Match tool can also compensate for translation and rotation of downstream tools (if selected).

The reference pattern is taught during setup. A reference pattern might include alphanumeric characters, logos, or any other shapes. During an inspection, the sensor checks that each part or package being inspected matches the reference pattern. The number of expected patterns can also be determined.

When a Match tool is added to an inspection, the inspection fails and there is a red box around Pattern. This is because a reference pattern has not yet been taught. Configure the Teach ROI as desired, and then teach the reference pattern.

Example applications:

- Date/Lot code inspections
- Label inspections
- Part etching inspections
- Part orientation inspections
- Part shape inspections

### 8.7.1 Match Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 178. Match Tool—Input Parameters

### Search ROI

The Search Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.



Figure 179. Search ROI

The Search ROI is indicated by a red or green box that is always rectangular. By default the Search ROI is 20% to 30% larger than the Teach ROI, which is blue. The sensor searches for the match only within the Search ROI.

Resize  the Search ROI as needed for the inspection.

### Teach ROI

The Teach Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor uses to teach a reference pattern.



Figure 180. Teach ROI

Resize  and rotate  the ROI around the feature to be used as the reference pattern. Change the shape of the ROI to a square, ellipse, or circle as needed by expanding Teach ROI on the Parameters pane and selecting the desired shape. The Teach ROI automatically displays on the Image pane when a Match tool is added.

### Pattern

Displays the reference pattern that the sensor is looking for. A teach is required for the Match tool. Click Teach to set the match tool criteria and display the reference pattern.




Figure 181. Teach Required




Figure 182. Pattern Taught

A red error displays until the teach is performed and the reference pattern is taught. When new patterns are added, you will need to teach the reference pattern again.

### Percent Match

Set the percent match to indicate the quality of the match (10% is a slight match; 100% is a perfect match). The default is 60%.




Figure 183. Percent Match

### Rotation Range

Select the range within which the pattern may be rotated and still count as a match to the reference image. The default is 45 degrees.




Figure 184. Rotation Range

The larger the Rotation Range, the longer the execution time of the tool. In general, this means that the execution time of the inspection increases.

### Precision

Select either Fine Search or Coarse Search. Course Search is the default. Fine Search is slower but provides more accurate results.




Figure 185. Precision

### Timeout

Set the amount of time the tool looks for the pattern before it stops.




Figure 186. Timeout

## Use as Reference

Choose whether to use this tool as a reference for other tools.




Figure 187. Use As Reference—No Reference Point Set




Figure 188. Use As Reference—Reference Point Set

### Adjust Downstream Tool ROIs

Select Adjust Downstream Tool ROIs to have tools added after this tool use the this tool to set the location of the additional ROIs.

Click Set Reference Point button so that the tool affects the related tools, otherwise the tool and all related tools will fail. If changes are made to the tool parameters that affect the reference point, the reference point must be set again.

### Force to Absolute

Select Force to Absolute to change this tool from relative positioning to absolute positioning.

When disabled, the tool ROI positions itself independent to any other locational tool preceding it in the inspection.

## Image Overlays

Chose whether to display or hide the annotations or the ROI when this tool is not selected.




Figure 189. Image Overlays—Default

These options override the ROI view buttons on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.



Figure 190. Show Match Tool Annotations



Figure 191. Hide Match Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 192. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 193. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 8.7.2 Match Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 194. Match Tool—Test Parameters

#### Count

The number of matching patterns.

#### Individual Matches

Specific Match—Select First Match or Specific Match.

Centroid X—The location of the point of the center of mass of the selected match on the x axis.

Centroid Y—The location of the point of the center of mass of the selected match on the y axis.

Angle—The rotated angle of the matching object.

#### Offset Point X

The x-dimension offset between the current match and the reference point.

Available when Adjust Downstream Tool ROI's is enabled.

#### Offset Point Y

The y-dimension offset between the current match and the reference point.

Available when Adjust Downstream Tool ROI's is enabled.

#### Offset Angle

The angular difference between the current angle and the angle from the reference point.

Available when Adjust Downstream Tool ROI's is enabled.

## 8.7.3 Match Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Count

The number of matching patterns.

#### Percentage Range

The percentage by which the found objects match the reference object. Expand Percentage Range to view the centroid (center point), angle, and percent match for the objects found within the ROI.

#### Offset

The offset between the match and the reference point.

Available when Adjust Downstream Tool ROI's is enabled.

Expand Offset to see the coordinates of the Reference Point, the Reference Angle, the Offset Point, and the Offset Angle.

#### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

#### Status

Status and error messages display as appropriate.

### 8.7.4 Using the Match Tool

Follow these steps for an example Match inspection. The Match tool requires that a reference pattern be taught during set up.

The Match tool uses two ROIs. The larger, green/red ROI is the Search ROI and defines the area that the sensor searches for the desired feature. This ROI cannot be rotated and it is always a square. The smaller, blue ROI is the Teach ROI. This ROI is used to define the feature that the sensor is looking for.

Before using the Match tool, teach the desired feature (reference pattern). While setting up a Match tool, it can be helpful to slow the trigger rate or to set the trigger to external.



NOTE: If the trigger is set to internal, there is a lag between when the TEACH occurs and when Vision Manager uses the taught feature to inspect the part(s). The time to teach the sensor is not included in the inspection time on Tools & Results or All Results.



NOTE: This procedure is an example only.

1. Add a Match tool to the inspection.

Note that the inspection fails and a warning displays until the reference pattern is taught.




Figure 195. Match Tool Defaults

2. Adjust the Teach ROI to frame the feature to be used as the reference pattern. In this case, the feature is the Banner logo.

- a) Expand Teach ROI and select the ellipse.
- b) Resize  and rotate  the ROI around the feature.

- On the Parameters pane, expand Pattern and click Teach.




Figure 196. Teach Required




Figure 197. Pattern Taught



NOTE: If the inspection uses more than one Match tool, teach only one Match tool at a time.

"Applying Changes" displays, and then the reference pattern displays in the Pattern pane and Tools & Results and All Results display one match.

- If necessary, repeat steps 2 and 3 to teach the feature again.
- Adjust the Search ROI to fill the FOV.



Figure 198. Teach and Search ROIs Configured

- Expand Percent Match and set it to 99.  
The found pattern must closely match the taught reference pattern.
- Expand Rotation Range and set it to 90.  
The found pattern can rotate by 90 degrees and still pass.



NOTE: Rotation Range and Percent Match work together. The higher the Percent Match, the lower the Rotation Range to pass. In this example a 99% match fails a missing letter but passes a match that is rotated 45 degrees.

- On the Test tab, select the Count checkbox to enable the Count test parameter.
- Expand Count and set it to a minimum of 1 and a maximum of 1.  
One and only one matching pattern must be found for the inspection to pass.

10. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 199. Rotated Good Part



Figure 200. Bad Part—Missing Letter

### 8.7.5 Using Remote TEACH with the Match Tool

If multiple Match tools are used in the same inspection, remote TEACH teaches all Match tools at the same time using the same trigger.

The time to teach is included in the inspection time on Tools & Results and All Results.

1. Set up the inspection and Match tool(s) as desired.
2. In Vision Manager, make sure that one of the five user-defined I/O is set to Remote Teach.
3. Toggle the Remote Teach input. The next valid Trigger input causes the Remote Teach to occur. This is when the new Match patterns are learned.



## 8.8 Object Tool

Use the Object tool to detect and measure the length of dark and bright segments in an ROI.

The Object tool measures the widths of every dark and light segment along the ROI, calculates the midpoint for every segment, and counts the total number of segments. The midpoint location can be used as an input to the Measure tool. Each segment can have a unique size limit, or all segments may have the same size limit.

Example applications:

- Measure the width of a label
- Locate the center of a box on a conveyor
- Measure the gaps between stamped metal parts

### 8.8.1 Object Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.



Figure 201. Object Tool—Input Parameters

## ROI

The Region of Interest (ROI) is the user-defined group of pixels in the image that the sensor analyzes.




Figure 202. ROI Parameters

The ROI is a line of pixels that can be shortened, lengthened, or widened as needed for the inspection. Tool analysis follows the direction of the arrow. Set the width and the sample rate for the region of interest. The ROI automatically displays on the Image pane when a tool is added.

### ROI Width

The ROI width increases in increments of 4 pixels (for example, 1, 5, 9, 13, ...) up to the total FOV size.

Note that:

- Narrow ROIs execute faster but could miss the edge
- Wide ROIs are more consistent but don't execute as fast
- A wide ROI provides an average value/location, which results in improved repeatability
- The ROI must be 13 pixels or wider to calculate the rotation of a part (Locate tool only)

### Sample Rate

The sample rate sets the number of samples per pixels (one sample per pixel, two samples per pixel, etc.). The sample rate determines the sub-pixel resolution, which increases the resolution of the tool, and increases the inspection time.




Figure 203. 1 px Wide ROI




Figure 204. 13 px Wide ROI

## Threshold

The Threshold parameter marks the grayscale transition point.

The tool marks the edge where the pixel intensity crosses the threshold level. From the Threshold Type list, select one of the following:

- Absolute
- Relative (default)
- Edge Strength

### Threshold Type: Relative

Finds an edge at a relative pixel intensity. This is the default threshold setting.




Figure 205. Relative Threshold Parameters

The brightest grayscale level found along the ROI is 100% and the darkest is 0%. While Relative threshold is more tolerant of light fluctuations between inspections than other transition types, it may find false edges.

*Relative Threshold: Percent*

Choose the percentage value at which the edge should be marked.

*Object Type*

Select the type of object the inspection is looking for.

- Bright—Finds objects brighter than the threshold value
- Dark—Finds objects darker than the threshold value
- Bright or Dark—Finds any object

*Relative Threshold: Edge Profile Graph*




Figure 206. Relative Threshold—Edge Profile Graph

For relative threshold, the x axis is the length of the ROI. The y axis is the pixel intensity along the ROI, with 0% as the darkest pixel in the ROI and 100% as the lightest pixel in the ROI. The light blue line shows the percentage pixel intensity relative to the horizontal gray threshold line. The threshold line moves up or down with the percent value.



NOTE: Because the pixel intensity is relative to what is seen in the ROI, this does not necessarily mean that 0% = pure black or that 100% = pure white.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

*Threshold Type: Absolute*

Finds an edge at a specific grayscale level.




Figure 207. Absolute Threshold Parameters

While Absolute threshold is less likely to find a false edge than Relative threshold, it may miss edges if the light level changes between inspections.

### Absolute Threshold: Value

Enter a specific grayscale value from 0 to 255.

### Object Type

Select the type of object the inspection is looking for.

- Bright—Finds objects brighter than the threshold value
- Dark—Finds objects darker than the threshold value
- Bright or Dark—Finds any object

### Absolute Threshold: Edge Profile Graph




Figure 208. Absolute Threshold—Edge Profile Graph

For absolute threshold, the x axis is the length of the ROI. The y axis is the actual grayscale value from 0 to 255. The light blue line shows the absolute pixel intensity. The horizontal gray threshold line moves up or down with the threshold value.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

### Threshold Type: Edge Strength

Measures the rate of change of grayscale values and needs sharply-defined transitions to find edges.




Figure 209. Edge Strength Threshold Parameters

Edge strength ignores gradual changes in light levels across the tool better than other threshold types and it filters out weak or gradual edges.

### Edge Strength Threshold: Edge Strength

Enter an edge strength value from 1 to 255.

Edges are selected by the edge strength method, which measures the rate of change from bright to dark or dark to bright. Enter an edge strength threshold in the range from 1 to 255. The default value is 20. As this value is reduced, the tool finds weak, blurry, or more gradual edges.

### Object Type

Select the type of object the inspection is looking for.

- Bright—Finds objects brighter than the threshold value

- Dark—Finds objects darker than the threshold value
- Bright or Dark—Finds any object

### Edge Strength Threshold: Edge Profile Graph




Figure 210. Edge Strength Threshold—Edge Profile Graph

For edge strength threshold, the x axis is the length of the ROI. The y axis has two measurements. The first is the light blue axis. It represents Edge Strength, a measure of the rate of change of pixel grayscale values. The second is the dark gray axis. It represents Edge Profile, which gives the absolute grayscale level across the tool ROI. The blue line is the rate of change of the grayscale value along the ROI. The two horizontal gray lines are the edge strength threshold plus and minus.

Point to a location on the graph—the corresponding location is the yellow line on the tool ROI displayed on the image.

### Filters

Set filters for tool analysis.




Figure 211. Object Tool Filters

#### Smoothing

Runs a rolling average along the ROI length. It filters out sharp changes in the edge profile.

#### Object Width

Filters out objects and spaces that are smaller than the minimum and larger than the maximum values specified.

#### Enable End Objects

When enabled, pixels that touch the ends of the ROI are ignored. This may ignore one or more objects.

## Edge Profile

The Edge Profile graph changes depending on which threshold type is selected. Refer to the Threshold section and the specific threshold types for details on the Edge Profile graph.

## Image Overlays

Chose whether to display or hide the annotations or the ROI when this tool is not selected.




Figure 212. Image Overlays—Default

These options override the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.

### Hide Annotations

Hides the annotations on the live image for the tool, even when the tool is selected.




Figure 213. Show Object Tool Annotations




Figure 214. Hide Object Tool Annotations

### Hide ROI

Hides the ROI when the tool is not selected.

## Tool Histogram

The Tool Histogram graphically displays pixel intensity information within the current ROI.




Figure 215. Example Histogram

Select the Tool Histogram checkbox to enable the histogram. The default is enabled. Expand the Tool Histogram parameter to view the histogram.

The histogram is a display of the grayscale values on the x axis and the number of pixels on the y axis. The histogram displays the amount of pixels for each grayscale value. The graph displays information for all grayscale values (0 to 255). Move the pointer anywhere over the histogram to view specific information. The information updates as the position of the pointer changes.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 216. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 8.8.2 Object Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.

Where applicable, use the sliders or enter the minimum and maximum for the selected test parameters.




Figure 217. Object Tool—Test Parameters

#### Total Count

The total number of bright, dark, or all objects, depending on the bright/dark option in effect.

#### Dark Count

The number of dark objects.

#### Bright Count

The number of bright objects.

#### Maximum Edge Strength

The greatest rate of change value observed by the tool.

Available when the Threshold Type is set to Edge Strength.

#### Individual Objects

Object(s) to test—Select All Objects, First Object, or Specific Object.

All Dark Width Range—Select the range of dark widths to count.

All Bright Width Range—Select the range of bright widths to count.

### 8.8.3 Object Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Total Count

The total number of bright, dark, or all objects, depending on the bright/dark option in effect.

#### Dark Count

The number of dark objects.

#### Bright Count

The number of bright objects.

**Total Widths**

The minimum and maximum total widths of the objects found.

Expand Total Widths to view the widths and location of the objects found.

**Dark Widths**

The minimum and maximum widths of the dark objects found.

Expand Dark Widths to view the widths and location of the dark objects found.

**Bright Widths**

The minimum and maximum widths of the bright objects found.

Expand Bright Widths to view the widths and location of the bright objects found.

**Maximum Edge Strength**

The greatest rate of change value observed by the tool.

Available when the Threshold Type is set to Edge Strength.

**Execution Time**

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

**Status**

Status and error messages display as appropriate.

## 8.8.4 Using the Object Tool

Follow these steps for an example Object inspection.

This example verifies the number and position of pins on a connector by analyzing the size of the two gaps between the pins.



NOTE: This procedure is an example only.

1. Add an Object tool to the inspection.
2. Adjust the position, length, and width of the ROI.
  - a) Move the ROI so that it crosses all of the pins.
  - b) Leave the default ROI width (13 px).




Figure 218. Object Tool

3. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) Leave the Threshold Type as the default (Relative).
  - c) Leave the Percent as the default (50).
  - d) Select Dark from the Object Type list.
4. Set the Test parameters to set the pass/fail criteria.
  - a) Expand Individual Objects.
  - b) Select the All Dark Width Range checkbox to enable the parameter.
  - c) Move the sliders or enter the minimum as 141.48 and the maximum as 252.96.

5. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.



Figure 219. Good Part



Figure 220. Bad Part—Bent Pin

# 9 Using the Inspection Tools: Analysis Tools

Analysis tools include Math, Measure, and Logic.

Click a tool on Tools & Results or Tools Only to access the Parameters pane for that tool.

## 9.1 Math Tool

Use the Math tool to perform basic arithmetic and inequality expressions, and calculate statistical information for inspections.

The Math tool takes one or more pieces of information from the tool data or user-supplied constants and makes mathematical expressions out of them. The results of the Math tool's analysis are displayed in Tools & Results and All Results.

The inputs to the Math tool are called operands. The operation is the mathematical expression used on the operands.

In general, a user-defined constant can be selected as one of the operands for the Math tool. This allows for a number of things, including scaling the output of a vision tool in real units (by dividing that output by a known conversion factor). Dynamic scaling of outputs is also possible by dividing one operand by another and then multiplying by a constant conversion factor. In this case, two Math tools would be used: one set for division, the other for multiplication. The output of the first Math tool would be an operand for the second Math tool.

Example application: Add advanced logic to an inspection using arithmetic or inequality expressions.

### 9.1.1 Math Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.



Figure 221. Math Tool—Input Parameters

### Operator

Select the type of mathematical expression used for the inspection operator.




Figure 222. Operator

Table 2: Single Operand Operations

Single operand operations require one input.

Operator	Summary	Description
ABS {A}	ABS(1) = 1	The absolute value of an operand is its unsigned magnitude. For example, Abs(-1.5) and Abs(1.5) both return 1.5
SQRT {A}	SQRT(1) = 1	The square root of the operand

Table 3: Dual Operand Operations

Dual operand operations require two inputs (operand A and operand B). For each operand, specify the tool (or a constant) and the specific attribute of interest for that tool.

Operator	Summary	Description
A + B	1 + 1 = 2	Add
A - B	1 - 1 = 0	Subtract
A * B	1 × 1 = 1	Multiply
A / B	1 ÷ 1 = 1	Divide
MOD {A, B}	1 % 1 = 0	Modulus; the modulus, or remainder, operator divides operand A by operand B and returns the remainder
Div {A, B}	1 ÷ 1 = 1	Integer division; returns the integer part of division, and the remainder is discarded
ABS (A - B)	1 - 1  = 0	Returns the absolute value of operand A – B
A > B	1 > 1 = false	Greater than; returns True, else False
A ≥ B	1 ≥ 1 = true	Greater than or equal to; returns True, else False
A = B	1 = 1 = true	Equal to; returns True, else False
A < B	1 < 1 = false	Less than; returns True, else False
A ≤ B	1 ≤ 1 = true	Less than or equal to; returns True, else False

If the output of a relational operation is used as an input for another Math Tool, True is interpreted as 1 and False is interpreted as 0.

Table 4: Array Operand Operations

Array Operations allow the user to make a long list of input data. All of these pieces of information are inputs to the selected operator. For example, select MIN{A} as the operator, and select an input tool.

Operator	Description
MIN{A}	Minimum—Returns the operand with the lowest value
MAX{A}	Maximum—Returns the operand with the highest value
MEAN{A}	Returns the mean value of the operands
MEDIAN{A}	The statistical median is the middle number of a group of numbers that have been arranged in order by size. If there is an even number of terms, the median is the mean of the two middle numbers.
COUNT{A}	Returns the count of the operands
SUM{A}	Returns the arithmetic sum of the operands
VAR{A}	Variance—A measure of how spread out the operands values are
STDDEV{A}	Standard Deviation—A measure of how spread out the operands values are

### Operand A

Choose the first variable from the vision tools in the inspection, or select a user-defined constant value.




Figure 223. Operand A

## Operand B

Choose the second variable from the vision tools in the inspection, or select a user-defined constant value.




Figure 224. Operand B

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 225. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 9.1.2 Math Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool. Select the parameter checkbox to enable it.




Figure 226. Math Tool—Test Parameters

Integer

The integer value range of the Math tool operation.

Decimal

The decimal value range of the Math tool operation.

Boolean

The boolean result for the Math tool operation.

### 9.1.3 Math Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Integer Result

The integer value result of the Math tool operation.

#### Decimal Result

The decimal result of the Math tool operation.

#### Boolean

The boolean result for the Math tool operation.

#### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

#### Status

Status and error messages display as appropriate.

### 9.1.4 Using the Math Tool

Follow these steps for an example Math inspection.

This example uses two Edge tools and a Math tool to determine whether the number of edges found by Edge01 is greater than the number of edges found by Edge02. See [Using the Edge and Measure Tools](#) on page 86 for more information on using the Edge tool.



NOTE: This procedure is an example only.

1. Add an Edge tool to the inspection.
2. Move the Edge01 ROI over the shapes in the image.




Figure 227. Edge01 ROI

3. Add a second Edge tool to the inspection.
4. Move the Edge02 ROI over the black area of the image.




Figure 228. Edge02 ROI

5. Add a Math tool to the inspection.
6. Expand Operator and choose a mathematical function to perform. For this example, select  $A > B$ .
7. Expand Operand A and select Edge01. This is the first variable or constant for the mathematical expression.
8. Expand Operand B and select Edge02. This is the second variable or constant for the mathematical expression.

9. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Boolean checkbox.  
This option sets whether the mathematical expression is true or false so that the part passes.
  - b) Select True.  
Edge01 must find more edges than Edge02 for a part to pass.
10. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 229. Edge02 ROI




Figure 230. Edge02 ROI

## 9.2 Measure Tool

Use the Measure tool to determine distances, calculate angles, and create points and lines for use as inputs to other Measure tools.

The Measure tool operations are:

- Measure from a point to a point
- Determine the intersection between two lines
- Measure from a line to a point

The points used in these operations are generated by a variety of vision tools and the lines are created by other Measure tools.

Example applications:

- Determine the distance between blobs
- Measure the width of a label
- Determine if two edges are parallel to each other

### 9.2.1 Measure Tool: Operations

#### Measure from a Point to a Point

In this operation, the distance between two points is calculated. In addition, the x and y components of that distance calculation are returned.

Along with distance, the following results are generated in this operation:

- A line from point 1 to point 2
- The angle of that line (relative to the x-axis)
- The midpoint location halfway between point 1 and point 2

#### How the Tool Measures Two Points

The inputs to the Measure tool for measuring two points are any two points that Vision tools generate.

The results include the total distance between the points and the x and y component distances. In addition to finding these distance values, the Measure tool also calculates the line between the two endpoints. The angle between this line and the camera's horizontal plane, as well as the coordinates for the line's midpoint, are also provided.

For example, a Measure01 measurement between the two points Edge01 and Edge02 appears as a dashed line. The actual measured distance between the points is a solid green line labeled Measure01 and an arrowhead indicates the direction of the measurement operation (from Edge01 to Edge02, in this case). A blue circle is the midpoint. Two shorter dashed lines represent the x and y components. The angle between Measure01 and the horizontal plane is a curved arrow. The results show the angle in degrees.

See [Using the Edge and Measure Tools](#) on page 86 for a Measure tool example.

## Intersect Two Lines

In this operation, the results of the intersection of two lines is generated. These results are:

- The angle of intersection between the two lines, measure from line 1 to line 2
- The intersection point, even if this point is not in the image

### How the Tool Measures Two Lines

This mode finds the angle between two lines. Both inputs are the line outputs from existing Measure tools. The order in which these tools are input matters.

The intersection point can well be off the screen. This angle gives the ability to measure two lines for parallelism.

For example, if you have two inputs that are both existing Measure tools, Measure01 and Measure02, the output, called Measure03, is the angle between the lines of each of the inputs. Measure03 is a curved arrow from the first input, Measure01, towards the arrowhead of the second input, Measure02. The results show this angle in degrees. The intersection point of the two best fit lines is also provided in the results and is shown by the blue circle in the image pane.

See [Using the Edge and Measure Tools](#) on page 86 for a Measure tool example.

### Measure from a Line to a Point

In this operation, the software calculates the distance between a line and a point. This is the shortest distance from the line to the point, and is generated by creating a line perpendicular to the original line that intersects the point. In addition, it returns the distance calculations for the X and Y component.

Additionally, the following results are generated in this operation:

- The perpendicular line, which goes from the line to the point
- The angle of that line (relative to the x-axis)
- The intersection point between the original line and the perpendicular line

### How the Tool Measures a Line and a Point

This mode finds the shortest distance between a point and a line.

The two inputs to the Measure tool are:

- Any point a vision tool generates
- Any line another measure tool generates

The shortest distance between a line and a point may lie along another line. This new line may be perpendicular to the original line.

For example, the center point of a blob, Blob01, and the nearest point in the input line Measure01 define a dashed line. The actual measured distance between Blob01 and Measure01 is labeled Measure02. A blue circle shows where Measure01 and Measure02 intersect. The results show the distance between the intersection point and the blob midpoint in pixels. Two shorter dashed lines represent the x and y components. The angle between Measure02 and the horizontal plane is a curved arrow. The results show this angle in degrees.

See [Using the Edge and Measure Tools](#) on page 86 for a Measure tool example.

## 9.2.2 Measure Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 231. Measure Tool—Input Parameters

## Measure from...

Select either a constant or another tool where the Measure tool will start measuring from.




Figure 232. Measure From...—Specific Tool Selected

If selecting a constant, enter the x and y coordinates to begin the measurement from. The coordinates are entered in pixels, however if Units is enabled, the value entered in pixels is converted to units for the calculation.

If selecting a specific tool, select the specific characteristic in the tool to measure from.

## Measure to...

Select either a constant or another tool where the Measure tool will stop measuring.




Figure 233. Measure To...—Constant Selected

If selecting a constant, enter in the x and y coordinates to end the measurement at. The coordinates are entered in pixels, however if Units is enabled, the value entered in pixels is converted to units for the calculation.

If selecting a specific tool, select the specific characteristic in the tool to measure to.

## Characteristics

Set additional parameters for the inspection.




Figure 234. Characteristics

### Preserve Sign

When Preserve Sign is selected, the x and y distances are computed as distance offsets. These distance offsets are represented by signed numbers. Negative numbers indicate that the distance offset is toward the origin (0,0). Positive numbers indicate that the distance offset is away from the origin.

### Force to Absolute

Select Force to Absolute to change the tool from calculating the x and y components of the measurement from relative positioning to absolute positioning. When disabled, the tool ROI positions itself independent to any other reference tool preceding it in the inspection.

## Image Overlays

Choose whether to display or hide the annotations when this tool is not selected.




Figure 235. Image Overlays

This option overrides the ROI view buttons  on the Image Pane Parameters when no tool is selected. When a specific tool is selected, the ROI information is shown.




Figure 236. Show Measure Tool Annotations




Figure 237. Hide Measure Tool Annotations

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 238. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 9.2.3 Measure Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool.

Select the parameter checkbox to enable it. Where applicable, the vertical green bar shows the current parameter information and the light gray backgrounds show the range over which a value has varied over time.




Figure 239. Measure Tool—Test Parameters

#### Distance

The straight-line distance between two constants or tools.

#### Distance X

The x dimension vector component of the straight line distance.

#### Distance Y

The y dimension vector component of the straight line distance.

#### Angle

The angle with respect to the x axis, along which the straight line measurement vector lies. If the tool is measuring from one Line tool to another Line tool, the Angle is the measurement of the angle formed by the two lines. If the Force to Absolute parameter is selected, the angle is calculated relative to the reference tool that precedes the Measure tool.

### 9.2.4 Measure Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

**Distance**

The straight-line distance between two constants or tools.

**Distance X**

The x dimension vector component of the straight line distance.

**Distance Y**

The y dimension vector component of the straight line distance.

**Angle**

The angle with respect to the x axis, along which the straight line measurement vector lies. If the tool is measuring from one Line tool to another Line tool, the Angle is the measurement of the angle formed by the two lines. If the Force to Absolute parameter is selected, the angle is calculated relative to the reference tool that precedes the Measure tool.

**Mid Point**

The x and y coordinates of the middle point between the two selected points.

Mid Point is calculated for point to point measurements only.

**Projection Point**

The x and y coordinates of the intersection point on the input line to a virtual line that is orthogonal to the input line and which the input point lies on the virtual line.

Projection Point is calculated for line to point measurements only.

**Intersection Point**

The x and y coordinates of the intersection point of two non-coincident input lines.

Intersection Point is calculated for line to line measurements only.

**Execution Time**

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

**Status**

Status and error messages display as appropriate.

## 9.2.5 Using the Edge and Measure Tools

Follow these steps for an example Edge inspection to check the position of a plunger in a syringe.

This procedure uses two Edge tools and a Measure tool to determine the position of the plunger in the barrel.



NOTE: This procedure is an example only.

1. Add an Edge tool to the inspection.
2. Adjust the ROI position, length, and width.
  - a) Position the ROI vertically over the top of the plunger.
  - b) Expand ROI, then expand ROI Width.
  - c) Set the ROI width to 161 px.




Figure 240. ROI Over the Top of the Plunger

3. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) Set the Threshold Type to Edge Strength.
  - c) Leave Edge Strength at the default (20).
  - d) Select Bright to Dark from the Edge Polarity list.The tool finds the top of the plunger.
4. Add a second Edge tool.
5. Adjust the ROI position, length, and width.
  - a) Position the ROI vertically over the top of the barrel.
  - b) Expand ROI, then expand ROI Width.
  - c) Set the ROI width to 97 px.




Figure 241. ROI Over the Top of the Barrel

6. Set the threshold.
  - a) Expand the Threshold parameters.
  - b) Set the Threshold Type to Edge Strength.
  - c) Expand Edge Strength and set it to 21.
  - d) Select Dark to Bright from the Edge Polarity list.The tool finds the lower edge of the barrel.
7. Add a Measure tool.
  - a) Expand Measure From... and select Edge02 from the Tool list.
  - b) Expand Measure To... and select Edge01 from the Tool list.




Figure 242. Measure Tool

8. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Distance Y checkbox to enable the test parameter.
  - b) Move the sliders slightly above and below the green line to allow for very slight variations in the distance.



NOTE: The green bar indicates the current distance and the light gray background indicates the distance over time.

9. Click  to show all ROIs at the same time.




Figure 243. All Tools Shown

10. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.




Figure 244. Good Part




Figure 245. Bad Part—Plunger Too High

## 9.3 & Logic Tool

Use the Logic tool to combine or convert tool results, or to drive discrete outputs from tool results.

The Logic tool uses Boolean logic to combine or convert tool results. The logic output can be used to pass or fail the inspection or to drive a discrete output. The results of the Logic tool's analysis are displayed in Tools & Results and All Results.

The inputs to the Logic tool are called operands. The camera tool, vision tools, or analysis tools can be operands if they are added to the current inspection. The operation is the logical expression used on the operands. AND, OR, and XOR logic are available.

### AND

A true output results if all inputs are true.

### OR

A true output results if one or more of the inputs are true.

### XOR

A true output results if one, and only one, of the inputs is true.

Example uses:

- Gather results from the camera tool, vision tools, or analysis tools
- Establish parameters for desired inspection results
- Tie multiple results together with logic options
- Include results in the overall Pass/Fail criteria
- Activate a discrete output based on the inspection results
- Part sorting applications

### 9.3.1 Logic Tool: Input Parameters

Use the Input parameters to configure how the tool analyzes an image.




Figure 246. Logic Tool—Input Parameters

## Operator

Select the type of logical expression used for the Logic tool operator.




Figure 247. Operator

Operator	Summary/Examples	Description
AND (All)	AND(True, True, True)=True AND(True, False, True)=False	A true output results if all inputs are true.
OR (Any)	OR(True, True, True)=True OR(True, False, True)=True	A true output results if one or more of the inputs are true.
XOR (Only one)	XOR(True, True, True)=False XOR(True, False, True)=False	A true output results if one, and only one, of the inputs is true.

## Operands

Choose the variables from the tools found in the inspection. The current tool result displays in the Result column.




Figure 248. Operands

The desired Operands must be listed before the Logic Tool in the Tools and Results pane so that they can be used by the Logic Tool. Each Operand must have its Test criteria enabled for the Logic tool to use it.

## Discrete Output

Select whether the Logic tool activates one of the five programmable I/O and what the active condition is.




Figure 249. Discrete Output—Output Active

### I/O #

Select the desired General Output I/O number.

To select and use I/O 1-5 in the Logic tool Discrete Output parameter, at least one I/O must be configured as General Output in the system settings. Click System Settings > Discrete I/O and select General Output from the Function list for the desired I/O.

### Active Condition

Select when the output is active—either when the result is True or when the result is False.

Available when an I/O # is selected.

## Inspection Pass/Fail

Select the Contribute to Inspection Pass/Fail check box (default) if the tool will influence the Pass/Fail status of the inspection.




Figure 250. Inspection Pass/Fail

The Pass/Fail contribution influences the following:

- Discrete output Pass
- Discrete output Fail
- Pass/Fail results counter
- Pass (Green) and Fail (red) LEDs on the Sensor

Select this checkbox if the overall Pass/Fail status of the inspection is dependent on the current tool.

### 9.3.2 Logic Tool: Test Parameters

Use the Test parameters to configure the pass/fail conditions for the tool. Select the parameter checkbox to enable it.




Figure 251. Logic Tool—Test Parameters

#### Logic Output

The Boolean result for the Logic tool operation.

### 9.3.3 Logic Tool: Results

Tools & Results and All Results list information from the current and previous inspections.

A red box around a tool indicates that the tool failed. Status provides information about the specific failure.

All Results displays the Result, Time, Pass Count, and Fail Count information at a glance. Expand the inspection tool to see specific results for that tool.

#### Logic Output

The Boolean result for the Logic tool operation.

#### Execution Time

The execution time, in milliseconds, for the currently selected tool in the current inspection.

Expand Execution Time to see the historical minimum and maximum execution times up to this point for the selected tool.

Use the reset button in the Inspection Summary to reset these historical values.

#### Status

Status and error messages display as appropriate.

### 9.3.4 Using the Logic Tool

Follow these steps for an example inspection that uses the Logic tool.

This example uses two Match tools and two Logic tools. The Match tools are taught independently. Each Match tool determines the presence or absence of a different logo on different size boxes. The first Logic tool passes the inspection if either Match tool finds its respective logo. The second Logic tool turns on an output if a specific logo is found. This output could be used to turn on a light or to send the box to a different line. See [Using the Match Tool](#) on page 104 for more information on using the Match tool.



NOTE: This procedure is an example only.

1. Add a Match tool to the inspection.
  - a) Configure Match01 to recognize the logo on the small box.
  - b) Expand Inspection Pass/Fail and remove the checkmark to disable the parameter.
  - c) On the Test tab, select the Count checkbox to enable the Count test parameter.
  - d) Expand Count and set it to a minimum of 1 and a maximum of 1.




Figure 252. Match01

2. Add a second Match tool.
  - a) Configure Match02 to recognize the logo on the large box.
  - b) Expand Inspection Pass/Fail and remove the checkmark to disable the parameter.
  - c) On the Test tab, select the Count checkbox to enable the Count test parameter.
  - d) Expand Count and set it to a minimum of 1 and a maximum of 1.



Figure 253. Match02

3. Add a Logic tool.
4. Expand Operator and choose the logical expression to perform. For this example, choose OR (Any).
5. Expand Operands and select the tools to include in the analysis.
  - a) Remove the checkmark from Camera01 to exclude it.
  - b) Select the Match01 and Match02 checkboxes to include them.
6. Leave Inspection Pass/Fail selected (default).
7. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Logic Output checkbox.  
This option sets whether the Boolean logic is true or false so that the part passes.
  - b) Select True.  
If any box has a logo, the Logic tool and inspection pass.
8. Add a second Logic tool to the inspection.
9. Expand Operator and choose the logical expression to perform. For this example, choose AND (Any).
10. Expand Operands and select the tools to include in the analysis.
  - a) Remove the checkmark from Camera01 to exclude it.
  - b) Select the Match01 checkbox to include it.
11. Set the Discrete I/O.
  - a) Click System Settings > Discrete I/O.
  - b) Select General Output as the Function for one I/O. This example uses I/O 5.
12. Set the Discrete Output parameter for the Logic tool.
  - a) Expand Discrete Output.
  - b) Select the desired I/O from the I/O # list. In this example, select 5. General Output.
  - c) Leave the Active Condition as Active when True (default).
13. Expand Inspection Pass/Fail and remove the checkmark to disable the parameter.
14. Set the Test parameters to set the pass/fail criteria.
  - a) On the Test tab, select the Logic Output checkbox.  
This option sets whether the Boolean logic is true or false so that the part passes.
  - b) Select True.  
The small box must have the logo to create the general output.

15. Expand the I/O Summary so that you can see the results.




Figure 254. I/O Summary—Small Box Passes with Output



Figure 255. I/O Summary—Large Box Passes with no Output

16. Test a complete range of good and bad samples to make sure that the sensor accepts good parts and rejects bad parts.

# 10 Emulators

Use Emulators on the  Home screen to connect to the emulator.




Figure 256. Emulators

Click  to connect to the desired emulator. This tab also displays the Image location on the computer, as well as the emulator version information.

Click  under Image Location to change the directory for the reference images. The default directory for images is C: > Users > Public > Documents > Banner Vision Manager > VE Series > VE xMP > Images. Both 8-bit monochrome bitmap (BMP) images and inspection logs are supported. Bitmap images should be the same resolution as the VE camera. If inspection logs are placed in the Images directory, the emulator automatically extracts the image out of the inspection log and uses it to run the currently loaded inspection.

The Emulators tab includes all available features and all tools function the same as they do when running on a sensor. On the emulator, execution time is not calculated.

## 10.1 Backup or Restore the Emulator

Emulator settings and inspections can be backed up and restored.

The backup file is saved to the location of your choice.

1. From the  Home screen, click Emulators.
2. Make sure that no sensors or emulators are connected to the Vision Manager software.
3. Click , then click Backup.
4. Follow the prompts to save a backup file.  
A message displays saying that the backup was successful.
5. To restore the sensor data, click , then click Restore.
6. Follow the prompts to restore the sensor data. A sensor backup file can be used to restore the emulator.



NOTE: This process can take several minutes.

A message displays saying that the restore was successful.

# 11 Sensor Display

The LCD display on the top of the sensor provides access to view or change several settings without using Vision Manager. The display provides limited programming options:

- ETHER—Ethernet settings
- PCHANGE—Product change
- IO—Input/Output settings
- IMAGE—Image settings
- INFO—Sensor information
- SYSERROR—System errors, if present
- DISPLAY—Display settings
- REBOOT—Reboot

Access the sensor menu by pressing Enter  from the Home Screen.

## 11.1 Sensor Display Interface

Use the sensor buttons to configure several sensor settings and to access sensor information.



### Down and Up Buttons

Press Down and Up to:

- Navigate the menu systems
- Change programming settings

When navigating the menu systems, the menu items loop.



### Enter Button

Press Enter to:

- Access the Sensor Menu
- Access the submenus
- Save changes

In the Sensor Menu, a check mark  in the lower right corner of the display indicates that pressing Enter accesses a submenu.



### Escape Button

Press Escape to:

- Leave the current menu and return to the parent menu
- Leave the current menu and return to the Home Screen from any menu



**Important:** Pressing Escape discards any unsaved changes.

In the Sensor Menu, a return arrow  in the upper left corner of the display indicates that pressing Escape returns to the parent menu.

Press and hold Escape for 2 seconds to return to the Home Screen from any menu.

## 11.2 Locking and Unlocking the Sensor

Use the lock and unlock feature to prevent unauthorized or accidental programming changes.

A lock symbol  displays in the upper left corner of the display to indicate when the sensor is locked. When locked, the menus are available to view settings, but the values cannot be changed.

To lock or unlock the sensor using the buttons, press and hold Down  and Escape  simultaneously until the lock symbol displays.

### 11.3 Sensor Menu




Figure 257. Menu Map

## 11.4 Ethernet Menu (ETHER)

---

Use this menu to view or change network connection information.

### STATUS

LINK—View the connection status (UP or NONE). UP indicates that an Ethernet link has been established. NONE indicates that a link has not been established.

SPEED—View the speed (100HD/100FD/1000FD).

### IP

View or change the IP address of the sensor.

### SUBNET

View or change the subnet address of the sensor.

### GATEWAY

View or change the gateway address of the sensor.

### MAC

View the MAC address of the sensor.

### MAX SPEED

Set the speed to 100HD, 100FD, or 1000FD. The default speed is 100 full duplex.



NOTE: To use 1000 full duplex, all supporting network hardware must fully support 1000 Mb Ethernet or poor communication throughput could occur.

## 11.5 Product Change Menu (PCHANGE)

---

Use this menu to view or change the inspection by slot number.

## 11.6 Input/Output Menu (IO)

---

Use this menu to view I/O information.

### OUTPUT

A Bit representation of the output states.

### INPUT

A Bit representation of the input states.

### PSELECT

The slot number represented by selected bits and a Bit representation of the Product Select input pins.

## 11.7 Image Menu (IMAGE)

---

Use this menu to view focus and trigger information.

### FOCUS#

View the current focus number.

### TRIGGER

Select Yes to trigger the sensor.

## 11.8 Information Menu (INFO)

---

Use this menu to view sensor information.

### NAME

View the device name.

### MODEL

View the model number.

FW VER

View the firmware version.

BOOT

View the boot number.

HOUR

View the hour count.

SERIAL

View the sensor serial number.

## 11.9 System Error Menu (SYSERR)

---

Use this menu to view or clear system errors, when present.

VIEW

View the latest system error, when present.

CLEAR

Select Yes to clear a system error state. Select No to return to the previous menu without clearing the error. Clearing the system error state does not remove the system error from the system log.

## 11.10 Display Menu (DISPLAY)

---

Use this menu to change the display orientation and sleep mode settings.

VIEW

View or change the display orientation of the sensor. For applications where the sensor must be mounted so that the display is not right-reading, invert the display for readability.

- Normal—The display is right-reading
- Invert—The display is inverted. The down and up buttons do not change when the display is inverted.

SLEEP

View or change when the display is put to sleep.

- Disabled
- 1min—1 minute
- 5min—5 minutes (default)
- 15min—15 minutes
- 60min—60 minutes

## 11.11 Reboot Menu (REBOOT)

---

Use this menu to reboot the sensor. The sensor retains the current settings after the reboot.

Select Yes to reboot the sensor. Select No to return to the Reboot option without rebooting the sensor.

# 12 Communications Guide

## 12.1 Communication Summary

The VE Series camera communicates with other devices via Ethernet.

To establish an Ethernet connection to the sensor, the external device must be configured with the correct IP address and support a communication protocol supported by the sensor.

### 12.1.1 Communication Channels

The VE Series camera supports up to two communications channels.

To access the channels, go to System Settings > Communications.

- Industrial Ethernet—A bi-directional communication channel that allows the user to control the sensor and access sensor results using Ethernet/IP, Modbus/TCP, PROFINET®, or PCCC protocol
- Image Export—Used to export inspection images to a remote device

### 12.1.2 Industrial Ethernet

The VE Series camera can be controlled or monitored over Industrial Ethernet using Ethernet/IP, Modbus/TCP, PROFINET®, or PCCC protocols.

Use this document to set up the VE Series camera in the desired configuration and to provide information needed to connect to the master device (PLC, HMI, etc.).

Navigate: System Settings > Communications > Industrial Protocols.

### 12.1.3 Image Export

Image export is a proprietary TCP/IP protocol that is supported only on Ethernet ports.

Navigate: System Settings > Communications > Image Export.

Inspection images match the resolution of the camera and are 8-bits per pixel grayscale images in Windows BMP format that represent all of the data in a full Field of View (FOV).

Each exported image is composed of a header (64 bytes) followed by the image data; see the following tables. All 16- and 32-bit numeric entries are little endian.

Table 5: Header Information

Byte Offset	Field	Size in Bytes	Data Type	Description
0-15	Header Prefix	16	char	"VE IMAGE"
16-19	Header Version	4	UInt32	2
20-23	Image Size	4	UInt32	Number of bytes; see the table below
24-27	Image Frame Number	4	UInt32	Most recently snapped image frame number
28-29	Image Width	2	UInt16	Based on camera resolution
30-31	Image Height	2	UInt16	Based on camera resolution
32-33	Image Format	2	UInt16	0: Bitmap
34-63	Reserved	32	byte	Reserved for future use

Field of View (FOV)	Image Size (bytes) <sup>6</sup>
1600 × 1200	1,921,078
1280 × 1024	1,311,798
752 × 480	362,038
320 × 240 (iVu Plus only)	77,878

<sup>6</sup> Windows BMP image. Image size is not fixed for JPEG images (if supported).

During the image export operation the sensor's output channels might become full. This can occur if the sensor is producing export data (images) faster than the data can be exported from the device (due to bandwidth limitations) or faster than the client is reading the channel export data.

The Hold READY setting affects how the sensor behaves in this situation.

- Select the Hold READY checkbox to ensure that all images are exported. In this case, the READY signal will remain inactive (sensor is busy) until the new image has been added to the channel for export. Triggers might be missed during this time.
- Clear the Hold READY checkbox to cause the sensor to discard the new image if the channel is full and activate the READY signal immediately after the current inspection is complete. In this case, the discarded images will not be exported.

#### Banner Image Export Sample Program

The VE Series camera has an Image Export sample application that provides a way to save exported images. In a production environment, you will need to write your own application to process exported images, for example to display them on an HMI or to save them to disk.

The Banner Image Export Sample Program installs automatically when the Vision Manager software is installed. The source code to write your own application is located at C:\Users\Public\Documents\Banner Vision Manager\Sample Programs\Source\Image Export.



Figure 258. Image Export Sample Application

## 12.2 Enabling Communications


### 12.2.1 Setting Up Ethernet Communications

Configure the PC to communicate with the sensor using the following instructions.

#### 12.2.2 Windows 7

1. Click the Start button, then on the Start menu, click Control Panel.
2. In Control Panel, click Network and Internet, then click Network and Sharing Center, and then click Change adapter settings.
3. Right-click on the connection that you want to change, then click Properties.

- If you are prompted for an administrator password or confirmation, enter the password or provide confirmation.
4. In the connection properties, click Internet Protocol Version 4 (TCP/IPv4), and then click Properties.



5. In Internet Protocol (TCP/IPv4) Properties, select Use the following IP address.
6. Make sure that the IP address is 192.168.0.2, and the subnet mask is 255.255.255.0.



### 12.2.3 Communications Channel Ports

The following is the default Ethernet port setting for the communication channels: Image Export—32200.

# 13 Industrial Ethernet Overview

## 13.1 Industrial Ethernet Setup

### 13.1.1 Set the Industrial Ethernet Protocol (EtherNet/IP, PROFINET®, Modbus/TCP, PCCC)

The Industrial Ethernet communication channel is disabled by default.

To enable this channel, use the following instructions:

1. From the  System Settings screen, click Communications, then click Industrial Protocols.
2. Select the desired protocol from the list.
  - Disabled (default)
  - EtherNet/IP
  - PROFINET®
  - Modbus/TCP
  - PCCC

Only one type of connection can be established at a time.

3. Select the desired 32 Bit Format from the list.

32 bit Format determines how 32 bit integers and floating point values are stored in sequential 16 bit registers (words) —least significant word first (LSW-MSW) or most significant word first (MSW-LSW).

Word	Value
0	LSW
1	MSW

OR

Word	Value
0	MSW
1	LSW



NOTE: To configure the tool-specific results, see:

- [Tool-Specific Results: EtherNet/IP](#) on page 144
- [Tool-Specific Results: Modbus/TCP](#) on page 165
- [Tool-Specific Results: PCCC](#) on page 174
- [Tool-Specific Results: PROFINET](#) on page 183

### 13.1.2 Set the Trigger Mode

Trigger the sensor using either the hardware trigger or through the Industrial Ethernet.

To only accept triggers generated through the Industrial Ethernet communication channel, set the trigger to Industrial Ethernet.



NOTE: An Industrial Protocol must be enabled from System Settings > Communications > Industrial Protocols before setting the trigger to Industrial Ethernet.

1. On the  Sensor screen, click the Camera tool.  
The Inputs tab displays.
2. On the Inputs tab, expand Trigger.
3. Select Industrial Ethernet from the Trigger Mode list.

## 13.2 Supported Functions

The VE Series camera is controlled over an Industrial Ethernet connection using the input and output data it makes available over the protocol.

The following are examples of sensor functions that can be performed using input and output values:

- Product change
- Remote teach
- Sensor trigger

- Read output indicators (pass/fail/ready/error)
- Read counters (pass, fail, error code, missed trigger, frame count, inspection time)

### 13.2.1 Sensor Input Values

The VE Series camera operation can be controlled through input bits.

*Table 6: Input Bits*

The following commands can be executed only using bits.

Input Coil Bit	Command	Description
0	Product Change	Execute a product change (the inspection number specified in the "Product Change Number" 32-bit integer register)
1	Teach Latch	Latch a teach bit; the Teach is executed on the next trigger
2	Trigger	Causes the system to trigger an inspection if ready

### 13.2.2 Sensor Output Values

The following information can be obtained using output values:

- ACK bits (acknowledgement bits) for input commands, including error codes
- System indicators (Ready, Pass/Fail, Output signals, Execution Error, etc.)
- Inspection History (Iteration Count, Pass Count, Fail Count, etc.)
- Sensor Pass/Fail Bits (Indications of whether each tool in the inspection passed or failed, individually)

See the section on protocols for more information.

#### ACK Bits

For each of the input bits there is a corresponding ACK bit. The vision sensor sets the ACK bit when the corresponding action is complete. Input bits cause actions to occur on the low-to-high transition of that bit.



**Important:** You must clear the input bit after the corresponding ACK bit has been observed to be high.

As an example, to use the Trigger ACK bit, the programming steps for triggering an inspection are:

1. Wait for ready.
2. Set Trigger input bit to 1.
3. Wait for Trigger ACK to go to 1.
4. Set Trigger input bit to 0.

## 13.3 EtherNet/IP

The VE Series camera is controlled via EtherNet/IP using assembly objects. From the point of view of a PLC, there are three input assemblies and two output assemblies.

The Originator of the EtherNet/IP connection is the PLC. The Target of the EtherNet/IP connection is the VE Series camera. The direction of communication can be described as T > O or O > T (sometimes also shown as T2O or O2T).

The following rules apply for the use of input bit commands:

- Only one VE Series camera input bit can be set at a time
- Corresponding ACK bits are set high only on completion of the command (if the VE input bit is still high)
- Corresponding ACK bits are cleared when the VE input bit is cleared
- When multiple VE input bits are set simultaneously, the Execution Error input bit is set and an Error Code value is reported in the Error Code register
- The Execution Error VE output bit is cleared when all ACK bits are cleared, or a new valid command is received




Figure 259. Trigger—Modbus/TCP, EtherNet/IP, PCCC




Figure 260. Trigger Timing Diagram  
X, Y, Z: Represent snapshot in time




Figure 261. TEACH—Modbus/TCP, EtherNet/IP, PCCC




Figure 262. Teach Latch Timing Diagram

X, Y, Z: Represent snapshot in time





Figure 263. Product Change—Modbus/TCP, EtherNet/IP, PCCC



X, Y, Z: Represent snapshot in time  
Figure 264. Product Change Timing Diagram

### 13.3.1 Inputs to the Sensor (Outputs from the PLC)

PLC Assembly Instance 112 (0x70) - 6 Registers (Sensor Inputs/PLC Outputs) 0 > T

Data transfer direction: Originator (PLC) to Target (VE). Assembly Instance 112 (0x70) is a small group of registers used for basic control of the VE Series camera.

WORD #	WORD NAME	DATA TYPE
0	Input Bits Register (see <i>Input and Output Bits</i> on page 144)	16-bit integer
1-2	Product Change Number	32-bit integer

WORD #	WORD NAME	DATA TYPE
3-5	<i>reserved</i>	16-bit integer

### 13.3.2 Outputs from the Sensor (Inputs to the PLC)

#### PLC Assembly Instance 100 (0x64) - 30 Registers (Sensor Outputs/PLC Inputs) T > O

Data transfer direction: Target (VE) to Originator (PLC). Assembly Instance 100 (0x64) is a small block of registers providing basic inspection results and 13 user-configurable registers for tool-specific results from the VE Series camera.

WORD #	RESULT	DATA TYPE
0	Input Bits ACK Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
1	Output Bits Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
2-3	Error Code	32-bit integer
4-5	Inspection Number	32-bit integer
6-7	Frame Count	32-bit integer
8-9	Pass Count	32-bit integer
10-11	Fail Count	32-bit integer
12-13	Missed Triggers	32-bit integer
14-15	Current Inspection Time	32-bit float
16	Sensor Pass/Fail Bits (see <a href="#">Sensor Pass/Fail Bits</a> on page 144)	16-bit integer
17-29	User-defined (see <a href="#">Tool-Specific Results: EtherNet/IP</a> on page 144)	Selection dependent

#### PLC Assembly Instance 101 (0x65) - 240 Registers (Sensor Outputs/PLC Inputs) T > O

Data transfer direction: Target (VE) to Originator (PLC). Assembly Instance 101 (0x65) is a large block of registers that provides both basic inspection results and 223 user-configurable registers for tool-specific results.

WORD #	WORD NAME	DATA TYPE
0	Input Bits ACK Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
1	Output Bits Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
2-3	Error Code	32-bit integer
4-5	Inspection Number	32-bit integer
6-7	Frame Count	32-bit integer
8-9	Pass Count	32-bit integer
10-11	Fail Count	32-bit integer
12-13	Missed Triggers	32-bit integer
14-15	Current Inspection Time	32-bit float
16	Sensor Pass/Fail Bits (see <a href="#">Sensor Pass/Fail Bits</a> on page 144)	16-bit integer
17-239	User-defined (see <a href="#">Tool-Specific Results: EtherNet/IP</a> on page 144)	Selection dependent

#### PLC Assembly Instance 102 (0x66) - 60 Registers (Sensor Outputs/PLC Inputs) T > O

Data transfer direction: Target (VE) to Originator (PLC). Assembly Instance 102 (0x66) is a large block of registers that provides both basic inspection results and 43 user-configurable registers for tool-specific results.

WORD #	WORD NAME	DATA TYPE
0	Input Bits ACK Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
1	Output Bits Register (see <a href="#">Input and Output Bits</a> on page 144)	16-bit integer
2-3	Error Code	32-bit integer
4-5	Inspection Number	32-bit integer
6-7	Frame Count	32-bit integer

WORD #	WORD NAME	DATA TYPE
8-9	Pass Count	32-bit integer
10-11	Fail Count	32-bit integer
12-13	Missed Triggers	32-bit integer
14-15	Current Inspection Time	32-bit float
16	Sensor Pass/Fail Bits (see <a href="#">Sensor Pass/Fail Bits</a> on page 144)	16-bit integer
17-59	User-defined (see <a href="#">Tool-Specific Results: EtherNet/IP</a> on page 144)	Selection dependent

### 13.3.3 Input and Output Bits

Table 7: Input Bits Register (Command Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	Trigger	Teach Latch	Product Change

Table 8: Input Bits ACK Register (ACK Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	Trigger ACK	Teach Latch ACK	Product Change ACK

Table 9: Output Bits Register (Sensor Status Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Execution Error	System Error	Teach Error	Missed Trigger	reserved	reserved	Output 5	Output 4	Output 3	Output 2	Output 1	reserved	Ready Latch	reserved	Pass/Fail	Ready

### 13.3.4 Sensor Pass/Fail Bits

For the sensor pass/fail bits, pass = 1 and fail = 0.

Table 10: Sensor Pass/Fail Bits

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Vision Tool 15 Pass/Fail	Vision Tool 14 Pass/Fail	Vision Tool 13 Pass/Fail	Vision Tool 12 Pass/Fail	Vision Tool 11 Pass/Fail	Vision Tool 10 Pass/Fail	Vision Tool 9 Pass/Fail	Vision Tool 8 Pass/Fail	Vision Tool 7 Pass/Fail	Vision Tool 6 Pass/Fail	Vision Tool 5 Pass/Fail	Vision Tool 4 Pass/Fail	Vision Tool 3 Pass/Fail	Vision Tool 2 Pass/Fail	Vision Tool 1 Pass/Fail	Camera Tool Pass/Fail

### 13.3.5 Tool-Specific Results: EtherNet/IP

Configure the VE to output user-defined, tool-specific results to the PLC using a custom map.

Each assembly instance includes system-defined and user-defined results in the map. To set the user-defined, tool-specific results in the custom map, navigate: System Settings > Communications > Industrial Protocols.




Figure 265. Industrial Protocols Tab—EtherNet/IP

The results are configurable only for the current inspection. However, all user-defined results in the custom map are shown on the Industrial Protocols tab whether or not they are included in the current inspection. To make changes to a different inspection, switch to the desired inspection and then make changes to the custom map. Updating the map does not disconnect the sensor from the PLC.

To configure the map:

1. Click  to add a new line to the map.
2. Set the Word/Register/Byte, Tool Name, and Result. See the following descriptions for more information.
3. Click Apply Changes to send the current map to the camera.



Important: Click Apply Changes or all user-defined data is lost when you click away from the Industrial Protocols tab.

4. Click  to print and save a PDF of the current map. The PDF includes all data, whether system-defined or user-defined.
5. To return the map to the default settings, click . All user-defined output data is deleted.

Column descriptions:

WORD #

The data location.

Inspection Slot #

Shows whether this tool result applies to the current inspection only (*inspection number*) or to any inspection (ANY) that includes the selected tool.

An Inspection Slot # of ANY means that if an inspection includes a tool with the exact name (for example, *AverageGray01*), the results are output. If an inspection does not have a tool with the exact name (for example *AverageGrayAssemblyLine01*), no results are output for that tool and that inspection.

Tool Type

Displays a graphic that represents the type of tool selected in the Tool Name column.

Tool Name

Select the desired Tool Name from the list. The list includes the tools available in the current inspection only. Select a different inspection from the inspection list, if necessary.

Result

The information to output.

Data Type

The type of information to output.

Actions

Click  to delete a result. You cannot delete system-defined results that contain the  symbol.

### 13.3.6 Configuration Assembly Object

The VE Series camera EIP implementation does not support an assembly object configuration instance. However, one is required for creation of implicit Class 1 connections on a ControlLogix family PLC. Therefore, a configuration instance is defined as instance number 128 (0x80). Its size is zero.

### 13.3.7 Data Formats

The VE Series camera EIP implementation supports 32-bit Integers in LSW\_MSW data format (default) or MSW\_LSW data format. The LSW\_MSW data format is such that the least significant word is stored first, then the most significant word. This format is used for Allen-Bradley ControlLogix PLCs.

The string format is compatible with the Allen-Bradley ControlLogix built-in string data type. This format is a 32 bit (DINT) length followed by character bytes (SINT). This results in the following string format as viewed from the VE Series camera:

Word	0	1	2		3		4		...	...
	Length LSW	Length MSW	byte 1	byte 0	byte 3	byte 2	byte 5	byte 4		

### 13.3.8 Minimum Requested Packet Interval (RPI) Value

The VE Series camera can operate with input and output Requested Packet Intervals (RPIs) as low as 50 milliseconds. The device may not operate reliably if a lower RPI value is selected.

### 13.3.9 VE Series Smart Camera EDS File Installation in ControlLogix Software

Use the EDS Hardware Installation Tool to register the Electronic Data Sheet (EDS) file.

1. On the Tools menu, click ESD Hardware Installation Tool.  
The Rockwell Automations's ESD Wizard dialog displays.




Figure 266. Tools—ESD Hardware Installation Tool

2. Click Next.

3. Select the Register an EDS file(s) option.



Figure 267. Rockwell Automations's ESD Wizard—Options

4. Browse to locate the EDS file and click Next.

If Vision Manager is installed on the computer, a copy of the EDS file is available at C: > Users > Public > Documents > Banner Vision Manager > VE Series > Industrial Protocols > EthernetIP.




Figure 268. Select File to Register

5. Click Next to register the tested file.




Figure 269. Register the Tested File

6. Click Next when you see the icon associated with the EDS file.




Figure 270. Rockwell Automations's ESD Wizard

7. Click Next to register the EDS file.




Figure 271. Register the EDS File

8. Click Finish to close the EDS Wizard window.
9. Right-click on the PLC's Ethernet adapter and select New Module...




Figure 272. New Module

10. Locate VE Series camera from the catalog and click Create.




Figure 273. Select Module Type

11. Enter a name, description (optional), and IP address for the VE Series camera.




Figure 274. New Module

12. Click Change in the Module Definition field.




Figure 275. Module Definition

13. Select the desired connection in the Module Definition window. Each of the items in the Name list represents a fixed grouping of input and output assembly instances:

- Small Assemblies
  - O>T PLC Input/Sensor Output Assembly 112 (0x70)
  - T>O PLC Output/Sensor Input Assembly 100 (0x64)

14. Select INT as the data type.




Figure 276. Module Definition—Data Type

15. Click OK twice and download the program to the PLC.




Figure 277. Download to the PLC

The connection looks like the one above.

### 13.3.10 RSLogix5000 Configuration

To create an implicit Class 1 configuration to the VE Series camera using EIP when using a ControlLogix family PLC, configure the VE as a “Generic Ethernet Module” under the ENET\_MODULE. The following is a sample setup of a Banner sensor:

1. Add a generic Ethernet module to the PLC's Ethernet card.




Figure 278. Add Ethernet Module

2. Select Module.




Figure 279. Select Module

### 3. Configure Module Properties.



NOTE: The data type in the Comm Format must be changed to an INT.

See [Inputs to the Sensor \(Outputs from the PLC\)](#) on page 142 and [Outputs from the Sensor \(Inputs to the PLC\)](#) on page 143 for more information on each specific assembly instance.




Figure 280. PLC Input Assembly (100), PLC Output Assembly (112)




Figure 281. PLC Input Assembly (101), PLC Output Assembly (113)




Figure 282. PLC Input Assembly (102), PLC Output Assembly (114)




Figure 283. Select or deselect Unicast Connection as desired



NOTE: The minimum allowed RPI is 50 ms.

4. If the module configuration was successful, the following information should display:




Figure 284. Successful Configuration

If the module configuration was not successful, the RSLogix 5000 software will indicate errors similar to the following:




Figure 285. ERROR: Assembly Instance Number and/or Size Incorrect






Figure 286. ERROR: VE Series camera Not Powered Up or EtherNet Cable Not Attached

5. Locate the memory map setup from Banner module to PLC memory map.



- C = Configuration (not used)
- I = Inputs to PLC (outputs from the sensor)
- O = Outputs from PLC (inputs to the sensor)

Figure 287. Memory Map



The VE Series camera memory map expanded. I = Inputs to PLC (outputs from the sensor).

Figure 288. Memory Map Expanded

### 13.4 Modbus/TCP

The Modbus/TCP protocol provides device information using register and coil banks defined by the slave device. This section defines the register and coil banks. By specification, Modbus/TCP uses TCP port 502.

The following registers are used to send values back and forth from the vision sensor to the PLC. VE Series camera read-only output data can be read as Input Registers (30000) using Modbus function code 04 (Read Input Registers). Because some devices like the Modicon family of PLCs cannot access data using the 30000 range of registers, the same values can also be seen as Holding Registers (40000) using Modbus function code 03 (Read Holding Registers).

The Input Bits can be set as Coils using Modbus function code 05 (Force Single Coil). The state of the Input ACK Bits and Status Bits can be read as Inputs (10000) using Modbus function code 02 (Read Input Status).

#### Modbus Function Codes Supported

- 01: Read Coil Status
- 02: Read Input Status
- 03: Read Holding Registers
- 04: Read Input Registers
- 05: Force Single Coil
- 06: Preset Single Register
- 07: Read Exception Status
- 16: Preset Multiple Registers

Table 11: Input Bits (Coils 00001-00016)

05: Force Single Coil		
Register	Bit Position	WORD Name
00001	0	Product Change
00002	1	Teach Latch
00003	2	Trigger
00004	3	<i>reserved</i>
00005	4	<i>reserved</i>
00006	5	<i>reserved</i>
00007	6	<i>reserved</i>
00008	7	<i>reserved</i>
00009	8	<i>reserved</i>
00010	9	<i>reserved</i>
00011	10	<i>reserved</i>
00012	11	<i>reserved</i>
00013	12	<i>reserved</i>
00014	13	<i>reserved</i>
00015	14	<i>reserved</i>
00016	15	<i>reserved</i>

Table 12: Input ACK Bits (Inputs 10001-10016)

02: Read Input Status		
Register	Bit Position	WORD Name
10001	0	Product Change ACK
10002	1	Teach Latch ACK
10003	2	Trigger ACK
10004	3	<i>reserved</i>
10005	4	<i>reserved</i>
10006	5	<i>reserved</i>
10007	6	<i>reserved</i>
10008	7	<i>reserved</i>
10009	8	<i>reserved</i>
10010	9	<i>reserved</i>
10011	10	<i>reserved</i>
10012	11	<i>reserved</i>
10013	12	<i>reserved</i>
10014	13	<i>reserved</i>
10015	14	<i>reserved</i>
10016	15	<i>reserved</i>

Table 13: Status Bits (Inputs 10017-10032)

02: Read Input Status		
Register	Bit Position	WORD Name
10017	0	Ready

02: Read Input Status		
Register	Bit Position	WORD Name
10018	1	Pass/Fail
10019	2	<i>reserved</i>
10020	3	Ready Latch
10021	4	<i>reserved</i>
10022	5	Output 1
10023	6	Output 2
10024	7	Output 3
10025	8	Output 4
10026	9	Output 5
10027	10	<i>reserved</i>
10028	11	<i>reserved</i>
10029	12	Missed Trigger
10030	13	Teach Error
10031	14	System Error
10032	15	Execution Error

The following rules apply for the use of input bit commands:

- Only one VE Series camera input bit can be set at a time
- Corresponding ACK bits are set high only on completion of the command (if the VE input bit is still high)
- Corresponding ACK bits are cleared when the VE input bit is cleared
- When multiple VE input bits are set simultaneously, the Execution Error input bit is set and an Error Code value is reported in the Error Code register
- The Execution Error VE output bit is cleared when all ACK bits are cleared, or a new valid command is received




Figure 289. Trigger—Modbus/TCP, EtherNet/IP, PCCC




Figure 290. Trigger Timing Diagram

X, Y, Z: Represent snapshot in time




Figure 291. TEACH—Modbus/TCP, EtherNet/IP, PCCC




Figure 292. Teach Latch Timing Diagram

X, Y, Z: Represent snapshot in time





Figure 293. Product Change—Modbus/TCP, EtherNet/IP, PCCC



X, Y, Z: Represent snapshot in time  
Figure 294. Product Change Timing Diagram

### 13.4.1 Sensor Input Values

Holding Registers (40000) are used by the PLC or HMI to write values to the VE Series camera. To write, use function codes 6 (Preset Single Register) or 16 (Preset Multiple Registers).

Table 14: VE Input Values (Modbus/TCP Holding Registers)

06: Preset Single Register or 16: Preset Multiple Registers		
REG #	WORD NAME	DATA TYPE
1	Input Bits (See <a href="#">Input and Output Bits</a> on page 164 and Coils 00001-16)	16-bit Integer

06: Preset Single Register or 16: Preset Multiple Registers		
REG #	WORD NAME	DATA TYPE
2-3	Product Change Number	32-bit Integer
4-500	<i>reserved</i>	16-bit Integer

### 13.4.2 Sensor Output Values

The VE Series camera sends output data to the PLC or HMI via a bank of Input Registers (30000). Some devices, like the Modicon family of PLCs, cannot access data using the 30000 range of register addresses. For these devices, the VE output data is also made available as Holding Registers (40000). To access this data, use either function code 04 (Read Input Registers) or function code 03 (Read Holding Registers).

Table 15: Sensor Output Values (Modbus/TCP Input or Holding Registers)

04: Read Input Registers or 03: Read Holding Registers			
Input REG #	Holding REG #	WORD NAME	DATA TYPE
1	1001	Input ACK Bits (see <a href="#">Input and Output Bits</a> on page 164, and also Inputs 10001-16)	16-bit Integer
2	1002	Status Bits (see <a href="#">Input and Output Bits</a> on page 164, and also Inputs 10017-32)	16-bit Integer
3-4	1003-4	Error Code	32-bit Integer
5-6	1005-6	Inspection Number	32-bit Integer
7-8	1007-8	Iteration Count	32-bit Integer
9-10	1009-10	Pass Count	32-bit Integer
11-12	1011-12	Fail Count	32-bit Integer
13-14	1013-14	Missed Triggers	32-bit Integer
15-16	1015-16	Current Inspection Time	Float
17	1017	Sensor Pass/Fail Bits (see <a href="#">Sensor Pass/Fail Bits</a> on page 144)	16-bit Integer
18-500	1018-500	User-defined (see <a href="#">Tool-Specific Results: Modbus/TCP</a> on page 165)	16-bit Integer

### 13.4.3 Input and Output Bits

Writeable Input Bits are inputs to the VE Series camera (outputs from the PLC or HMI). They are used for basic control of the sensor. They are accessible using function code 6 (Preset Single Register). The same control is also possible using Coils 00001-16, function code 05 (Force Single Coil).

Table 16: Input Bits: PLC Holding Register 1, also Coils 00001-16

Coil 16	Coil 15	Coil 14	Coil 13	Coil 12	Coil 11	Coil 10	Coil 9	Coil 8	Coil 7	Coil 6	Coil 5	Coil 4	Coil 3	Coil 2	Coil 1
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<i>reserved</i>	Trigger	Teach Latch	Product Change												

Read-only Input ACK Bits are outputs from the VE Series camera (inputs to the PLC or HMI). They are used to acknowledge each of the input bits sent from the PLC. For example, if the PLC changes the Trigger bit (from Input Bits, above) from a 0 to a 1, the VE changes the Trigger ACK bit from a 0 to a 1 in response. This information is available as Input Registers or Holding Registers. Use either function code 04 (Read Input Registers) or function code 03 (Read Holding Registers). The same data can be seen as Inputs (10000) using Modbus function code 02 (Read Input Status).

Table 17: Input ACK Bits: PLC Input Register 1 or Holding Register 1001, also Inputs 10001-16

Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<i>reserved</i>	Trigger ACK	Teach Latch ACK	Product Change ACK												

Read-only Status Bits are outputs from the VE Series camera (inputs to the PLC or HMI). They are used to report the basic status of the sensor and the last inspection run. This information is available as Input Registers or Holding Registers. Use either function code 04 (Read Input Registers) or function code 03 (Read Holding Registers). The same data can be seen as Inputs (10000) using Modbus function code 02 (Read Input Status).

Table 18: Status Bits: PLC Input Register 2 or Holding Register 1002, also Inputs 10017-32

Input 32	Input 31	Input 30	Input 29	Input 28	Input 27	Input 26	Input 25	Input 24	Input 23	Input 22	Input 21	Input 20	Input 19	Input 18	Input 17
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Execution Error	System Error	Teach Error	Missed Trigger	reserved	reserved	Output 5	Output 4	Output 3	Output 2	Output 1	reserved	Ready Latch	reserved	Pass/Fail	Ready

### 13.4.4 Sensor Pass/Fail Bits

For the sensor pass/fail bits, pass = 1 and fail = 0.

Table 19: Sensor Pass/Fail Bits

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Vision Tool 15 Pass/Fail	Vision Tool 14 Pass/Fail	Vision Tool 13 Pass/Fail	Vision Tool 12 Pass/Fail	Vision Tool 11 Pass/Fail	Vision Tool 10 Pass/Fail	Vision Tool 9 Pass/Fail	Vision Tool 8 Pass/Fail	Vision Tool 7 Pass/Fail	Vision Tool 6 Pass/Fail	Vision Tool 5 Pass/Fail	Vision Tool 4 Pass/Fail	Vision Tool 3 Pass/Fail	Vision Tool 2 Pass/Fail	Vision Tool 1 Pass/Fail	Camera Tool Pass/Fail

### 13.4.5 Tool-Specific Results: Modbus/TCP

Configure the VE to output user-defined, tool-specific results to the PLC using a custom map.

The sensor output values (Modbus/TCP Input or Holding Registers) include both system-defined and user-defined results in the map. To set the user-defined, tool-specific results in the custom map, navigate: System Settings > Communications > Industrial Protocols.




Figure 295. Industrial Protocols Tab—Modbus/TCP

The results are configurable only for the current inspection. However, all user-defined results in the custom map are shown on the Industrial Protocols tab whether or not they are included in the current inspection. To make changes to a different inspection, switch to the desired inspection and then make changes to the custom map. Updating the map does not disconnect the sensor from the PLC.

To configure the map:

1. Click  to add a new line to the map.
2. Set the Word/Register/Byte, Tool Name, and Result. See the following descriptions for more information.
3. Click Apply Changes to send the current map to the camera.



Important: Click Apply Changes or all user-defined data is lost when you click away from the Industrial Protocols tab.

4. Click  to print and save a PDF of the current map. The PDF includes all data, whether system-defined or user-defined.
5. To return the map to the default settings, click . All user-defined output data is deleted.

Column descriptions:

REG #

The data location.

Inspection Slot #

Shows whether this tool result applies to the current inspection only (*inspection number*) or to any inspection (ANY) that includes the selected tool.

An Inspection Slot # of ANY means that if an inspection includes a tool with the exact name (for example, *AverageGray01*), the results are output. If an inspection does not have a tool with the exact name (for example *AverageGrayAssemblyLine01*), no results are output for that tool and that inspection.

Tool Type

Displays a graphic that represents the type of tool selected in the Tool Name column.

Tool Name

Select the desired Tool Name from the list. The list includes the tools available in the current inspection only. Select a different inspection from the inspection list, if necessary.

Result

The information to output.

Data Type

The type of information to output.

Actions

Click  to delete a result. You cannot delete system-defined results that contain the  symbol.

## 13.5 PLC5 and SLC 5 (PCCC)

Allen-Bradley's PLC5 and SLC 500 family of devices use PCCC communications protocol. The VE Series camera supports these PLCs using input and output register arrays.

The Output bits, ACK bits and Input bits bit definitions are the same as defined in the EIP Assembly Objects section. The terms "Input" and "Output" are from the point of view of the PLC.

The following rules apply for the use of input bit commands:

- Only one VE Series camera input bit can be set at a time
- Corresponding ACK bits are set high only on completion of the command (if the VE input bit is still high)
- Corresponding ACK bits are cleared when the VE input bit is cleared
- When multiple VE input bits are set simultaneously, the Execution Error input bit is set and an Error Code value is reported in the Error Code register
- The Execution Error VE output bit is cleared when all ACK bits are cleared, or a new valid command is received




Figure 296. Trigger—Modbus/TCP, EtherNet/IP, PCCC




Figure 297. Trigger Timing Diagram  
X, Y, Z: Represent snapshot in time




Figure 298. TEACH—Modbus/TCP, EtherNet/IP, PCCC




Figure 299. Teach Latch Timing Diagram

X, Y, Z: Represent snapshot in time





Figure 300. Product Change—Modbus/TCP, EtherNet/IP, PCCC




X, Y, Z: Represent snapshot in time  
Figure 301. Product Change Timing Diagram

### 13.5.1 Configuration


The following images represent a typical configuration.

PLC Read Message Command



This Controller  
Communications Command = PLC5 Read  
Data Table Address = Integer table "Nx"  
Target Device  
Data Table Address = N7: x


Figure 302. General tab: Example message command reading from N7 table on the VE and sending the data to the N7 table on the PLC



To Address = IP address of the sensor


*Figure 303. MultiHop tab: IP Address of the VE is entered here*

PLC Write Message Command



This Controller  
Communications Command = PLC5 Write  
Data Table Address = Integer table "Nx"  
Target Device  
Data Table Address = N14:x

Figure 304. General tab: Example message command writing to N14 table on the VE from the N14 table of the PLC



To Address = IP address of the sensor

Figure 305. MultiHop tab: IP address of the VE is entered here

### 13.5.2 Inputs to the Sensor (Outputs from the PLC)

The registers below are used by the PLC to push values to the VE Series camera. MSG (message) commands are used to write (N14) to the sensor.

Table 20: PCCC PLC Output Registers (Sensor Inputs, N14 Table on the Sensor)

WORD #	WORD NAME	DATA TYPE
0	Input Bits Register (see <a href="#">Input and Output Bits</a> on page 174)	16-bit integer
1-2	Product Change Number	32-bit integer
3-500	<i>reserved</i>	32-bit integer

### 13.5.3 Outputs from the Sensor (Inputs to the PLC)

The registers below are used to send output values from the VE Series camera to the PLC. MSG (message) commands are used to read (N7) from the sensor.

Table 21: PCCC PLC Input Registers (Sensor Outputs, N7 Table on the Sensor)

WORD #	WORD NAME	DATA TYPE
0	Input Bits ACK Register (see <a href="#">Input and Output Bits</a> on page 174)	16-bit integer
1	Output Bits Register (see <a href="#">Input and Output Bits</a> on page 174)	16-bit integer
2-3	Error Code	32-bit integer
4-5	Inspection Number	32-bit integer
6-7	Iteration Count	32-bit integer
8-9	Pass Count	32-bit integer
10-11	Fail Count	32-bit integer
12-13	Missed Triggers	32-bit integer

WORD #	WORD NAME	DATA TYPE
14-15	Current Inspection Time	Float
16	Sensor Pass/Fail Bits (see <a href="#">Sensor Pass/Fail Bits</a> on page 144)	16-bit integer
17-500	User-defined (see <a href="#">Tool-Specific Results: PCCC</a> on page 174)	16-bit integer

### 13.5.4 Input and Output Bits

The Input Bits are used to command execution of basic functions. The Output Bits are used to push single bit outputs from the VE Series camera to the PLC. The 32 bits of VE Series camera output can also be accessed using the bits of the first two Output Registers (Input Bits ACK Register(word 0) and Output Bits Register (word1)).

Table 22: Input Bits Register (Command Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	Trigger	Teach Latch	Product Change

Table 23: Input Bits ACK Register (ACK Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	reserved	Trigger ACK	Teach Latch ACK	Product Change ACK

Table 24: Output Bits Register (Sensor Status Bits)

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Execution Error	System Error	Teach Error	Missed Trigger	reserved	reserved	Output 5	Output 4	Output 3	Output 2	Output 1	reserved	Ready Latch	reserved	Pass/Fail	Ready

### 13.5.5 Sensor Pass/Fail Bits

For the sensor pass/fail bits, pass = 1 and fail = 0.

Table 25: Sensor Pass/Fail Bits

Bit Position															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Vision Tool 15 Pass/Fail	Vision Tool 14 Pass/Fail	Vision Tool 13 Pass/Fail	Vision Tool 12 Pass/Fail	Vision Tool 11 Pass/Fail	Vision Tool 10 Pass/Fail	Vision Tool 9 Pass/Fail	Vision Tool 8 Pass/Fail	Vision Tool 7 Pass/Fail	Vision Tool 6 Pass/Fail	Vision Tool 5 Pass/Fail	Vision Tool 4 Pass/Fail	Vision Tool 3 Pass/Fail	Vision Tool 2 Pass/Fail	Vision Tool 1 Pass/Fail	Camera Tool Pass/Fail

### 13.5.6 Tool-Specific Results: PCCC

Configure the VE to output user-defined, tool-specific results to the PLC using a custom map.

The output submodule includes both system-defined and user-defined results in the map. To set the user-defined, tool-specific results in the custom map, navigate: System Settings > Communications > Industrial Protocols.




Figure 306. Industrial Protocols Tab—PCCC

The results are configurable only for the current inspection. However, all user-defined results in the custom map are shown on the Industrial Protocols tab whether or not they are included in the current inspection. To make changes to a different inspection, switch to the desired inspection and then make changes to the custom map. Updating the map does not disconnect the sensor from the PLC.

To configure the map:

1. Click to add a new line to the map.
2. Set the Word/Register/Byte, Tool Name, and Result. See the following descriptions for more information.
3. Click Apply Changes to send the current map to the camera.



Important: Click Apply Changes or all user-defined data is lost when you click away from the Industrial Protocols tab.

4. Click to print and save a PDF of the current map. The PDF includes all data, whether system-defined or user-defined.
5. To return the map to the default settings, click . All user-defined output data is deleted.

Column descriptions:

**WORD #**

The data location.

**Inspection Slot #**

Shows whether this tool result applies to the current inspection only (*inspection number*) or to any inspection (*ANY*) that includes the selected tool.

An Inspection Slot # of *ANY* means that if an inspection includes a tool with the exact name (for example, *AverageGray01*), the results are output. If an inspection does not have a tool with the exact name (for example *AverageGrayAssemblyLine01*), no results are output for that tool and that inspection.

**Tool Type**

Displays a graphic that represents the type of tool selected in the Tool Name column.

Tool Name

Select the desired Tool Name from the list. The list includes the tools available in the current inspection only. Select a different inspection from the inspection list, if necessary.

Result

The information to output.

Data Type

The type of information to output.

Actions

Click  to delete a result. You cannot delete system-defined results that contain the  symbol.

## 13.6 PROFINET

PROFINET<sup>7</sup> is a data communication protocol for industrial automation and processes. PROFINET IO defines how controllers (IO controllers) and peripheral devices (IO devices) exchange data in real time.

The image sensor, VE Series camera, supports PROFINET IO. The data communication protocol is TCP/IP; the data transmission medium is copper wire; the PROFINET conformance class is CC-A.<sup>8</sup>



NOTE: In this document, outputs from the VE device are referred to as "inputs" to the controller (PLC). Outputs from the controller (PLC) are referred to as "inputs" to the VE device.

### 13.6.1 General Station Description (GSD) File

The General Station Description (GSD) file contains module information, such as:

- Configuration data
- Data information (pass count, inspection status, etc.)
- Diagnostics

### 13.6.2 VE Series camera PROFINET IO Data Model

The PROFINET IO data model is based on the typical, expandable field device that has a backplane with slots. Modules and submodules have different functionalities.

Modules are plugged into slots; submodules are plugged into subslots. In the PROFINET IO data model, Slot 0 Subslot 1 is reserved for the Device Access Point (DAP) or network interface.

Both modules and submodules are used to control the type and volume of data that is sent to the controller (PLC).

- A submodule is typically designated as input type, output type, or combined input/output type
- An input submodule is used to send data to the controller (PLC)
- An output submodule is used to receive data from the controller (PLC)
- The combined input/output submodule simultaneously receives and sends data in both directions

### 13.6.3 Configure the VE Series Smart Camera for a PROFINET IO Connection

The VE Series camera and the controller (PLC) must be configured for PROFINET<sup>®</sup>.

1. On the  System Settings screen, select Communications, then select the Industrial Protocols tab.
2. Select PROFINET from the Protocol list.  
The sensor configuration is complete. Configure the PLC to complete the PROFINET connection.

The default PROFINET configuration consists of a single module plugged into Slot 1. This module, called the Device Control and Status Module, accepts two submodules: the Inspection Result Submodule, plugged into Subslot 1, and the Device Control Submodule, plugged into Subslot 2.

The Inspection Result Submodule provides the inspection results from the VE Series camera, including Pass Count, Fail Count, and Current Inspection Time. See [Table 29](#) on page 178.



NOTE: The Inspection Result Submodule does not provide any sensor-specific output data.

The Device Control Submodule allows the user to issue commands to the VE, such as Trigger, TEACH, and Product Change. This submodule also provides the user with command feedback. See [Table 30](#) on page 179.

<sup>7</sup> PROFINET<sup>®</sup> is a registered trademark of PROFIBUS Nutzerorganisation e.V.

<sup>8</sup> CC-A ensures that the device has the minimum properties in regard to functionality and interoperability.

### 13.6.4 Description of Modules and Submodules

Table 26: Module Slot Assignment

	Module
Slot 1	VE Control and Status Module
Slot 2	VE Output Module

Table 27: VE Control and Status Module (Ident 0x00000010)

	Submodule	Notes
Subslot 1	VE Inspection Results Submodule	Always present.
Subslot 2	VE Device Control Submodule	Present by default, but can be removed.

Table 28: Sensor Output Module (Ident 0x00000040)

	Submodule	Notes
Subslot 1	sensor output submodules (various)	There are six versions of this submodule supporting payloads of 16, 32, 64, 128, 256, and 512 bytes.

### 13.6.5 Description of Submodules

#### VE Inspection Results Submodule

The VE Inspection Result submodule contains inspection results and sends input data into the controller (PLC). This submodule is plugged into Slot 1 Subslot 1 and cannot be removed.

Table 29: VE Inspection Result Submodule (Ident 0x0101)

PLC Input Data Name	Input Data Type	PLC Output Data Name	Output Data Type
Inspection Status Word	Unsigned16	Not applicable	Not applicable
Inspection Number	Unsigned32		
Sensor Pass/Fail Bits	Unsigned32		
Iteration Count	Unsigned32		
Pass Count	Unsigned32		
Fail Count	Unsigned32		
Missed Trigger Count	Unsigned32		
Current Inspection Time	Unsigned32		

Inspection Status Word	
Bit Position for Cyclic Input Data	Function
Bit 0	System Ready
Bit 1	Inspection Pass/Fail
Bit 3	Ready Signal Latch
Bit 5	Output 1 ON/OFF
Bit 6	Output 2 ON/OFF
Bit 7	Output 3 ON/OFF
Bit 8	Output 4 ON/OFF
Bit 9	Output 5 ON/OFF

Sensor Pass/Fail Bits	
Bit Position	Function
Bit 0	Camera Tool Pass/Fail
Bit 1	Vision Tool 1 Pass/Fail
...	...
Bit 32	Vision Tool 31 Pass/Fail

## VE Device Control Submodule

The VE Device Control Submodule contains controller (PLC) input and output data, including device controls for the VE. The Device Control Submodule is plugged into Slot 1, Subslot 2 by default but it can be removed.

Table 30: VE Device Control Submodule (Ident 0x0001)

PLC Input Data Name	Input Data Type	PLC Output Data Name	Output Data Type
Device Control ACK Word	Unsigned16	Device Control Command Word	Unsigned16
Return Error Code	Unsigned32	Product Change Number	Unsigned32

Device Control ACK Word		Device Control Command Word	
Bit Position for Cyclic Input Data	Function	Bit Position for Cyclic Output Data	Function
Bit 0	Product Change Acknowledgement	Bit 0	Product Change Request
Bit 1	Teach Latch Acknowledgement	Bit 1	Teach Latch Request
Bit 2	Trigger Acknowledgement	Bit 2	Trigger Request
Bit 13	Teach Error		
Bit 14	System Error		
Bit 15	Command Execution Error		

The following rules apply for the use of input bit commands:

- Only one VE Series camera input bit can be set at a time
- Corresponding ACK bits are set high only on completion of the command (if the VE input bit is still high)
- Corresponding ACK bits are cleared when the VE input bit is cleared
- When multiple VE input bits are set simultaneously, the Execution Error input bit is set and an Error Code value is reported in the Error Code register
- The Execution Error VE output bit is cleared when all ACK bits are cleared, or a new valid command is received





Figure 307. Trigger—PROFINET



X, Y, Z: Represent snapshot in time

Figure 308. Trigger Timing Diagram





Figure 309. TEACH—PROFINET



X, Y, Z: Represent snapshot in time  
 Figure 310. Teach Latch Timing Diagram





Figure 311. Product Change—PROFINET



X, Y, Z: Represent snapshot in time  
Figure 312. Product Change Timing Diagram

### Sensor Output Submodules

The Sensor Output Submodules contain user-defined maps of sensor output data. There are six versions with 16, 32, 64, 128, 256, and 512 bytes, depending on the size of the output data. A sensor output submodule can be added to slot 2, subslot 1.

Table 31: Sensor Output Submodule

Submodule		PLC Input Data		PLC Output Data	
Name	Ident No.	Name	Type	Name	Type
16-Byte Custom Map	0x00028	User-mapped Sensor Result Data Block	16-byte OctetString	Not applicable	Not applicable

Submodule		PLC Input Data		PLC Output Data	
Name	Ident No.	Name	Type	Name	Type
32-Byte Custom Map	0x00029	User-mapped Sensor Result Data Block	32-byte OctetString	Not applicable	Not applicable
64-Byte Custom Map	0x00030	User-mapped Sensor Result Data Block	64-byte OctetString	Not applicable	Not applicable
128-Byte Custom Map	0x00031	User-mapped Sensor Result Data Block	128-byte OctetString	Not applicable	Not applicable
256-Byte Custom Map	0x00032	User-mapped Sensor Result Data Block	256-byte OctetString	Not applicable	Not applicable
512-Byte Custom Map	0x00033	User-mapped Sensor Result Data Block	512-byte OctetString	Not applicable	Not applicable

Tool-Specific Results: PROFINET

Configure the VE to output user-defined, tool-specific results to the PLC using a custom map.

The sensor output submodule include both system-defined and user-defined results in the map. To set the user-defined, tool-specific results, navigate: System Settings > Communications > Industrial Protocols.




Figure 313. Industrial Protocols Tab—PROFINET

The results are configurable only for the current inspection. However, all user-defined results in the custom map are shown on the Industrial Protocols tab whether or not they are included in the current inspection. To make changes to a different inspection, switch to the desired inspection and then make changes to the custom map. Updating the map does not disconnect the sensor from the PLC.

To configure the map:

1. Click to add a new line to the map.
2. Set the Word/Register/Byte, Tool Name, and Result. See the following descriptions for more information.
3. Click Apply Changes to send the current map to the camera.



Important: Click Apply Changes or all user-defined data is lost when you click away from the Industrial Protocols tab.

4. Click to print and save a PDF of the current map. The PDF includes all data, whether system-defined or user-defined.
5. To return the map to the default settings, click . All user-defined output data is deleted.

Column descriptions:

Byte

The data location.

#### Inspection Slot #

Shows whether this tool result applies to the current inspection only (*inspection number*) or to any inspection (ANY) that includes the selected tool.

An Inspection Slot # of ANY means that if an inspection includes a tool with the exact name (for example, *AverageGray01*), the results are output. If an inspection does not have a tool with the exact name (for example *AverageGrayAssemblyLine01*), no results are output for that tool and that inspection.

#### Tool Type

Displays a graphic that represents the type of tool selected in the Tool Name column.

#### Tool Name

Select the desired Tool Name from the list. The list includes the tools available in the current inspection only. Select a different inspection from the inspection list, if necessary.

#### Result

The information to output.

#### Data Type

The type of information to output.

#### Actions

Click  to delete a result.

## 13.6.6 Configuration Instructions

### Using Siemens TIA Portal (v13) Software

#### Installing the Banner VE Series camera GSD File

Use these instructions to install the Banner VE Series camera GSD file in the Siemens TIA Portal (v13) software. Use these instructions as a basis for installing the Banner VE Series camera GSD file in another controller (PLC).

1. Start the Siemens TIA Portal (v13) software.
2. Click Open existing project.
3. Select a project and open it.

4. Click Devices & networks after the project has been uploaded.




Figure 314. Devices and Networks

5. Click Configure networks.




Figure 315. Configure Networks

Network view displays.

6. Click Options and select Install general station description file (GSD).




Figure 316. Options—Install the GSD

The Install general station description file window opens.

7. Click the browse button (...) to the right of the Source path field.




Figure 317. Manage GSD Files

8. Navigate to C: > Users > Public > Documents > Banner Vision Manager > VE Series > Industrial Protocols > Profinet.
9. Select the VE GSD file.

10. Click Install.




Figure 318. Hardware Catalog

The system installs the VE GSD file and places it in the Hardware catalog. In the above example, the VE GSD file is located under Other field devices > PROFINET IO > Sensors > Banner Engineering Corp. > Banner Vision Sensors > VE Series Vision Sensor > VE Series > VE.



NOTE: If the VE GSD file does not install properly, save the log and contact Banner Engineering Corporation.

### Adding a Device to a Project

Use these instructions to add a VE Series camera device to a Siemens TIA Portal (v13) project, and to configure the device. Use these instructions as a basis for adding a VE Series camera device to another controller (PLC).

1. Start the Siemens TIA Portal (v13) software.
2. Click Open existing project.
3. Select a project and open it.

4. Click Devices & networks after the project has been uploaded.




Figure 319. Devices and Networks

5. Click Configure networks.



Figure 320. Configure Networks

Network view displays.



NOTE: For Step 6 through Step 10, Network view must be open.

6. Locate the VE Series camera in the Hardware catalog.




Figure 321. Hardware Catalog

In the above example, the VE device is located under Other field devices > PROFINET IO > Sensors > Banner Engineering Corp. > Banner Vision Sensors > VE Series Vision Sensor > VE Series > VE.

7. Select the device and add it to the configuration.

- |                  |  |
|------------------|--|
| Selection Option | Description  |
| Drag             | Drag the VE from the Hardware catalog directly into the configuration. |
| Double-click     | Double-click on the VE and add it to the configuration.                |

8. Click the green square on the VE icon. Drag the pointer to the green square on the PLC\_1 icon to connect the device to the controller (PLC).




Figure 322. Drag to Connect

The connection is made.

9. Double-click the VE icon to open the Device window.
10. Select the desired modules or submodules from the Hardware catalog and drag them onto the Device overview tab on the Device view tab.  
The VE device is configured.

### Changing the Device IP Address

Use these instructions to change the IP address of the VE device, using the Siemens TIA Portal (v13) software. Use these instructions as a basis if you are using another controller (PLC).

1. Start the Siemens TIA Portal (v13) software.
2. Click Open existing project.
3. Select a project and open it.
4. Click Devices & networks after the project has been uploaded to go to Network view.




Figure 323. Network View

Network View displays.

5. Double-click on the VE icon to open the Device view.
6. Click on the VE icon in the graphic area of the Device view to open the Module properties window. The module can now be configured.
7. Click Properties.
8. Click General.
9. Select PROFINET interface > Ethernet addresses.




Figure 324. Ethernet Addresses

10. Select Set IP address in the project.




Figure 325. Set IP Address

The project sets the IP address of the device.

11. Enter the IP address.

12. Right-click on the device icon and select Online & diagnostics.




Figure 326. Select Online & Diagnostics




Figure 327. Online & Diagnostics

The Online & diagnostics window displays.

- 13. Select Assign IP address under Functions.
- 14. Click Accessible devices.




Figure 328. Assign IP Address—Accessible Devices

The Select device window searches the network for available devices.

- 15. Determine the device to be adjusted via the MAC address and select it.



NOTE: Use the Vision Manager software to find the MAC address: Home > Sensor Neighborhood > Active Sensors.

16. Click Apply.




Figure 329. Select the Device and Apply Changes

The IP address for the device is updated.

17. Click Assign IP address to complete the step.

This step is completed for every device.

### Changing the Device Name

Use these instructions to change the name of the VE device, using the Siemens TIA Portal (v13) software. Use these instructions as a basis if you are using another controller (PLC).

1. Open a project and click on Devices & networks to go to the Network view.




Figure 330. Network View

Network view displays.

2. Double-click on the VE icon to open Device view.
3. Click on the VE icon in the graphic area of Device view to open the Module properties window.
4. Click General.
5. Select PROFINET interface [X1] > Ethernet addresses.




Figure 331. Ethernet Addresses

- Deselect Generate PROFINET device name automatically.



Figure 332. PROFINET Device Name

- Enter a unique name in the PROFINET device name field.
- Enter a unique device number in the Device number field.



NOTE: Each device number is used only once.

- Right-click on the device icon and select Online & diagnostics.




Figure 333. Select Online & Diagnostics




Figure 334. Online & Diagnostics

The Online & diagnostics window displays.

- Select Assign name under Functions.  
The Assign name window displays. The devices in the network are discovered.
- Select the device that will have a name assigned to it.

- Click Assign name to start the process.  
The name is assigned.




Figure 335. Assign Name

## 13.7 Troubleshooting

### 13.7.1 Industrial Ethernet Error Codes

The VE Series camera camera provides error codes when coil bit commands fail to execute successfully.

If such an error occurs, the Execution Error flag is set in the Output Bits/Status Register. When this bit is set, read the Error Code register to know the reason of failure.

Error Code	Description	Recommended Solution
520	The coil action resulted in a failure.	Clear all coil bits. Verify that the corresponding acknowledgement bits are reset to zero. The error code will clear when the next valid command is issued.
524	Multiple coils were asserted simultaneously.	Clear all coil bits. Verify that the corresponding acknowledgement bits are reset to zero. The error code will clear when the next valid command is issued.
80400	Sensor must be in the Ready state to perform a product change.	Clear the Product Change bit. Verify that the Product Change acknowledgement bit has been reset to zero. Wait until the sensor is Ready. Re-assert the Product Change bit.
80401	Attempt to product change to a unknown or invalid inspection.	Clear the Product Change bit. Verify that the Product Change acknowledgement bit has been reset to zero. Set the inspection slot to a valid value. Re-assert the Product Change bit.

### 13.7.2 PROFINET

#### Discovering Sensors

The Siemens TIA Portal (v13) software discovery and configuration protocols are used to discover sensors on a network.

- Start the Siemens TIA Portal (v13) software.
- Click Open an existing project.
- Select a project and open it.
- Click Devices & networks after the project has been uploaded.
- Click Configure networks.

- Click the Accessible devices icon.



The Accessible devices window opens.

- Select an interface connection in the Type of the PG/PC interface list.
- Select an interface connection in the PG/PC interface list.




Figure 336. PG/PC Interface

The PC scans the network for PROFINET® devices. If the device you are looking for is not present, check the cabling.

### Example of Scanning Results

Under Online status information, the scan shows that three devices were found.




Figure 337. Select Device—Online Status Information

### Diagnosing Errors

The Siemens TIA Portal (v13) software includes numerous diagnostic tools. When a computer is connected to the controller (PLC), diagnostic information is available. The controller (PLC) generates a message that is displayed in the Diagnostics window. A flashing red light on the CPU module of the controller (PLC) indicates an error.

- Click on the text in the Details column to request detailed information about the device that caused the error.




Figure 338. Diagnostics

All system and device messages are displayed in the Diagnostics buffer window under Events and Details on event.

- Select a message in the table, Display CPU Time Stamps in PG/PC local time.




Figure 339. Diagnostics Buffer

The respective information displays in the Description field under Details on event.

- Read the message to learn about the error and resolve it. When the error is resolved, the icon that corresponds to the displayed message is green.

## 14 Troubleshooting

Problem	Solution
The Vision Manager software will not connect to my sensor	Make sure that: <ul style="list-style-type: none"> <li>• The sensor is powered on</li> <li>• The sensor is connected to the computer or the network</li> <li>• You are connecting to the correct sensor (verify the sensor name and IP address)</li> </ul>
The image is not clear	Make sure that: <ul style="list-style-type: none"> <li>• The lens is properly screwed onto the sensor</li> <li>• The lens is clean</li> <li>• The lens is properly focused (see <a href="#">Acquire a Good Image</a> on page 16)</li> </ul>
No images appear in the Image pane	Make sure that: <ul style="list-style-type: none"> <li>• The exposure is correct (run Auto Exposure)</li> <li>• The sensor is receiving trigger signals</li> </ul>
I changed a test parameter but the test does not seem to be working	Make sure that the test parameter checkbox is selected to enable the test parameter

Depending on the situation, a message may appear on the computer screen. These messages include an identification number, a message description, and a list of recommended solutions. There is also an option to send a report to Banner Engineering.

### 14.1 Vision Manager Error Codes

Error Code	Description	Recommended Solution
10000	The sensor's feature set is too old to work with this version of Vision Manager.	<ul style="list-style-type: none"> <li>• Update the sensor firmware to a version compatible with this application</li> <li>• Install a older version of this application</li> </ul>
10001	The sensor's feature set is too new to work with this version of Vision Manager.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Downgrade the sensor firmware to a version compatible with this application</li> </ul>
10005	The sensor was not found at the specified IP address. Network PING results indicate no device present at the specified IP address.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify sensor subnet valid</li> </ul>
10010	A connection to the sensor could not be established. One or more required channels failed to connect.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10011	A connection to the sensor could not be established. One or more required channels failed to connect	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10012	A connection to the sensor could not be established. A timeout occurred connecting required channels.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10020	A connection to the sensor could not be established. One or more required channels failed to connect.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10021	A connection to the sensor could not be established. One or more required channels failed to connect.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10022	The connection to the sensor was lost while sending data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10023	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10024	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10025	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10026	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10027	The connection to the sensor was lost.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10040	The device at the specified IP address indicated it is already connected to another application. This can happen when another Vision Manager is already connected to the sensor.	<ul style="list-style-type: none"> <li>• Disconnect the other application and try again</li> <li>• Verify there are no other devices using the same IP address</li> </ul>
10041	The device at the specified IP address rejected the connection attempt. This can happen when the network device does not support the Vision Manager protocol.	<ul style="list-style-type: none"> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> </ul>
10050	The connection to the sensor was lost.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10051	The connection to the sensor was lost.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10053	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10054	The Connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10055	The Connection to the sensor was lost due to network keep alive expiration.	<ul style="list-style-type: none"> <li>• Verify network adaptor link speed and duplex settings</li> <li>• Verify sensor not stalled, or in shutdown mode</li> </ul>
10070	The Connection to sensor was lost due to a receive state machine error.	<ul style="list-style-type: none"> <li>• Verify sensor not stalled, or in shutdown mode</li> <li>• Verify sensor is supported version</li> </ul>
10071	The Connection to sensor was lost due to a receive state machine error.	<ul style="list-style-type: none"> <li>• Verify sensor not stalled, or in shutdown mode</li> <li>• Verify sensor is supported version</li> </ul>
10080	The Connection to sensor was lost.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10085	A connection to the sensor could not be established. One or more required channels failed to connect.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10086	The connection to the sensor was lost while receiving data.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
10091	Receiving data from the sensor timed out (no data was received). Connection to the sensor was aborted.	<ul style="list-style-type: none"> <li>• Verify network adaptor link speed and duplex settings</li> <li>• Verify sensor not stalled, or in shutdown mode</li> </ul>
10092	Receiving data from the sensor timed out (partial data was received). Connection to the sensor was aborted.	<ul style="list-style-type: none"> <li>• Verify network adaptor link speed and duplex settings</li> <li>• Verify sensor not stalled, or in shutdown mode</li> </ul>
10095	Receiving data from the sensor timed out (internal error). Connection to the sensor was aborted.	<ul style="list-style-type: none"> <li>• Verify network adaptor link speed and duplex settings</li> <li>• Verify sensor not stalled, or in shutdown mode</li> </ul>
10100	The connection to the sensor was lost while sending data.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10101	The connection to the sensor was lost while sending data.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10110	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10111	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>

Error Code	Description	Recommended Solution
10120	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10125	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10126	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10140	The Connection to the sensor was lost due to network keep alive expiration.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10150	The connection to the sensor was closed by this application due to a internal processing error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10190	The connection to the sensor was closed by this application due to a internal threading error.	<ul style="list-style-type: none"> <li>• Install a newer version of this application</li> <li>• Verify the device at the specified IP address is a Banner Vision sensor</li> <li>• Verify the sensor's firmware version is compatible with this application</li> <li>• Check firewall setup on computer</li> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> </ul>
10300	Vision Manager and the sensor's release types must exactly match. Release types are specified as part of the version (eg. ALPHA, BETA, EVAL). The connection was aborted.	<ul style="list-style-type: none"> <li>• Install the version of this application which matches the release of the sensor</li> <li>• Update the sensor firmware to match the release type of this application</li> </ul>
10900	The file selected for firmware update is not valid for use with this application.	Select a firmware update file which is supported by this application.
10910	The file selected for firmware update is too old to work with this application.	Install a older version of this application.
10911	The file selected for firmware update is too new to work with this application.	Install a newer version of this application.

Error Code	Description	Recommended Solution
10912	The firmware update process timed out.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify sensor not stalled, or in shutdown mode</li> <li>• Reboot the sensor</li> </ul>
20000	An application error occurred while refreshing the display. An unhandled exception was detected.	Go to Sensor Neighborhood and reconnect to the sensor.
20001	An application error occurred while refreshing the display. There was a problem parsing data from the sensor.	Go to Sensor Neighborhood and reconnect to the sensor.
20010	An application error occurred while refreshing the display. There was a problem creating screen elements.	Go to Sensor Neighborhood and reconnect to the sensor.
20011	An application error occurred while refreshing the display. There was a problem releasing screen elements.	Go to Sensor Neighborhood and reconnect to the sensor.
20020	An application error occurred while refreshing the display. There was a problem synchronizing data.	Go to Sensor Neighborhood and reconnect to the sensor.
20021	An application error occurred while refreshing the display. There was a problem releasing data resources.	Go to Sensor Neighborhood and reconnect to the sensor.
20030	An application error occurred while refreshing the display. There was a problem synchronizing with the inspection.	Go to Sensor Neighborhood and reconnect to the sensor.
20040	An application error occurred while refreshing the display. There was a problem updating input data.	Go to Sensor Neighborhood and reconnect to the sensor.
20041	An application error occurred while refreshing the display. There was a problem updating result data.	Go to Sensor Neighborhood and reconnect to the sensor.
20050	This application detected an error while refreshing the display. There was a problem rendering the image.	Go to Sensor Neighborhood and reconnect to the sensor.
20060	An application error occurred while refreshing the display. There was a problem updating pixel annotations.	Go to Sensor Neighborhood and reconnect to the sensor.
20061	An application error occurred while refreshing the display. There was a problem updating pixel annotations.	Go to Sensor Neighborhood and reconnect to the sensor.
20070	An application error occurred while refreshing the display. There was a problem updating vector annotations.	Go to Sensor Neighborhood and reconnect to the sensor.
20071	An application error occurred while refreshing the display. There was a problem updating vector annotations.	Go to Sensor Neighborhood and reconnect to the sensor.
20072	An application error occurred while refreshing the display. There was a problem releasing vector annotations.	Go to Sensor Neighborhood and reconnect to the sensor.

Error Code	Description	Recommended Solution
20073	An application error occurred while refreshing the display. There was a problem releasing display elements.	Go to Sensor Neighborhood and reconnect to the sensor.
20100	There was a problem using the specified file.	Verify user has access to the file.
20101	A invalid file format was detected.	Verify the selected file is compatible with this application.
20103	The maximum number of tools have been added to the device.	Remove some tools from the device.
20104	There was a problem restoring the selected file to the sensor.	Call Banner Customer Support.
20105	There was a problem creating the backup of the sensor.	Call Banner Customer Support.
20150	Connection to the emulator failed.	Call Banner Customer Support.
20151	There was an error starting the emulator.	<ul style="list-style-type: none"> <li>• Reinstall this application</li> <li>• Check firewall setup on computer</li> </ul>
20152	The selected emulator could not be found.	<ul style="list-style-type: none"> <li>• Reinstall this application</li> <li>• Check firewall setup on computer</li> </ul>
20153	There was a problem closing the previous emulator session.	Reboot the computer to end processes which did not shut down properly.
20154	There was a problem closing the previous emulator session.	Reboot the computer to end processes which did not shut down properly.
20155	There was a problem closing the previous emulator session.	Reboot the computer to end processes which did not shut down properly.
20156	There was a problem closing the previous emulator session.	Reboot the computer to end processes which did not shut down properly.
20157	There was an error starting the emulator.	<ul style="list-style-type: none"> <li>• Reinstall this application</li> <li>• Check firewall setup on computer</li> </ul>
20158	There was an error starting the emulator.	<ul style="list-style-type: none"> <li>• Reinstall this application</li> <li>• Check firewall setup on computer</li> </ul>
20159	There was an error starting the emulator.	<ul style="list-style-type: none"> <li>• Reinstall this application</li> <li>• Check firewall setup on computer</li> </ul>
20160	Another emulator session is currently running. Only one emulator session can be run at a time.	<ul style="list-style-type: none"> <li>• Close the other Vision Manager currently connected to the emulator</li> <li>• Reboot the computer to end processes which did not shut down properly</li> </ul>
20203	Uploading the image to the sensor failed due to timeout.	<ul style="list-style-type: none"> <li>• Reboot the sensor</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>

Error Code	Description	Recommended Solution
20208	Downloading the inspection from the sensor failed due to a timeout.	<ul style="list-style-type: none"> <li>• Reboot the sensor</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
20209	Inspection download invalid parameter.	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20210	Downloading the inspection from the sensor failed (inspection not found).	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20211	Downloading the inspection from the sensor failed (invalid header detected).	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20212	Downloading the inspection from the sensor failed (incompatibility detected).	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20215	Uploading the inspection to the sensor failed due to a timeout.	<ul style="list-style-type: none"> <li>• Reboot the sensor</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
20216	Uploading the inspection to the sensor failed due to a invalid parameter.	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20219	Upload inspection to sensor failed. The inspection being uploaded contains features which are not compatible with the sensor.	<ul style="list-style-type: none"> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>




Error Code	Description	Recommended Solution
20231	A firmware update error was detected.	<ul style="list-style-type: none"> <li>• Verify the sensor is energized</li> <li>• Verify sensor not stalled, or in shutdown mode</li> <li>• Reboot the sensor</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
20232	A firmware update timeout was detected.	<ul style="list-style-type: none"> <li>• Reboot the sensor</li> <li>• Verify the sensor ethernet cable is connected</li> <li>• Verify all inline network equipment is energized, properly configured and connect</li> <li>• Verify network equipment cables connected</li> <li>• Verify network adaptor properly configured</li> <li>• Verify the sensor IP address valid</li> <li>• Verify there are no other devices using the same IP address</li> <li>• Verify sensor subnet valid</li> <li>• Verify the sensor can be successfully pinged</li> <li>• Verify network firewall settings support connection to the sensor</li> </ul>
20233	A maintenance service internal error was detected.	<ul style="list-style-type: none"> <li>• Go to Sensor Neighborhood and reconnect to the sensor</li> <li>• Reboot the sensor</li> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
20400	An application error occurred while applying the new industrial protocol settings. The settings will be reverted to their previous value.	<ul style="list-style-type: none"> <li>• Update sensor firmware to latest version</li> <li>• Update the Vision Manager Application to the latest version</li> </ul>
30151	Firmware update cannot proceed. Selected sensor may be connected to another Vision Manager application	Disconnect the other application and try again.
30152	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30153	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30154	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30155	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30156	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30157	Firmware update cannot be completed due to internal error.	Reboot the sensor.
30199	Firmware update cannot be completed due to internal error.	Call Banner Customer Support.

# 15 Accessories



## 15.1 Cordsets

All measurements are listed in millimeters [inches], unless noted otherwise.

Power, Discrete I/O Cordsets  
I/O sealed high-flex cordsets, 12 flying leads

12-Pin M12/Euro-Style Cordsets with Open Shield				
Model	Length	Style	Dimensions	Pinout (Female)
MQDC2S-1206	1.83 m (6 ft)	Straight		 <ul style="list-style-type: none"> <li>1 = White</li> <li>2 = Brown</li> <li>3 = Green</li> <li>4 = Yellow</li> <li>5 = Gray</li> <li>6 = Pink</li> <li>7 = Blue</li> <li>8 = Red</li> <li>9 = Orange</li> <li>10 = Light Blue</li> <li>11 = Black</li> <li>12 = Violet</li> </ul>
MQDC2S-1215	4.57 m (15 ft)			
MQDC2S-1230	9.14 m (30 ft)			
MQDC2S-1250	15.2 m (50 ft)			
MQDC2S-1275	22.9 m (75 ft)			
MQDC2S-1206RA	1.83 m (6 ft)	Right Angle		
MQDC2S-1215RA	4.57 m (15 ft)			
MQDC2S-1230RA	9.14 m (30 ft)			
MQDC2S-1250RA	15.2 m (50 ft)			

### Ethernet Cordsets

RJ45 Ethernet to 8-Pin Threaded M12/Euro-Style Cordsets				
Model	Length	Style	Dimensions	Pinout
STP-M12-806	1.83 m (6 ft)	Straight, Cat5e Shielded		 <ul style="list-style-type: none"> <li>1 = White/Black</li> <li>2 = White/Brown</li> <li>3 = Brown</li> <li>4 = Orange</li> <li>5 = White/Green</li> <li>6 = White/Orange</li> <li>7 = Blue</li> <li>8 = Green</li> </ul>
STP-M12-815	4.57 m (15 ft)			
STP-M12-830	9.14 m (30 ft)			

The following Ethernet cables are used with 4-pin D-code Ethernet models only.


Model	Description
BWA-E2M	Ethernet cable, RSCD RJ45 440, 2 m (6.6 ft)
BWA-E8M	Ethernet cable, RSCD RJ45 440, 8 m (26.2 ft)

## 15.2 Brackets

All measurements are listed in millimeters [inches], unless noted otherwise.


SMBVERA

- Right-angle mounting bracket with curved slots
- 12-gauge stainless steel
- M3 x 0.5 mounting hardware included



SMBVEMP

- Painted black aluminum
- Adapter holes for mounting hardware



## 15.3 Lenses

Additional models are available. See [www.bannerengineering.com](http://www.bannerengineering.com).

Table 32: C-Mount Megapixel Lens Focal Length—For use with WVGA, 1.3MP, or 2MP models

Manufacturer	5 mm	6 mm	8 mm	12 mm	16 mm	25 mm	35 mm	50 mm	75 mm
Computar	LCF05LCMP <sup>9</sup>	-	LCF08LMP	LCF12LMP	LCF16LCMP	LCF25LCMP	LCF35LCMP	LCF50LCMP	LCF75LCMP
Evetar	-	LCF06LEVMP <sup>9</sup>	LCF08LEVMP	LCF12LEVMP <sup>9</sup>	LCF16LEVMP	LCF25LEVMP	LCF35LEVMP	LCF50LEVMP <sup>9</sup>	LCF75LEVMP <sup>9</sup>
Edmund Optics	-	-	LCF08LEMP	LCF12LEMP	LCF16LEMP <sup>9</sup>	LCF25LEMP <sup>9</sup>	LCF35LEMP <sup>9</sup>	-	-
Tamron	-	-	LCF08LTMP <sup>9</sup>	-	LCF16LTMP	LCF25LTMP	-	LCF50LTMP	-

Table 33: C-Mount Standard Lens Focal Length—For use with WVGA models only

4 mm	8 mm	12 mm	16 mm
LCF04	LCF08	LCF12	LCF16

### 15.3.1 WVGA Lens Working Distance and Field of View

For use with VE200G1A models.

Table 34: C-Mount Standard Lens Focal Length—Working Distance and Field of View

	4 mm <sup>10</sup>	8 mm	12 mm	16 mm
WD (mm)	Approximate Horizontal x Vertical Field of View (FOV) in mm			
150	162 x 103	71 x 45	46 x 29	32 x 20
600	656 x 419	303 x 193	198 x 126	141 x 90
1500	1646 x 1050	767 x 489	500 x 319	360 x 230
FOV (mm)	Approximate Working Distance (WD) in mm			
100 x 64	94	206	310	430
300 x 192	276	594	905	1253
600 x 384	549	1177	1798	2488

<sup>9</sup> For 2 MP lenses only: Denotes specific lens used for WD and FOV example.

<sup>10</sup> Using a 0.25 mm spacer (LEKS).




Figure 340. Working Distance and Field of View

### 15.3.2 1.3 MP Lens Working Distance and Field of View

For use with VE201G1A models.

Table 35: C-Mount Megapixel Lens Focal Length—Working Distance and Field of View

	6 mm	8 mm	12 mm	16 mm	25 mm	35 mm	50 mm	75 mm
WD (mm)	Approximate Horizontal × Vertical Field of View (FOV) in mm							
150	130 × 104	100 × 80	66 × 53	-	-	-	-	-
600	629 × 503	469 × 375	318 × 254	229 × 183	147 × 118	111 × 89	71 × 57	-
1500	1628 × 1302	1207 × 966	822 × 658	598 × 478	381 × 305	289 × 231	191 × 153	124 × 99
FOV (mm)	Approximate Working Distance (WD) in mm							
100 × 80	123	151	211	286	420	547	820	1227
300 × 240	303	395	569	774	1189	1557	2312	3474
600 × 480	574	760	1104	1505	2343	3072	4551	6845




Figure 341. Working Distance and Field of View

### 15.3.3 2 MP Lens Working Distance and Field of View

For use with VE202G1A and VE202G2A models.

Table 36: C-Mount Megapixel Lens Focal Length—Working Distance and Field of View

	5 mm	6 mm	8 mm	12 mm	16 mm	25 mm	35 mm	50 mm	75 mm
WD (mm)	Approximate Horizontal × Vertical Field of View (FOV) in mm								
150	188 × 141	140 × 105	126 × 95	72 × 54	55 × 41	36 × 27	-	-	-
600	822 × 617	663 × 498	549 × 411	340 × 255	259 × 194	164 × 123	114 × 86	75 × 56	47 × 35
1500	2091 × 1568	1710 × 1283	1393 × 1045	874 × 656	667 × 500	422 × 317	300 × 225	205 × 154	132 × 99
FOV (mm)	Approximate Working Distance (WD) in mm								
100 × 75	88	-	122	196	248	376	531	774	1160
300 × 225	229	288	335	533	690	1074	1500	2161	3263
600 × 450	442	545	655	1038	1353	2120	2950	4241	6417




Figure 342. Working Distance and Field of View

## 15.4 C-Mount Lens Filter Models

Use filters to improve the image contrast and system reliability in vision applications.

For additional filter information, see p/n 173239.

Family	Color	-	Size
FLT	B470 ( Blue) G525 (Green) I850 (Infrared) R635 (Red) R660 (Dark Red) PR032 (Linear Polarizer)	- (dash)	25.5 (25.5 mm) 27 (27 mm) 30.5 (30.5 mm) 34 (34 mm) 43 (43 mm)

Filters are available in three sizes, specific to the inside thread diameter of the lens. Use the table below to select the corresponding filter for each C-mount lens available through Banner Engineering.

Size	Lens Option
25.5 mm	Edmund Optics, Tamron
27 mm	Ricoh, Evetar (8 mm, 12 mm, 16 mm, 25 mm, 35 mm)
30.5 mm	Computar (8 mm, 12 mm, 16 mm, 25 mm, 35 mm, 50 mm, 75 mm), Evetar (50 mm)
34 mm	Evetar (6 mm, 75 mm)
43 mm	Computar (5 mm)



**Important:** These filters are for the C-mount lens only. Depending on the lighting technique used, a polarizing filter may be needed for both the lens and the light source. See [www.bannerengineering.com](http://www.bannerengineering.com) for Banner's selection of light filters.

## 15.5 Lens Cover

When used, the optional lens covers offer an IP67 rating for the sensor for wet or dirty environments. The cover is painted black aluminum.


Model	Length	Material	Window Material
VELC60-PC	60 mm	Painted aluminum	Polycarbonate
VELC60-BG			Borosilicate glass
VELC85-PC	85 mm		Polycarbonate
VELC85-BG			Borosilicate glass

## 15.6 Display Cover

Use the Display Cover to protect the display and buttons from the elements.

### VEDC-BD

- Painted anodized aluminum with borosilicate glass window
- Mounting hardware included



## 15.7 Ring Lights

For additional ring light information, see p/n 192656 for standard lights and p/n 192657 for high intensity lights. Additional (standalone) lights are available. See [www.bannerengineering.com](http://www.bannerengineering.com).

### Standard Ring Lights

62 × 62 mm Models	80 × 80 mm Models	Color	Connection
LEDIRV62X62M	LEDIRV80X80M	Infrared, 940 nm	300 mm (12 in) cable with a threaded 3-pin Pico-style connector
LEDRRV62X62M	LEDRRV80X80M	Visible red, 630 nm	
LEDWRV62X62M	LEDWRV80X80M	White, all visible	
LEDBRV62X62M	LEDBRV80X80M	Visible blue, 464 nm to 475 nm	
LEDGRV62X62M	LEDGRV80X80M	Visible green, 520 nm to 540 nm	

### High Intensity Ring Lights

Model	LED Color	Intensity Adjustment	Connection
LEDRRV70XD5-XM	Visible red, 620 nm to 630 nm	Fixed	300 mm (12 in) cable with a threaded 3-pin Pico-style connector <sup>11</sup>
LEDWRV70XD5-XM	White, 5000 K to 8300 K		
LEDBRV70XD5-XM	Visible blue, 465 nm to 485 nm		
LEDGRV70XD5-XM	Visible green, 520 nm to 535 nm		
LEDIRV70XD5-XM	Infrared, 850 nm		
LEDUV395RV70XD5-XM	Ultraviolet, 395 nm	Potentiometer	
LEDRRV70XD5-PM	Visible red, 620 nm to 630 nm		
LEDWRV70XD5-PM	White, 5000 K to 8300 K		
LEDBRV70XD5-PM	Visible blue, 465 nm to 485 nm		
LEDGRV70XD5-PM	Visible green, 520 nm to 535 nm		
LEDIRV70XD5-PM	Infrared, 850 nm		
LEDUV395RV70XD5-PM	Ultraviolet, 395 nm		

## 15.8 Interface Module

For additional interface module information, see p/n 193821.

Models	Trigger	Connections
VESIM-PT	Current Sourcing (PNP)	Two 13-pin Terminals

<sup>11</sup> Connects directly to the VE Series smart cameras

## 15.9 Product CD

---

Part Number	Description
97733	CD that includes the Vision Manager software and applicable documentation. Available for purchase for those without access to download the software and documentation from the internet.

# 16 Product Support and Maintenance

## 16.1 Repairs

Contact Banner Engineering for troubleshooting of this device. Do not attempt any repairs to this Banner device; it contains no field-replaceable parts or components. If the device, device part, or device component is determined to be defective by a Banner Applications Engineer, they will advise you of Banner's RMA (Return Merchandise Authorization) procedure.



Important: If instructed to return the device, pack it with care. Damage that occurs in return shipping is not covered by warranty.

## 16.2 Maintenance

Maintenance tasks include keeping the hardware free of dust and dirt and updating the Vision Manager software and sensor firmware as new versions become available.

### 16.2.1 Clean the Sensor

Regularly remove any dust or dirt from the sensor using a soft cloth.

If needed, slightly dampen the cloth with a weak solution of neutral detergent. Avoid getting dirt on the imager (the area behind the lens). If the imager is dirty, use anti-static compressed air to blow off the dust.

### 16.2.2 Clean the Lens

Regularly remove dust, dirt, or fingerprints from the lens.

Use anti-static compressed air to blow off dust. If necessary, use a lens cloth and lens cleaner or window cleaner to wipe off remaining debris.

### 16.2.3 Update the Software and Firmware

The current version of Vision Manager software and the sensor firmware is available for download from [www.bannerengineering.com](http://www.bannerengineering.com).

## 16.3 Contact Us

### Corporate Headquarters

Address:  
Banner Engineering Corporate  
9714 Tenth Avenue North  
Minneapolis, Minnesota 55441, USA

Phone: +1 763 544 3164  
Website: [www.bannerengineering.com](http://www.bannerengineering.com)

### Europe

Address:  
Banner Engineering EMEA  
Park Lane Culliganlaan 2F  
Diegem B-1831, Belgium

Phone: +32 (0)2 456 0780  
Website: [www.bannerengineering.com/eu](http://www.bannerengineering.com/eu)  
Email: [mail@bannerengineering.com](mailto:mail@bannerengineering.com)

### Turkey

Address:  
Banner Engineering Turkey  
Barbaros Mah. Uphill Court Towers A Blok D: 49  
34746 Batı Ataşehir İstanbul Türkiye

Phone: +90 216 688 8282  
Website: [www.bannerengineering.com.tr](http://www.bannerengineering.com.tr)  
Email: [turkey@bannerengineering.com.tr](mailto:turkey@bannerengineering.com.tr)

### India

Address:  
Banner Engineering India Pune Head Quarters  
Office No. 1001, 10th Floor Sai Capital, Opp. ICC Senapati Bapat Road  
Pune 411016, India

Phone: +91 (0) 206 640 5624  
Website: [www.bannerengineering.co.in](http://www.bannerengineering.co.in)  
Email: [salesindia@bannerengineering.com](mailto:salesindia@bannerengineering.com)

## Mexico

Address:  
Banner Engineering de Mexico Monterrey Head Office  
Edificio VAO Av. David Alfaro Siqueiros No.103 Col. Valle Oriente C.P.66269  
San Pedro Garza Garcia, Nuevo Leon, Mexico

Phone: +52 81 8363 2714 or 01 800 BANNERE (toll free)  
Website: [www.bannerengineering.com.mx](http://www.bannerengineering.com.mx)  
Email: [mexico@bannerengineering.com](mailto:mexico@bannerengineering.com)

## Brazil

Address:  
Banner do Brasil  
Rua Barão de Teffé nº 1000, sala 54  
Campos Elíseos, Jundiaí - SP, CEP.: 13208-761, Brasil

Phone: +1 763 544 3164  
Website: [www.bannerengineering.com.br](http://www.bannerengineering.com.br)  
Email: [brasil@bannerengineering.com](mailto:brasil@bannerengineering.com)

## China

Address:  
Banner Engineering Shanghai Rep Office  
Xinlian Scientific Research Building Level 12, Building 2  
1535 Hongmei Road, Shanghai 200233, China

Phone: +86 212 422 6888  
Website: [www.bannerengineering.com.cn](http://www.bannerengineering.com.cn)  
Email: [sensors@bannerengineering.com.cn](mailto:sensors@bannerengineering.com.cn)

## Japan

Address:  
Banner Engineering Japan  
Cent-Urban Building 305 3-23-15 Nishi-Nakajima Yodogawa-Ku  
Osaka 532-0011, Japan

Phone: +81 (0)6 6309 0411  
Website: [www.bannerengineering.co.jp](http://www.bannerengineering.co.jp)  
Email: [mail@bannerengineering.co.jp](mailto:mail@bannerengineering.co.jp)

## Taiwan

Address:  
Banner Engineering Taiwan  
8F-2, No. 308 Section 1, Neihu Road  
Taipei 114, Taiwan

Phone: +886 (0)2 8751 9966  
Website: [www.bannerengineering.com.tw](http://www.bannerengineering.com.tw)  
Email: [info@bannerengineering.com.tw](mailto:info@bannerengineering.com.tw)

## 16.4 Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com).

# Index

## A

- absolute threshold
  - edge profile 81, 90, 109
  - value 80, 90, 109
- Active Sensors tab 22
- adaptive threshold
  - bead type 55, 69
  - blob type 55, 69
- All Results 29
- area 74
- area range 70
- auto exposure 45
- Average Gray tool
  - test parameters 51
  - input parameters 49–51
  - results 52
  - using 52

## B

- backup 25, 130
- Bead tool
  - bead width 56
  - filters 56
  - input parameters 53–57
  - results 58
  - ROI 54, 59
  - test parameters 58
  - using 61
- bead type
  - adaptive threshold 55, 69
  - fixed threshold 55
- Blemish tool
  - input parameters 64–66
  - results 67
  - test parameters 66
  - using 67
- blob statistics 70
- Blob tool
  - input parameters 68–72
  - results 73–76
  - statistics 70
  - test parameters 72
  - using 76
- blob type
  - adaptive threshold 55, 69
  - fixed threshold 55
- bracket 208
- buttons
  - lock 131

## C

- Camera tool
  - results 48
  - using 45–48
- centroid 74
- characteristics
  - Measure tool 121

- communications 36–38
- compactness 75
- copy 20, 32
- cordset 208
- cover
  - lens 211

## D

- DAP 176
- data model 176
- delete
  - inspection 20, 32
  - tool 20
  - tool and tools after 20
- Device Access Point
  - See DAP
- device control 179
- discrete I/O
  - configure 21
- display 131–134
- DISPLAY 134
- display menu 134
- duplicate 20

## E

- eccentricity 76
  - edge length range
    - Blemish tool 65
  - edge polarity 80–82, 89–91
  - edge profile
    - absolute threshold 81, 90, 109
    - edge strength threshold 83, 91, 110
    - relative threshold 82, 89, 108
  - edge strength threshold
    - edge strength 82, 91, 109
  - Edge tool
    - input parameters 79–84
    - results 85
    - test parameters 85
    - using 86, 123
  - emulator
    - backup 25, 130
    - restore 25, 130
  - ETHER 133
  - Ethernet
    - communications 136
    - settings 36
  - EtherNet/IP 37
  - export
    - system logs 39
  - exposure
    - auto 45
  - external strobe 47
- ## F
- factory default 44

## Favorites tab

- add 23
- remove 23
- filters
  - Bead tool 56
  - blob tool 71
  - Edge tool 83
  - lens 12, 211
  - Locate tool 92
  - Object tool 110
- firmware
  - update 24
  - version 24, 25
- fixed threshold
  - bead type 55
  - blob type 55
- focus information 47

## G

- gain 45
- Generic Station Description
  - See GSD
- GSD
  - Install 184

## H

- histogram
  - See tool histogram
- Home screen 22–26

## I

- I/O
  - discrete 34, 36
  - summary 27
- IMAGE 133
- image export
  - settings 38
- image menu 133
- image overlays 50, 56, 65, 71, 84, 93, 101, 111, 121
- imager 45
- indicators, LED 7
- Industrial Protocols 37
- INFO 133
- information menu 133
- Input/Output 133
- inspection
  - begin at startup 33
  - copy 32
  - delete 20, 32
  - manage 32, 33
  - modify 19
  - name 19
  - save 19, 33
  - set up 17–20
  - summary 27

- transfer 33
- Inspection Logs
  - sources 30
- Inspection Logs screen 30, 31
- Inspection Management screen 31–33
- inspection results 178
- interface 131
- interface module 212
- IO 133

## L

- lens
  - 1.3 MP 210
  - 2 MP 210
  - cover 12, 211
  - filter 12, 211
  - WVGA 209
- light
  - ring 12, 212
- Locate tool
  - input parameters 88–93
  - results 94
  - test parameters 94
  - using 95
- Logic tool
  - input parameters 125–127
  - results 127
  - test parameters 127
  - using 127
- logs
  - inspection 30, 31
  - system logs 39

## M

- major axis angle 75
- major axis length 75
- Manage 32, 33
- mask
  - add 50, 54, 64, 69
  - delete 50, 54, 64, 69
- Match tool
  - input parameters 98–102
  - remote TEACH 106
  - results 103
  - test parameters 102
  - using 104
- Math tool
  - input parameters 115–117
  - operand A 116
  - operand B 117
  - operator 115
  - results 117
  - test parameters 117
  - using 118
- max radius 76
- max radius position 76
- measure from 121
- measure to 121
- Measure tool

- characteristics 121
- input parameters 120–122
- measure from 121
- measure to 121
- results 122
- test parameters 122
- min radius 76
- min radius position 76
- minor axis length 75
- Modbus/TCP 37
- models 6

## N

- Network Adapters tab 24

## O

- Object tool
  - input parameters 106–112
  - results 112
  - test parameters 112
  - using 113
- object type 108, 109
- operand 115, 125
- operand A 116
- operand B 117
- operation 115
- operator 115

## P

- pattern
  - Match tool 99
- PC Requirements 9
- PCCC 37
- PCHANGE 133
- percent
  - relative threshold 81, 89, 108
- percent match 100
- perimeter 74
- pixel intensity range 50
- precision 100
- product change 133
- PROFINET 37

## R

- reboot 44
- REBOOT 134
- reboot menu 134
- reject level 55, 56, 70
- relative threshold
  - edge profile 82, 89, 108
  - percent 81, 89, 108
- remote TEACH
  - Match tool 106
- reset 44
- restore 25, 130
- results
  - Average Gray tool 52

- Bead tool 58
- Blemish tool 67
- Blob tool 73–76
- Camera tool 48
- Edge tool 85
- Locate tool 94
- Logic tool 127
- Match tool 103
- Math tool 117
- Measure tool 122
- Object tool 112
- ring light 12, 212
- ROI (Region of Interest)
  - Bead tool 54, 59
  - search 99
  - teach 99
- rotation range 100

## S

- save 19, 33
- scale units 42
- screen
  - Home 22–26
  - Inspection Logs 30, 31
  - Inspection Management 31–33
  - Sensor 26–29
  - System Settings 34, 36–39, 41, 42, 44
- search ROI 99
- sensitivity 65
- sensor
  - backup 25
  - boot count 34
  - firmware version 34
  - gateway 34
  - hour count 34
  - IP address 34
  - MAC address 34
  - menu 132
  - model number 34
  - name 34
  - reset 44
  - restore 25
  - serial number 34
  - subnet mask 34
- Sensor Maintenance 24, 25
- Sensor Neighborhood 22–24
- Sensor screen 26–29
- software
  - information 26
  - version number 26
  - Vision Manager 8
- strobe
  - external 47
- submodule description 178, 179, 182, 183
- supported submodules 178, 179, 182, 183
- SYSERR 134
- system error menu 134

System Settings screen 34,  
36–39, 41, 42, 44

## T

### tab

- About 26
- Active Sensors 22
- All Results 29
- Favorites 23
- Network Adapters 24
- Tools & Results 28
- Tools Only 28

### TEACH

, See remote TEACH

teach ROI 99

### test

- Average Gray tool 51
- Bead tool 58
- Blemish tool 66
- Blob tool 72
- Edge tool 85
- Locate tool 94
- Logic tool 127
- Match tool 102
- Math tool 117

Measure tool 122

Object tool 112

### threshold

- absolute 80, 81, 90, 108,  
109
- adaptive 54, 55, 69, 70
- edge polarity 80–82, 89–91
- edge strength 82, 83, 91,  
109, 110
- fixed 55, 56, 70
- object type 108, 109
- reject level 55, 56, 70
- relative 81, 82, 89, 107,  
108

timeout 100

### tool

- add 17
- Average Gray 49–52
- Bead 53–59, 61
- Blemish 63–67
- Blob 68–76
- copy 20
- delete 20
- delete tool and after 20
- Edge 79–86

Locate 87–95

Logic 125–127

Match 98–104, 106

Math 115–118

Measure 119–123

Object 106–113

rename 18

tool histogram 51, 57, 66, 72,  
84, 93, 102, 111

Tools & Results 28

Tools Only 28

Transfer 33

trigger 46

trigger mode 138

## U

Units 41, 42

use as reference 92, 101

## V

Vision Manager

about 26

version number 26