# WLS15 Pro LED Strip Light



## Instruction Manual

Banner's WLS15 LED Strip Lights have sturdy aluminum inner frames, encased in shatter resistant, UV-stabilized, polycarbonate shells, making them ideal for indoor and outdoor applications.



- Bright, programmable strip light with RGB LEDs
  19 color options for varied indication and inspection uses
  Programmable using Banner's Pro Editor software and Pro Converter Cable
  Pro Editor software configuration and three discrete inputs gives access to color, flashing, intensity, and animation settings, as well as advanced operating modes for displaying distance, count, time and position
- Available in six lengths from 220 mm to 1200 mm
- Low-profile, space-saving design
- Rugged, water-resistant design



**Important:** Read the following instructions before operating the light. Please download the complete WLS15 Pro LED Strip Light technical documentation, available in multiple languages, from www.bannerengineering.com for details on the proper use, applications, Warnings, and installation instructions of this device.




Important: Lea el siguiente instructivo antes de operar el luminario. Por favor descargue desde www.bannerengineering.com toda la documentación técnica de los WLS15 Pro LED Strip Light, disponibles en multiples idiomas, para detalles del uso adecuado, aplicaciones, advertencias, y las instrucciones de instalación de estos dispositivos.



**Important:** Lisez les instructions suivantes avant d'utiliser le luminaire. Veuillez télécharger la documentation technique complète des WLS15 Pro LED Strip Light sur notre site www.bannerengineering.com pour les détails sur leur utilisation correcte, les applications, les notes de sécurité et les instructions de montage.

#### Models



## Configuration Instructions

### Pro Editor




Use Banner's Pro Editor software and Pro Converter Cable to create custom configurations by selecting different colors, flash patterns, and animations. For more information visit www.bannerengineering.com/proeditor.

13 April 2021

### Full Preview Connection (Required)

The full preview connection must be used for the TL50 Pro Tower Light, the K90 Pro Indicator, and for Pro-series Strip Lights, and is optional but recommended for other Pro-series enabled devices.



- A = Pro Converter Cable (MQDC-506-USB)
- B = Splitter (CSB-M1251FM1251M)
- C = PC running Pro Editor software
- D = Any Banner Pro Series-enabled device (K50 shown)
- E = Power Supply (PSW-24-1 or PSD-24-4)

F = 8-Pin to 5-Pin Double-Ended Cordset (MQDC-801-5M-PRO), required for 8-Pin models

## Wiring Diagrams

Male	Pin	Wire Color	Description 1
2 4	1	Brown	Input 1
	2	White	Input 3
	3	Blue	DC common
	4	Black	Input 2

7 Color Binary Control (Binary input state controls color, default configuration)					
Input 1: Pin 1 Brown Wire	Input 2: Pin 4 Black Wire	Input 3: Pin 2 White Wire	LED Color		
_	-	_	Light OFF		
12 V DC to 30 V DC	_	_	Red		
_	12 V DC to 30 V DC	_	Green		
_	_	12 V DC to 30 V DC	Yellow		
12 V DC to 30 V DC	12 V DC to 30 V DC	_	Blue		
12 V DC to 30 V DC	_	12 V DC to 30 V DC	Daylight White		
_	12 V DC to 30 V DC	12 V DC to 30 V DC	Daylight White with Red Ends Flash		
12 V DC to 30 V DC	12 V DC to 30 V DC	12 V DC to 30 V DC	Blue Bounce with Daylight White Background		

#### Pro Editor Configuration for the WLS15 Pro

Banner's Pro Editor software offers an easy way to configure Pro Series-enabled touch and indicator devices, allowing users full control of device states. The easy-to-use configuration software provides a variety of tools and capabilities to solve a wide range of applications. Configure any Pro Series-enabled device using the free Pro Editor software, available for download at <a href="https://www.bannerengineering.com/proeditor">www.bannerengineering.com/proeditor</a>.

Machine and Work Cell—Choose colors and animations to create up to seven discretely controlled illumination and status states. Spans functionality from single segment to two-colored animations.

Single Segment—The single segment option shows the WLS15 in one solid color. The input wires are used to change colors. Flashing and intensity options are available. Presets are available for common configurations, which can be adjusted as desired.

**End Status**—The end status option shows the inside section of the WLS15 in one color and the ends of the light in another. The size of the two sections are customizable. The input wires are used to change color states. Flashing and intensity options are available.

**Process Visualization**—The process visualization option enables a choice of colors, animations, speeds, and intensities to provide visual information that corresponds to equipment or process status. Single color illumination states are also available.

**Tower Light**—Choose colors, intensities, and animations to create a discretely controlled two or three segment indicator. The segments are controlled independently with input wires.

Mobile—Choose colors and animations to create states that can be used for advanced and intuitive indication on mobile equipment.

Basic Warning—Choose colors, intensities, and animation to create a discretely controlled three segment indicator for communication of equipment status. The segments are controlled independently with input wires.

<sup>1</sup> Input functionality can change depending on configuration created with Pro Editor. Refer to wiring diagrams in selected mode in Pro Editor.

**Advanced Warning**—Create up to seven discretely controlled status indicators, and use presets for Loading and Emergency Stop conditions. Colors, animations, speeds, and intensities provide equipment status.

Timer—The timer option uses the WLS15 as a timer, counting up or counting down. Set the total time and choose up to four thresholds to change the visual appearance of the light as time advances. The timer starts when 12 V DC to 30 V DC is applied to the timer run input wire (pin 2 or white wire), and paused when left floating or tied to ground. The timer resets when 12 V DC to 30 V DC is applied to the reset wire (pin 4 or black wire). The timer automatically resets when it reaches the final count. A steady global background or threshold markers can be applied, from which color and intensity can be defined.

Counter—The counter option counts up or down by converting input pulses into movement of LEDs along the length of the light based on up to four thresholds that define colors, intensity, and flashing. When the rising edge of an 12 V DC to 30 V DC pulse is applied to the counter input wire (pin 2 or white wire), the count increases by one. The user can choose whether the counter resets or the count decreases by one when 12 V DC to 30 V DC is applied to the control input wire (pin 4 or black wire). The counter automatically resets when it reaches the final count. A steady global background or threshold markers can be applied, from which color and intensity can also be defined.

Pick Put Build—Choose colors and animations to create states that can be used to guide operators, signal material status, enable light-guided assembly, create pick-to-light operations, and enable kitting operations.

Basic Segment—Choose colors, intensities, and animation to create a discretely controlled two or three segment indicator for communication of processes.

Advanced Segment – Enable up to seven discretely controlled segments to be used as individual indications states. Only one segment can be enabled at once.

**Distance**—The distance mode uses the light to display colored LEDs proportional to a PFM (pulse frequency modulation) or PWM (pulse width modulation) input and set range or with discretely controlled levels.

**Distance**—The light adjusts position and color continuously based on the PFM or PWM input value (pin 2 or white wire) and defined color, flash, and intensity in up to four thresholds while maintaining an optional steady background for LEDs outside the active threshold range. Threshold markers can be applied, from which color and intensity can also be defined. The PFM signal frequency range can be from 100 to 10,000 Hz. The PWM duty cycle range can be from 0 to 100%.

Coarse Distance—Choose colors, intensities, and flash patterns to create up to seven discretely controlled levels based upon input wiring logic states for simple distance and level indication.

Gauge—The gauge option controls the color and position of a band of LEDs based on a defined PFM or PWM input value (pin 2 or white wire) and range. The width of the band is defined as a percentage of total lighted length. The light adjusts the position and color of the band and background continuously based on the input signal and defined color, flash, intensities, and animations in upper, lower, and center thresholds. Threshold markers can be applied, from which color and intensity can also be defined. The PFM signal frequency range can be from 100 to 10,000 Hz. The PWM duty cycle range can be from 0 to 100%.

#### **Animation Settings**

Animation	Description
Off	Device OFF, no animation displays
Steady	Color 1 is solid ON at the defined intensity
Flash	Color 1 flashes at the defined speed, color intensity, and pattern (normal, strobe, three pulse, SOS, or random)
Two Color Flash	Color 1 and Color 2 flash alternately at the defined speed, color intensities, and pattern (normal, strobe, three pulse, SOS, or random)
Two Color Shift	Color 1 and Color 2 flash alternately on adjacent LEDs at defined speed and color intensities
Ends Steady	Color 1 defines the center 75% of the light. Color 2 defines the 12.5% of the light on each end. Center and ends are on steady. Center proportion can be defined in <b>End Status</b> mode
Ends Flash	Color 1 defines the center 75% of the light. Color 2 defines the 12.5% of the light on each end. The ends will flash at defined speed and pattern. Center proportion can be defined in <b>End Status</b> mode
Scroll	Color 1 defines a band 20% of the length of the light that moves in one direction up or down against the background of Color 2 at the defined speed and color intensities
Center Scroll	Color 1 defines a band 10% the length of the light that moves from the center of the light to the ends against the background of Color 2 at the defined speed and color intensity
Bounce	Color 1 defines a band 20% of the length of the light that moves up and down between the top and bottom of the light against the background of Color 2 at the defined speed and color intensities
Center Bounce	Color 1 defines a band 10% the length of the light that moves from the center of the light to the ends and back against the background of Color 2 at the defined speed and color intensity
Intensity Sweep	Color 1 continuously increases and decreases intensity between 0% to 100% at defined speed and color intensity
Two Color Sweep	Color 1 and Color 2 define the end values of a line across the color gamut. The light continuously displays a color by moving along the line at the defined speed and color intensity
Color Spectrum	The light scrolls through the 13 predefined colors with a different color on each LED at the defined speed, Color 1 intensity, and direction
Single End Steady	Color 1 is solid ON at the defined intensity on one end of the device
Single End Flash	Color 1 flashes at the defined speed, color intensity, and pattern (normal, strobe, three pulse, SOS, or random) on one end of the device

By default, when the sub-applications for Machine and Work Cell are selected, Pro Editor opens I/O State configuration in Advanced. Three I/O states are available:

I/O State Configuration Settings	Description
Basic	Configurations made in this state assign one wire to one state, with the following override control:  • Pin 4 (Black) overrides Pin 1 (Brown)  • Pin 2 (White) overrides Pins 1 and 4 (Brown and Black)
Advanced	I/O state with full seven state options for maximum configuration. Configurations made in Advanced assign binary wiring combinations of all valid inputs to each state.
I/O Block	Three state control for use with I/O block. Configurations made in I/O Block assign states to the black, white, and combination of black and white wires for use with I/O blocks for which power (brown) and common (blue) are always on for five pin connections.

## Specifications

Supply Voltage
12 V DC to 30 V DC
Use only with suitable Class 2 power supply (UL) or a SELV power supply (CE) See electrical characteristics on product label

Light Length	Typical Current	Maximum Current		
	12 V DC	24 V DC	30 V DC	A
0220 mm	0.120	0.060	0.050	0.125
0360 mm	0.240	0.120	0.100	0.250
0500 mm	0.360	0.180	0.150	0.375
0640 mm	0.480	0.240	0.200	0.500
0920 mm	0.720	0.360	0.300	0.750
1200 mm	0.960	0.480	0.400	1.000

Supply Protection Circuitry
Protected against reverse polarity and transient voltages



**Note:** Do not spray cable with high-pressure sprayer, or cable damage will result.

#### Input Rating

John Adulty
Leakage Current Immunity: 400 μA
Indicator On/Off Response Time: 300 ms (maximum)
PWM Input Characteristics

Duty Cycle Range: 0 to 100%

Constant Frequency Range: 100 to 10000 Hz

PFM Input Characteristics

Frequency Range: 100 to 10000 Hz
Constant Duty Cycle Range: 10 to 90%

#### Construction

Clear anodized aluminum housing Polycarbonate outer housing Polyamide end caps

#### Light Characteristics

RGB LED PWM Frequency: 1kHz

2 m (6.5 ft) integral PVC cable 150 mm (6 in) PVC cable with a 4-pin M12 male quick disconnect Models with a quick disconnect require a mating cordset

#### Mounting

Integral mounting slots for M4 (#8) screws, tighten to 5 in-lbf max torque Multiple bracket options available
Secure cables within 150 mm (5.9 in) of the light



Note: It is recommended to use the provided mounting bushings when mounting using the endcaps. Center the mounting bushings in each slot to allow for expansion and contraction. Install using a M4 (#8) screw in each bushing torqued to a maximum of 0.45 N-m (4 in-lbf). For 920 mm and 1200 mm models in environments that vary more than 10 °C (18 °F), it is recommended to use one of the mounting bracket options instead of the end cap slots. If using the LMBWLS15 clip bracket and additional attachment is desired, only one end may be fastened using one of the spacers provided in the LMBWLS15 hardware packet to allow the opposite end to expand and contract. See mounting options in the instruction manual for bracket and tape options that allow expansion and contraction over temperature variations.

Environmental Rating
Rated IEC IP66 and IEC IP67
Suitable for wet locations per UL 2108

Vibration and Mechanical Shock
Vibration: 10 Hz to 55 Hz, 1.0 mm peak-to-peak amplitude per IEC 60068-2-6
Shock: 15G 11 ms duration, half sine wave per IEC 60068-2-27

 $\begin{array}{c} \textbf{Operating Temperature} \\ -40~^{\circ}\text{C to } +50~^{\circ}\text{C } (-40~^{\circ}\text{F to } +122~^{\circ}\text{F}) \\ \textbf{Storage Temperature:} -40~^{\circ}\text{C to } +70~^{\circ}\text{C } (-40~^{\circ}\text{F to } +158~^{\circ}\text{F}) \end{array}$ 

#### Certifications








		Color Coordinates <sup>2</sup>		Lumens at Specified Length (Typical at 25 °C)					
Color	Dominant Wavelength (nm) or Color Temperature (CCT)	x	Y	220 mm	360 mm	500 mm	640 mm	920 mm	1200 mm
Daylight White	5000K	0.345	0.352	30	60	90	120	180	240
Incandescent White	2700K	0.460	0.411	30	60	90	120	180	240
Warm White	3000K	0.440	0.404	30	60	90	120	180	240
Fluorescent White	4100K	0.376	0.374	30	60	90	120	180	240
Neutral White	5700K	0.328	0.337	30	60	90	120	180	240
Cool White	6500K	0.314	0.324	30	60	90	120	180	240
Green	532	0.181	0.735	45	90	135	180	270	360
Red	621	0.691	0.308	25	50	75	100	150	200
Yellow	578	0.473	0.474	35	70	105	140	210	280
Blue	467	0.137	0.056	10	20	30	40	60	80
Magenta	-	0.379	0.177	20	40	60	80	120	160
Cyan	492	0.150	0.334	30	60	90	120	180	240
Amber	590	0.552	0.414	30	60	90	120	180	240
Rose	-	0.508	0.230	25	50	75	100	150	200
Lime Green	565	0.393	0.535	40	80	120	160	240	320
Orange	600	0.611	0.370	30	60	90	120	180	240
Sky Blue	485	0.146	0.241	25	50	75	100	150	200
Violet	-	0.212	0.091	15	30	45	60	90	120
Spring Green	509	0.157	0.553	40	80	120	160	240	320

Refer to the CIE 1931 (x,y) Chromaticity Diagram to show equivalent color with indicated color coordinates. Actual coordinates may differ ± 5%.

## Dimensions



Models	L1	L2	L3
WLS150220	146.4 mm (5.76 inches)	194 mm (7.64 inches)	220 mm (8.66 inches)
WLS150360	286.4 mm (11.28 inches)	334 mm (13.15 inches)	360 mm (14.17 inches)
WLS150500	426.4 mm (16.79 inches)	474 mm (18.66 inches)	500 mm (19.69 inches)
WLS150640	566.4 mm (22.3 inches)	614 mm (24.17 inches)	640 mm (25.2 inches)
WLS150920	846.4 mm (33.32 inches)	894 mm (35.2 inches)	920 mm (36.22 inches)
WLS151200	1126.4 mm (44.35 inches)	1174 mm (46.22 inches)	1200 mm (47.24 inches)

## Accessories

## Cordsets

### PRO-KIT

#### Includes:

- Pro Converter Cable (MQDC-506-USB)
  Splitter (CSB-M1251FM1251M)
  Power Supply (PSW-24-1)



### MQDC-506-USB

- Pro Converter Cable
  1.83 m (6 ft) M12 quick disconnect to
  Device and USB to PC
  Required for connection to Pro Editor



## CSB-M1251FM1251M

- For in parallel Y splitter (Male-Male-Female)
  For full Pro Editor preview capability
  Requires external power supply, sold
  separately



#### PSW-24-1

- 24 V DC, 1 A power supply 2 m (6.5 ft) PVC cable with M12 quick disconnect Provides external power with splitter cable, sold separately



### PSD-24-4

- 90 to 264 V AC 50/60 Hz input
- Includes a 1.8 m (6 ft) US style 5-15P input plug
- 24 V DC UL Listed Class 2 M12 connector output
- 4 A total current



### LC28PB2-3Q

- In-line switch with M12
- connectors Rugged metal housing
- Perfect for dc-powered task lights, indicators, and tower lights
- Rated for up to 30 V dc




4-Pin Threaded M12 Cordsets—Single Ended					
Model	Length	Style	Dimensions	Pinout (Female)	
MQDC-406	2 m (6.56 ft)		<del></del>		
MQDC-415	5 m (16.4 ft)		44 тур.		
MQDC-430	9 m (29.5 ft)	Straight			
MQDC-450	15 m (49.2 ft)	-	M12 x 1 — ø 14.5 —	1 600 2	
MQDC-406RA	2 m (6.56 ft)		32 Typ. [1.26"] 30 Typ. [1.18"] 9 14.5 [0.57"]	4 3	
MQDC-415RA	5 m (16.4 ft)			1 – Brown	
MQDC-430RA	9 m (29.5 ft)				
MQDC-450RA	15 m (49.2 ft)	Right-Angle		1 = Brown 2 = White 3 = Blue 4 = Black	

## Mounting Accessories


#### LMBWLS15

- Stainless steel clip bracket
- Includes 3 clip brackets and 2 plastic spacers
- Clearance hole for M5 hardware



#### LMBWLS15-150S

- Set of 2 stainless steel swivel bracket, allows for 150° of movement
- Clearance hole for M5 button head screw



#### LMBWLS15MAG

- Set of 2 brackets
- Magnetic mounting bracket for attachment to steel and iron surfaces



#### LMBWLS15TD

- Includes 4 100 mm (4 in) strips of 3M<sup>™</sup> Dual Lock<sup>™</sup> reclosable fasteners
- Recommended for mounting to metal and plastic surfaces
- Strong, pressure-sensitive adhesive bonds on contact



#### LMBWLS15TF

- Includes 2 100 mm (4 in) strips of double-sided foam urethane strips
- Acrylic adhesive provides high bond strength to most surfaces
- Bonds to low surface energy plastics such as polypropylene and powder coated paints



All measurements are listed in millimeters [inches], unless noted otherwise.

## Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

## FCC Part 15 and CAN ICES-3 (B)/NMB-3(B)

This device complies with part 15 of the FCC Rules and CAN ICES-3 (B)/NMB-3(B). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
   This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules and CAN ICES-3 (B)/NMB-3(B). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  Increase the separation between the equipment and receiver.
  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  Consult the manufacturer.

## Mexican Importer

Banner Engineering de Mèxico, S. de R.L. de C.V. David Alfaro Siqueiros 103 Piso 2 Valle oriente San Pedro Garza Garcia Nuevo Leòn, C. P. 66269

81 8363.2714

